

DR Diagnostics List
(Note:For reference only)

model	year	system	subitem	function	subfunction
dr1	2000-2018	ENG	UAES 473MT	Read code	
dr1	2000-2018	ENG	UAES 473MT	Clear code	
dr1	2000-2018	ENG	UAES 473MT	Data Stream	
dr1	2000-2018	ENG	UAES 473MT	Sys. Info.	
dr1	2000-2018	ENG	UAES 473MT	Actuation	
dr1	2000-2018	ENG	DELPHI 472MT	Read code	
dr1	2000-2018	ENG	DELPHI 472MT	Clear code	
dr1	2000-2018	ENG	DELPHI 472MT	Data Stream	
dr1	2000-2018	ENG	DELPHI 472MT	Sys. Info.	
dr1	2000-2018	ENG	DELPHI 472MT	Actuation	
dr1	2000-2018	ENG	DELPHI 472MT	Special Functions	Read freeze frame
dr1	2000-2018	ENG	DELPHI 472MT	Special Functions	O2 sensor test
dr1	2000-2018	ENG	DELPHI 472MT	Special Functions	End of line test
dr1	2000-2018	ENG	MM 473AMT	Read code	
dr1	2000-2018	ENG	MM 473AMT	Clear code	
dr1	2000-2018	ENG	MM 473AMT	Data Stream	
dr1	2000-2018	ENG	MM 473AMT	Sys. Info.	
dr1	2000-2018	ENG	MM 473AMT	Actuation	
dr1	2000-2018	ENG	371MT UAES engine system	Read code	
dr1	2000-2018	ENG	371MT UAES engine system	Clear code	
dr1	2000-2018	ENG	371MT UAES engine system	Data Stream	
dr1	2000-2018	ENG	371MT UAES engine system	Sys. Info.	
dr1	2000-2018	ENG	371MT UAES engine system	Actuation	
dr1	2000-2018	ENG	1.3L FlexFuel engine system	Read code	
dr1	2000-2018	ENG	1.3L FlexFuel engine system	Clear code	
dr1	2000-2018	ENG	1.3L FlexFuel engine system	Data Stream	
dr1	2000-2018	ENG	1.3L FlexFuel engine system	Sys. Info.	
dr1	2000-2018	ENG	1.3L FlexFuel engine system	Actuation	
dr1	2000-2018	ENG	1.3L FlexFuel engine system	Special Functions	Read freeze frame
dr1	2000-2018	ENG	1.3L FlexFuel engine system	Special Functions	Write data

model	year	system	subitem	function	subfunction
dr1	2000-2018	ENG	1.3L FlexFuel engine system	Special Functions	Cold Start System EOL Inspection
dr1	2000-2018	ENG	1.3L FlexFuel engine system	Special Functions	EOBD function
dr1	2000-2018	ENG	477MT mechanical UAES engine system	Read code	
dr1	2000-2018	ENG	477MT mechanical UAES engine system	Clear code	
dr1	2000-2018	ENG	477MT mechanical UAES engine system	Data Stream	
dr1	2000-2018	ENG	477MT mechanical UAES engine system	Sys. Info.	
dr1	2000-2018	ENG	477MT mechanical UAES engine system	Actuation	
dr1	2000-2018	ENG	477MT mechanical UAES engine system	Special Functions	ECU Reset
dr1	2000-2018	ABS	ABS	Read code	
dr1	2000-2018	ABS	ABS	Clear code	
dr1	2000-2018	ABS	ABS	Data Stream	
dr1	2000-2018	ABS	ABS	Sys. Info.	
dr1	2000-2018	ABS	ABS	Special Functions	Hydraulic unit test
dr1	2000-2018	ABS	ABS	Special Functions	bleeding and fill brake fluid
dr1	2000-2018	IMMO	IMMO	Read code	
dr1	2000-2018	IMMO	IMMO	Clear code	
dr1	2000-2018	IMMO	IMMO	Data Stream	
dr1	2000-2018	IMMO	IMMO	Sys. Info.	
dr1	2000-2018	BCM	BCM	Read code	
dr1	2000-2018	BCM	BCM	Clear code	
dr1	2000-2018	BCM	BCM	Data Stream	
dr1	2000-2018	BCM	BCM	Special Functions	Key teach
dr1	2000-2018	SRS	EASTJOY SRS	Read code	
dr1	2000-2018	SRS	EASTJOY SRS	Clear code	
dr1	2000-2018	SRS	EASTJOY SRS	Data Stream	
dr1	2000-2018	SRS	EASTJOY SRS	Sys. Info.	
dr1	2000-2018	SRS	BOSCH SRS	Read code	
dr1	2000-2018	SRS	BOSCH SRS	Clear code	
dr1	2000-2018	SRS	BOSCH SRS	Data Stream	
dr1	2000-2018	SRS	BOSCH SRS	Sys. Info.	
dr1	2000-2018	ICM	MT ICM	Read code	
dr1	2000-2018	ICM	MT ICM	Clear code	
dr1	2000-2018	ICM	MT ICM	Data Stream	
dr1	2000-2018	ICM	MT ICM	Sys. Info.	
dr1	2000-2018	ICM	MT ICM	Actuation	

model	year	system	subitem	function	subfunction
dr1	2000-2018	ICM	MT ICM	Special Functions	Car Maintenance
dr1	2000-2018	ICM	MT ICM	Special Functions	ECU Reset
dr1	2000-2018	ICM	AMT ICM	Read code	
dr1	2000-2018	ICM	AMT ICM	Clear code	
dr1	2000-2018	ICM	AMT ICM	Data Stream	
dr1	2000-2018	ICM	AMT ICM	Sys. Info.	
dr1	2000-2018	ICM	AMT ICM	Actuation	
dr1	2000-2018	ICM	AMT ICM	Special Functions	Car Maintenance
dr1	2000-2018	ICM	FlexFuel ICM system	Read code	
dr1	2000-2018	ICM	FlexFuel ICM system	Clear code	
dr1	2000-2018	ICM	FlexFuel ICM system	Data Stream	
dr1	2000-2018	ICM	FlexFuel ICM system	Sys. Info.	
dr1	2000-2018	ICM	FlexFuel ICM system	Actuation	
dr1	2000-2018	ICM	FlexFuel ICM system	Special Functions	Car Maintenance
dr1	2000-2018	ICM	FlexFuel ICM system	Special Functions	ECU Reset
dr1	2000-2018	AT	MM CFC318C AT	Read code	
dr1	2000-2018	AT	MM CFC318C AT	Clear code	
dr1	2000-2018	AT	MM CFC318C AT	Data Stream	
dr1	2000-2018	AT	MM CFC318C AT	Sys. Info.	
dr1	2000-2018	AT	MM CFC318C AT	Actuation	
dr1	2000-2018	AT	MM CFC318C AT	Special Functions	EOL function
dr2	2000-2018	ENG	UAES system	Sys. Info.	
dr2	2000-2018	ENG	UAES system	Read code	
dr2	2000-2018	ENG	UAES system	Clear code	
dr2	2000-2018	ENG	UAES system	Data Stream	
dr2	2000-2018	ENG	UAES system	Actuation	
dr2	2000-2018	ENG	MM 472 system	Sys. Info.	
dr2	2000-2018	ENG	MM 472 system	Read code	
dr2	2000-2018	ENG	MM 472 system	Clear code	
dr2	2000-2018	ENG	MM 472 system	Data Stream	
dr2	2000-2018	ENG	MM 472 system	Actuation	
dr2	2000-2018	ENG	UAES system EOBD module	Read code	
dr2	2000-2018	ENG	UAES system EOBD module	Clear code	
dr2	2000-2018	ENG	UAES system EOBD module	Data Stream	
dr2	2000-2018	ENG	MM 473 AMT system	Sys. Info.	
dr2	2000-2018	ENG	MM 473 AMT system	Read code	
dr2	2000-2018	ENG	MM 473 AMT system	Clear code	
dr2	2000-2018	ENG	MM 473 AMT system	Data Stream	
dr2	2000-2018	ENG	MM 473 AMT system	Actuation	

model	year	system	subitem	function	subfunction
dr2	2000-2018	ENG	MM 473 AMT system	Special Functions	freeze frame data
dr2	2000-2018	ENG	MM 473 AMT system	Special Functions	Reset To Default
dr2	2000-2018	ENG	DELPHI 473 system	Sys. Info.	
dr2	2000-2018	ENG	DELPHI 473 system	Read code	
dr2	2000-2018	ENG	DELPHI 473 system	Clear code	
dr2	2000-2018	ENG	DELPHI 473 system	Data Stream	
dr2	2000-2018	ENG	DELPHI 473 system	Actuation	
dr2	2000-2018	ENG	DELPHI 473 system	Special Functions	Read freeze frame
dr2	2000-2018	ENG	DELPHI 473 system	Special Functions	End of line test
dr2	2000-2018	ENG	DELPHI ETHANOL system	Sys. Info.	
dr2	2000-2018	ENG	DELPHI ETHANOL system	Read code	
dr2	2000-2018	ENG	DELPHI ETHANOL system	Clear code	
dr2	2000-2018	ENG	DELPHI ETHANOL system	Data Stream	
dr2	2000-2018	ENG	DELPHI ETHANOL system	Actuation	
dr2	2000-2018	ENG	DELPHI ETHANOL system	Special Functions	Read freeze frame
dr2	2000-2018	ENG	DELPHI ETHANOL system	Special Functions	End of line test
dr2	2000-2018	ENG	Continent engine system(E4G13)	Sys. Info.	
dr2	2000-2018	ENG	Continent engine system(E4G13)	Read code	
dr2	2000-2018	ENG	Continent engine system(E4G13)	Clear code	
dr2	2000-2018	ENG	Continent engine system(E4G13)	Data Stream	
dr2	2000-2018	ENG	Continent engine system(E4G13)	Actuation	
dr2	2000-2018	ENG	Continent engine system(E4G13)	Special Functions	Read freeze frame
dr2	2000-2018	ENG	Continent engine system(E4G13)	Special Functions	Reset all adaptive value
dr2	2000-2018	ENG	1.3L FlexFuel engine system	Sys. Info.	
dr2	2000-2018	ENG	1.3L FlexFuel engine system	Read code	
dr2	2000-2018	ENG	1.3L FlexFuel engine system	Clear code	
dr2	2000-2018	ENG	1.3L FlexFuel engine system	Data Stream	
dr2	2000-2018	ENG	1.3L FlexFuel engine system	Actuation	
dr2	2000-2018	ENG	1.3L FlexFuel engine system	Special Functions	Read freeze frame

model	year	system	subitem	function	subfunction
dr2	2000-2018	ENG	1.3L FlexFuel engine system	Special Functions	Write data
dr2	2000-2018	ENG	1.3L FlexFuel engine system	Special Functions	Cold Start System EOL Inspection
dr2	2000-2018	ENG	1.3L FlexFuel engine system	Special Functions	EOBD function
dr2	2000-2018	ABS	MGH-25 ABS system	Sys. Info.	
dr2	2000-2018	ABS	MGH-25 ABS system	Read code	
dr2	2000-2018	ABS	MGH-25 ABS system	Clear code	
dr2	2000-2018	ABS	MGH-25 ABS system	Data Stream	
dr2	2000-2018	ABS	MGH-25 ABS system	Actuation	
dr2	2000-2018	ABS	MGH-60 ABS system	Sys. Info.	
dr2	2000-2018	ABS	MGH-60 ABS system	Read code	
dr2	2000-2018	ABS	MGH-60 ABS system	Clear code	
dr2	2000-2018	ABS	MGH-60 ABS system	Data Stream	
dr2	2000-2018	ABS	MGH-60 ABS system	Actuation	
dr2	2000-2018	SRS	SRS	Sys. Info.	
dr2	2000-2018	SRS	SRS	Read code	
dr2	2000-2018	SRS	SRS	Clear code	
dr2	2000-2018	BCM	A TECH BCM	Read code	
dr2	2000-2018	BCM	A TECH BCM	Clear code	
dr2	2000-2018	BCM	A TECH BCM	Data Stream	
dr2	2000-2018	BCM	A TECH BCM	Special Functions	Key Teach
dr2	2000-2018	BCM	ZhongSheng BCM	Read code	
dr2	2000-2018	BCM	ZhongSheng BCM	Clear code	
dr2	2000-2018	BCM	ZhongSheng BCM	Data Stream	
dr2	2000-2018	BCM	ZhongSheng BCM	Special Functions	Key Teach
dr2	2000-2018	ICM	A TECH ICM	Sys. Info.	
dr2	2000-2018	ICM	A TECH ICM	Read code	
dr2	2000-2018	ICM	A TECH ICM	Clear code	
dr2	2000-2018	ICM	A TECH ICM	Data Stream	
dr2	2000-2018	ICM	A TECH ICM	Actuation	
dr2	2000-2018	ICM	A TECH ICM	Special Functions	Reset Car Maintenance
dr2	2000-2018	ICM	AMT series A TECH ICM	Sys. Info.	
dr2	2000-2018	ICM	AMT series A TECH ICM	Read code	
dr2	2000-2018	ICM	AMT series A TECH ICM	Clear code	
dr2	2000-2018	ICM	AMT series A TECH ICM	Data Stream	
dr2	2000-2018	ICM	AMT series A TECH ICM	Actuation	
dr2	2000-2018	ICM	AMT series A TECH ICM	Special Functions	Reset Car Maintenance
dr2	2000-2018	IMMO	SHAIHAI SHIYE IMMO	Sys. Info.	
dr2	2000-2018	IMMO	SHAIHAI SHIYE IMMO	Read code	
dr2	2000-2018	IMMO	SHAIHAI SHIYE IMMO	Clear code	
dr2	2000-2018	IMMO	SHAIHAI SHIYE IMMO	Data Stream	

model	year	system	subitem	function	subfunction
dr2	2000-2018	IMMO	SHAIHAI SHIYE IMMO	Special Functions	input code
dr2	2000-2018	IMMO	SHAIHAI SHIYE IMMO	Special Functions	immobilizer adapt
dr2	2000-2018	IMMO	DELPHI IMMO	Sys. Info.	
dr2	2000-2018	IMMO	DELPHI IMMO	Read code	
dr2	2000-2018	IMMO	DELPHI IMMO	Clear code	
dr2	2000-2018	IMMO	DELPHI IMMO	Data Stream	
dr2	2000-2018	IMMO	DELPHI IMMO	Special Functions	Immobilizer matching function
dr2	2000-2018	IMMO	DELPHI IMMO	Special Functions	Set user's authority code
dr2	2000-2018	IMMO	DELPHI IMMO	Special Functions	Input user's authority code
dr2	2000-2018	MM A/T	MM A/T	Sys. Info.	
dr2	2000-2018	MM A/T	MM A/T	Read code	
dr2	2000-2018	MM A/T	MM A/T	Clear code	
dr2	2000-2018	MM A/T	MM A/T	Data Stream	
dr2	2000-2018	MM A/T	MM A/T	Actuation	
dr2	2000-2018	MM A/T	MM A/T	Special Functions	EOL function
dr3	2000-2018	EMS	EMS	Sys. Info.	
dr3	2000-2018	EMS	EMS	Read code	
dr3	2000-2018	EMS	EMS	Clear code	
dr3	2000-2018	EMS	EMS	Data Stream	
dr3	2000-2018	EMS	EMS	Actuation	
dr3	2000-2018	EMS	EMS	Special Functions	Special function
dr3	2000-2018	BSM	BSM	Sys. Info.	
dr3	2000-2018	BSM	BSM	Read code	
dr3	2000-2018	BSM	BSM	Clear code	
dr3	2000-2018	BSM	BSM	Data Stream	
dr3	2000-2018	BSM	BSM	Special Functions	Freeze frame
dr3	2000-2018	BSM	BSM	Special Functions	Special function
dr3	2000-2018	ICM	ICM	Sys. Info.	
dr3	2000-2018	ICM	ICM	Read code	
dr3	2000-2018	ICM	ICM	Clear code	
dr3	2000-2018	ICM	ICM	Data Stream	
dr3	2000-2018	ICM	ICM	Actuation	
dr3	2000-2018	ICM	ICM	Special Functions	Special function
dr3	2000-2018	BCM	BCM	Sys. Info.	
dr3	2000-2018	BCM	BCM	Read code	
dr3	2000-2018	BCM	BCM	Clear code	

model	year	system	subitem	function	subfunction
dr3	2000-2018	BCM	BCM	Data Stream	
dr3	2000-2018	BCM	BCM	Actuation	
dr3	2000-2018	BCM	BCM	Special Functions	Special function
dr3	2000-2018	RRM	RRM	Sys. Info.	
dr3	2000-2018	RRM	RRM	Read code	
dr3	2000-2018	RRM	RRM	Clear code	
dr3	2000-2018	RRM	RRM	Data Stream	
dr3	2000-2018	RRM	RRM	Actuation	
dr3	2000-2018	RRM	RRM	Special Functions	Special function
dr3	2000-2018	TPMS	TPMS	Sys. Info.	
dr3	2000-2018	TPMS	TPMS	Read code	
dr3	2000-2018	TPMS	TPMS	Clear code	
dr3	2000-2018	TPMS	TPMS	Data Stream	
dr3	2000-2018	TPMS	TPMS	Special Functions	Freeze frame
dr3	2000-2018	TPMS	TPMS	Special Functions	Special function
dr3	2000-2018	TCU	TCU	Sys. Info.	
dr3	2000-2018	TCU	TCU	Read code	
dr3	2000-2018	TCU	TCU	Clear code	
dr3	2000-2018	TCU	TCU	Data Stream	
dr3	2000-2018	TCU	TCU	Actuation	
dr3	2000-2018	SAM	SAM	Sys. Info.	
dr3	2000-2018	SAM	SAM	Read code	
dr3	2000-2018	SAM	SAM	Data Stream	
dr3	2000-2018	SAM	SAM	Special Functions	Re-calibration
dr3	2000-2018	SAM	SAM	Special Functions	Initial calibration
dr3	2000-2018	RADAR	RADAR	Sys. Info.	
dr3	2000-2018	RADAR	RADAR	Read code	
dr3	2000-2018	RADAR	RADAR	Clear code	
dr3	2000-2018	RADAR	RADAR	Data Stream	
dr3	2000-2018	ABM	ABM	Sys. Info.	
dr3	2000-2018	ABM	ABM	Read code	
dr3	2000-2018	ABM	ABM	Clear code	
dr3	2000-2018	ABM	ABM	Data Stream	
dr3	2000-2018	ABM	ABM	Special Functions	ECU reset
dr3	2000-2018	IMMO	IMMO	Sys. Info.	
dr3	2000-2018	IMMO	IMMO	Read code	
dr3	2000-2018	IMMO	IMMO	Clear code	
dr3	2000-2018	IMMO	IMMO	Special Functions	write data
dr3	2000-2018	IMMO	IMMO	Special Functions	after sale function
dr3	2000-2018	EPS	EPS	Sys. Info.	

model	year	system	subitem	function	subfunction
dr3	2000-2018	EPS	EPS	Read code	
dr3	2000-2018	EPS	EPS	Clear code	
dr3	2000-2018	EPS	EPS	Data Stream	
dr3	2000-2018	EPS	EPS	Special Functions	Freeze frame
dr3	2000-2018	EPS	EPS	Special Functions	Special function
dr4	2000-2018	EMS	MT	Sys. Info.	
dr4	2000-2018	EMS	MT	Read code	
dr4	2000-2018	EMS	MT	Clear code	
dr4	2000-2018	EMS	MT	Data Stream	
dr4	2000-2018	EMS	MT	Actuation	
dr4	2000-2018	EMS	MT	Special Functions	Write ECU installation date
dr4	2000-2018	EMS	CVT	Sys. Info.	
dr4	2000-2018	EMS	CVT	Read code	
dr4	2000-2018	EMS	CVT	Clear code	
dr4	2000-2018	EMS	CVT	Data Stream	
dr4	2000-2018	EMS	CVT	Actuation	
dr4	2000-2018	EMS	CVT	Special Functions	Write ECU installation date
dr4	2000-2018	EMS	CVT	Special Functions	Gear info. learning
dr4	2000-2018	ABS	ABS	Sys. Info.	
dr4	2000-2018	ABS	ABS	Read code	
dr4	2000-2018	ABS	ABS	Clear code	
dr4	2000-2018	ABS	ABS	Data Stream	
dr4	2000-2018	ABS	ABS	Actuation	
dr4	2000-2018	ABS	ABS	Special Functions	Freeze Frame data
dr4	2000-2018	ABS	ABS	Special Functions	Write ECU installation date
dr4	2000-2018	ABS	ABS	Special Functions	Repair bleed
dr4	2000-2018	ABS	ABS	Special Functions	Sensor calibration
dr4	2000-2018	TCU (CVT)	TCU (CVT)	Sys. Info.	
dr4	2000-2018	TCU (CVT)	TCU (CVT)	Read code	
dr4	2000-2018	TCU (CVT)	TCU (CVT)	Clear code	
dr4	2000-2018	TCU (CVT)	TCU (CVT)	Special Functions	learned value clear
dr4	2000-2018	BCM	BCM	Sys. Info.	
dr4	2000-2018	BCM	BCM	Read code	
dr4	2000-2018	BCM	BCM	Clear code	
dr4	2000-2018	BCM	BCM	Data Stream	
dr4	2000-2018	BCM	BCM	Actuation	

model	year	system	subitem	function	subfunction
dr4	2000-2018	BCM	BCM	Special Functions	write VIN
dr4	2000-2018	BCM	BCM	Special Functions	Write ECU installation date
dr4	2000-2018	BCM	BCM	Special Functions	Write vehicle
dr4	2000-2018	ICM	ICM	Sys. Info.	
dr4	2000-2018	ICM	ICM	Read code	
dr4	2000-2018	ICM	ICM	Clear code	
dr4	2000-2018	ICM	ICM	Actuation	
dr4	2000-2018	ICM	ICM	Special Functions	write VIN
dr4	2000-2018	ICM	ICM	Special Functions	SAS Sensor calibration
dr4	2000-2018	ICM	ICM	Special Functions	Write ECU installation date
dr4	2000-2018	ICM	ICM	Special Functions	Write vchle special code
dr4	2000-2018	EPS	EPS	Sys. Info.	
dr4	2000-2018	EPS	EPS	Read code	
dr4	2000-2018	EPS	EPS	Clear code	
dr4	2000-2018	EPS	EPS	Data Stream	
dr4	2000-2018	EPS	EPS	Special Functions	Write ECU installation date
dr4	2000-2018	EPS	EPS	Special Functions	Angle sensor learning
dr4	2000-2018	TPMS	TPMS	Sys. Info.	
dr4	2000-2018	TPMS	TPMS	Read code	
dr4	2000-2018	TPMS	TPMS	Clear code	
dr4	2000-2018	TPMS	TPMS	Special Functions	Write ECU installation date
dr4	2000-2018	IMMO	IMMO	Sys. Info.	
dr4	2000-2018	IMMO	IMMO	Read code	
dr4	2000-2018	IMMO	IMMO	Clear code	
dr4	2000-2018	IMMO	IMMO	Data Stream	
dr4	2000-2018	IMMO	IMMO	Special Functions	Write ECU installation date
dr4	2000-2018	IMMO	IMMO	Special Functions	after sale functoin
dr4	2000-2018	MP5	MP5	Sys. Info.	
dr4	2000-2018	MP5	MP5	Read code	
dr4	2000-2018	MP5	MP5	Clear code	
dr4	2000-2018	MP5	MP5	Actuation	

model	year	system	subitem	function	subfunction
dr4	2000-2018	MP5	MP5	Special Functions	Write ECU installation date
dr4	2000-2018	HVAC	HVAC	Sys. Info.	
dr4	2000-2018	HVAC	HVAC	Read code	
dr4	2000-2018	HVAC	HVAC	Clear code	
dr4	2000-2018	HVAC	HVAC	Actuation	
dr4	2000-2018	HVAC	HVAC	Special Functions	Write ECU installation date
dr4	2000-2018	PEPS	PEPS	Sys. Info.	
dr4	2000-2018	PEPS	PEPS	Read code	
dr4	2000-2018	PEPS	PEPS	Clear code	
dr4	2000-2018	PEPS	PEPS	Data Stream	
dr4	2000-2018	PEPS	PEPS	Special Functions	Write ECU installation date
dr4	2000-2018	PEPS	PEPS	Special Functions	after sale functoin
dr4	2000-2018	APM	APM	Sys. Info.	
dr4	2000-2018	APM	APM	Read code	
dr4	2000-2018	APM	APM	Clear code	
dr4	2000-2018	APM	APM	Data Stream	
dr4	2000-2018	APM	APM	Actuation	
dr4	2000-2018	APM	APM	Special Functions	Special Operations
dr4	2000-2018	AVM	AVM	Sys. Info.	
dr4	2000-2018	AVM	AVM	Read code	
dr4	2000-2018	AVM	AVM	Clear code	
dr4	2000-2018	AVM	AVM	Actuation	
dr4	2000-2018	AVM	AVM	Special Functions	Write ECU installation date
dr4	2000-2018	AVM	AVM	Special Functions	AVM calibration
dr4	2000-2018	T-BOX	T-BOX	Sys. Info.	
dr4	2000-2018	T-BOX	T-BOX	Read code	
dr4	2000-2018	T-BOX	T-BOX	Clear code	
dr4	2000-2018	T-BOX	T-BOX	Data Stream	
dr4	2000-2018	T-BOX	T-BOX	Special Functions	Write ECU installation date
dr5	2000-2018	ENG	Delphi system 2.0L/2.4L(4G63/4G64)	Sys. Info.	
dr5	2000-2018	ENG	Delphi system 2.0L/2.4L(4G63/4G64)	Read code	
dr5	2000-2018	ENG	Delphi system 2.0L/2.4L(4G63/4G64)	Clear code	

model	year	system	subitem	function	subfunction
dr5	2000-2018	ENG	Delphi system 2. 0L/2. 4L (4G63/4G64)	Data Stream	
dr5	2000-2018	ENG	Delphi system 2. 0L/2. 4L (4G63/4G64)	Actuation	
dr5	2000-2018	ENG	Delphi system 1. 6L (481F)	Sys. Info.	
dr5	2000-2018	ENG	Delphi system 1. 6L (481F)	Read code	
dr5	2000-2018	ENG	Delphi system 1. 6L (481F)	Clear code	
dr5	2000-2018	ENG	Delphi system 1. 6L (481F)	Data Stream	
dr5	2000-2018	ENG	Delphi system 1. 6L (481F)	Actuation	
dr5	2000-2018	ENG	Delphi system 1. 6L (481F)	Special Functions	Write VIN
dr5	2000-2018	ENG	Delphi system 1. 6L (481F)	Special Functions	Gear information learning
dr5	2000-2018	ENG	Delphi system 1. 6L (481F)	Special Functions	EBOD diagnostic Function
dr5	2000-2018	ENG	Mitsubishi system 2. 0L/2. 4L (4G63/4G64)	Read code	
dr5	2000-2018	ENG	Mitsubishi system 2. 0L/2. 4L (4G63/4G64)	Clear code	
dr5	2000-2018	ENG	Mitsubishi system 2. 0L/2. 4L (4G63/4G64)	Data Stream	
dr5	2000-2018	ENG	Mitsubishi system 2. 0L/2. 4L (4G63/4G64)	Actuation	
dr5	2000-2018	ENG	UAES system 1. 6L (484F)	Sys. Info.	
dr5	2000-2018	ENG	UAES system 1. 6L (484F)	Read code	
dr5	2000-2018	ENG	UAES system 1. 6L (484F)	Clear code	
dr5	2000-2018	ENG	UAES system 1. 6L (484F)	Data Stream	
dr5	2000-2018	ENG	UAES system 1. 6L (484F)	Actuation	
dr5	2000-2018	ENG	UAES system 2. 0L (484F)	Sys. Info.	
dr5	2000-2018	ENG	UAES system 2. 0L (484F)	Read code	
dr5	2000-2018	ENG	UAES system 2. 0L (484F)	Clear code	
dr5	2000-2018	ENG	UAES system 2. 0L (484F)	Data Stream	
dr5	2000-2018	ENG	UAES system 2. 0L (484F)	Actuation	
dr5	2000-2018	ENG	UAES system module 1. 6L/2. 0MT (481F/484F)	Read code	
dr5	2000-2018	ENG	UAES system module 1. 6L/2. 0MT (481F/484F)	Clear code	
dr5	2000-2018	ENG	UAES system module 1. 6L/2. 0MT (481F/484F)	Data Stream	
dr5	2000-2018	ENG	DPO UAES system module 2. 0AT (484F)	Read code	

model	year	system	subitem	function	subfunction
dr5	2000-2018	ENG	DPO UAES system module 2.0AT(484F)	Clear code	
dr5	2000-2018	ENG	DPO UAES system module 2.0AT(484F)	Data Stream	
dr5	2000-2018	ENG	MM system 1.8L(481FC)	Sys. Info.	
dr5	2000-2018	ENG	MM system 1.8L(481FC)	Read code	
dr5	2000-2018	ENG	MM system 1.8L(481FC)	Clear code	
dr5	2000-2018	ENG	MM system 1.8L(481FC)	Data Stream	
dr5	2000-2018	ENG	MM system 1.8L(481FC)	Actuation	
dr5	2000-2018	ENG	MM system 1.8L(481FC)	Special Functions	freeze frame data
dr5	2000-2018	ENG	MM system 1.8L(481FC)	Special Functions	Reset To Default
dr5	2000-2018	ENG	MM system EOBD module 1.8L(481FC)	Read code	
dr5	2000-2018	ENG	MM system EOBD module 1.8L(481FC)	Clear code	
dr5	2000-2018	ENG	MM system EOBD module 1.8L(481FC)	Data Stream	
dr5	2000-2018	ENG	UAES system 1.6L(VVT)	Sys. Info.	
dr5	2000-2018	ENG	UAES system 1.6L(VVT)	Read code	
dr5	2000-2018	ENG	UAES system 1.6L(VVT)	Clear code	
dr5	2000-2018	ENG	UAES system 1.6L(VVT)	Data Stream	
dr5	2000-2018	ENG	UAES system 1.6L(VVT)	Actuation	
dr5	2000-2018	ENG	UAES system 1.6L(VVT)	Special Functions	ECU reset
dr5	2000-2018	ENG	UAES system 1.6L(VVT)	Special Functions	Start routine
dr5	2000-2018	ENG	UAES system 1.6L(VVT)	Special Functions	VVT function test
dr5	2000-2018	ENG	BOSCH diesel system 1.9L(481A)	Sys. Info.	
dr5	2000-2018	ENG	BOSCH diesel system 1.9L(481A)	Read code	
dr5	2000-2018	ENG	BOSCH diesel system 1.9L(481A)	Clear code	
dr5	2000-2018	ENG	BOSCH diesel system 1.9L(481A)	Data Stream	
dr5	2000-2018	ENG	BOSCH diesel system 1.9L(481A)	Actuation	
dr5	2000-2018	ENG	BOSCH diesel system 1.9L(481A)	Special Functions	IQA
dr5	2000-2018	ENG	BOSCH diesel system 1.9L(481A)	Special Functions	Freeze frame
dr5	2000-2018	ENG	BOSCH diesel system 1.9L(481A)	Special Functions	VSA self-learning
dr5	2000-2018	ENG	BOSCH diesel system 1.9L(481A)	Special Functions	ECU internal data area setting

model	year	system	subitem	function	subfunction
dr5	2000-2018	ENG	UAES system 2.0D(VVT)	Sys. Info.	
dr5	2000-2018	ENG	UAES system 2.0D(VVT)	Read code	
dr5	2000-2018	ENG	UAES system 2.0D(VVT)	Clear code	
dr5	2000-2018	ENG	UAES system 2.0D(VVT)	Data Stream	
dr5	2000-2018	ENG	UAES system 2.0D(VVT)	Actuation	
dr5	2000-2018	ENG	UAES system 2.0D(VVT)	Special Functions	ECU reset
dr5	2000-2018	ENG	T11FL2 CEMS	Sys. Info.	
dr5	2000-2018	ENG	T11FL2 CEMS	Read code	
dr5	2000-2018	ENG	T11FL2 CEMS	Clear code	
dr5	2000-2018	ENG	T11FL2 CEMS	Data Stream	
dr5	2000-2018	ENG	T11FL2 CEMS	Actuation	
dr5	2000-2018	ENG	T11FL2 CEMS	Special Functions	Request Current Powertrain Diagnostic Data
dr5	2000-2018	ENG	T11FL2 CEMS	Special Functions	Request Powertrain Freeze Frame Data
dr5	2000-2018	ENG	T11FL2 CEMS	Special Functions	Request Vehicle Information
dr5	2000-2018	SRS	HYUNDAI SRS system	Sys. Info.	
dr5	2000-2018	SRS	HYUNDAI SRS system	Read code	
dr5	2000-2018	SRS	HYUNDAI SRS system	Clear code	
dr5	2000-2018	SRS	Continental SRS system	Sys. Info.	
dr5	2000-2018	SRS	Continental SRS system	Read code	
dr5	2000-2018	SRS	Continental SRS system	Clear code	
dr5	2000-2018	SRS	Continental SRS system	Data Stream	
dr5	2000-2018	SRS	Continental SRS system	Actuation	
dr5	2000-2018	SRS	Continental SRS system	Special Functions	Write data
dr5	2000-2018	SRS	Continental SRS system	Special Functions	ECU reset (power on)
dr5	2000-2018	ABS	MGH-25 ABS system	Sys. Info.	
dr5	2000-2018	ABS	MGH-25 ABS system	Read code	
dr5	2000-2018	ABS	MGH-25 ABS system	Clear code	
dr5	2000-2018	ABS	MGH-25 ABS system	Data Stream	
dr5	2000-2018	ABS	MGH-25 ABS system	Actuation	
dr5	2000-2018	ABS	MGH-40 ABS system	Sys. Info.	
dr5	2000-2018	ABS	MGH-40 ABS system	Read code	

model	year	system	subitem	function	subfunction
dr5	2000-2018	ABS	MGH-40 ABS system	Clear code	
dr5	2000-2018	ABS	MGH-40 ABS system	Data Stream	
dr5	2000-2018	ABS	MGH-40 ABS system	Actuation	
dr5	2000-2018	ABS	MGH-60 ABS system	Sys. Info.	
dr5	2000-2018	ABS	MGH-60 ABS system	Read code	
dr5	2000-2018	ABS	MGH-60 ABS system	Clear code	
dr5	2000-2018	ABS	MGH-60 ABS system	Data Stream	
dr5	2000-2018	ABS	MGH-60 ABS system	Actuation	
dr5	2000-2018	ISU	ISU	Data Stream	
dr5	2000-2018	ISU	ISU	Actuation	
dr5	2000-2018	ICM	Siemens system	Data Stream	
dr5	2000-2018	ICM	Siemens system	Actuation	
dr5	2000-2018	ICM	Atech system	Sys. Info.	
dr5	2000-2018	ICM	Atech system	Read code	
dr5	2000-2018	ICM	Atech system	Clear code	
dr5	2000-2018	ICM	Atech system	Actuation	
dr5	2000-2018	ICM	1.8AMT ATECH system	Sys. Info.	
dr5	2000-2018	ICM	1.8AMT ATECH system	Read code	
dr5	2000-2018	ICM	1.8AMT ATECH system	Clear code	
dr5	2000-2018	ICM	1.8AMT ATECH system	Data Stream	
dr5	2000-2018	ICM	1.8AMT ATECH system	Actuation	
dr5	2000-2018	ICM	1.8AMT ATECH system	Special Functions	Car Maintenance
dr5	2000-2018	ICM	1.6 VVT CVT ATECH system	Sys. Info.	
dr5	2000-2018	ICM	1.6 VVT CVT ATECH system	Read code	
dr5	2000-2018	ICM	1.6 VVT CVT ATECH system	Clear code	
dr5	2000-2018	ICM	1.6 VVT CVT ATECH system	Data Stream	
dr5	2000-2018	ICM	1.6 VVT CVT ATECH system	Actuation	
dr5	2000-2018	ICM	1.6 VVT CVT ATECH system	Special Functions	Car Maintenance
dr5	2000-2018	ICM	1.6 VVT CVT ATECH system	Special Functions	ECU reset
dr5	2000-2018	ICM	T11 1.6 RHD ICM system	Sys. Info.	
dr5	2000-2018	ICM	T11 1.6 RHD ICM system	Read code	
dr5	2000-2018	ICM	T11 1.6 RHD ICM system	Clear code	
dr5	2000-2018	ICM	T11 1.6 RHD ICM system	Data Stream	
dr5	2000-2018	ICM	T11 1.6 RHD ICM system	Actuation	
dr5	2000-2018	ICM	T11 1.6 RHD ICM system	Special Functions	Car Maintenance
dr5	2000-2018	ICM	T11 1.6 RHD ICM system	Special Functions	ECU reset
dr5	2000-2018	ITM	ITM	Sys. Info.	
dr5	2000-2018	ITM	ITM	Read code	
dr5	2000-2018	ITM	ITM	Clear code	

model	year	system	subitem	function	subfunction
dr5	2000-2018	A/T	Mitsubishi system	Read code	
dr5	2000-2018	A/T	Mitsubishi system	Clear code	
dr5	2000-2018	A/T	Mitsubishi system	Data Stream	
dr5	2000-2018	A/T	Mitsubishi system	Actuation	
dr5	2000-2018	A/T	DPO system	Sys. Info.	
dr5	2000-2018	A/T	DPO system	Read code	
dr5	2000-2018	A/T	DPO system	Clear code	
dr5	2000-2018	A/T	DPO system	Data Stream	
dr5	2000-2018	A/T	DPO system	Actuation	
dr5	2000-2018	A/T	DPO system	Special Functions	Routine
dr5	2000-2018	A/T	DPO system	Special Functions	EOBD Mode
dr5	2000-2018	A/T	DPO system	Special Functions	Freeze Frame
dr5	2000-2018	A/T	MM CFC318C system	Sys. Info.	
dr5	2000-2018	A/T	MM CFC318C system	Read code	
dr5	2000-2018	A/T	MM CFC318C system	Clear code	
dr5	2000-2018	A/T	MM CFC318C system	Data Stream	
dr5	2000-2018	A/T	MM CFC318C system	Actuation	
dr5	2000-2018	A/T	MM CFC318C system	Special Functions	EOL function
dr5	2000-2018	A/T	CVT TCU system	Read code	
dr5	2000-2018	A/T	CVT TCU system	Clear code	
dr5	2000-2018	A/T	CVT TCU system	Data Stream	
dr5	2000-2018	A/T	CVT TCU system	Special Functions	Read Freeze Frame Data
dr5	2000-2018	A/T	CVT TCU system	Special Functions	Clear adaptation of table
dr5	2000-2018	IMMO	IMMO	Sys. Info.	
dr5	2000-2018	IMMO	IMMO	Read code	
dr5	2000-2018	IMMO	IMMO	Clear code	
dr5	2000-2018	IMMO	IMMO	Data Stream	
dr5	2000-2018	IMMO	IMMO	Special Functions	input code
dr5	2000-2018	IMMO	IMMO	Special Functions	immobilizer adapt
dr5	2000-2018	BCm	BCM(AWA)	Read code	
dr5	2000-2018	BCm	BCM(AWA)	Clear code	
dr5	2000-2018	BCm	BCM(AWA)	Data Stream	
dr5	2000-2018	BCm	BCM(AWA)	Special Functions	key Teach
dr5	2000-2018	BCm	BCM(AWA)	Special Functions	Auto window lifting by RKE
dr5	2000-2018	BCm	Atech BCM system	Sys. Info.	
dr5	2000-2018	BCm	Atech BCM system	Read code	
dr5	2000-2018	BCm	Atech BCM system	Clear code	

model	year	system	subitem	function	subfunction
dr5	2000-2018	BCm	Atech BCM system	Data Stream	
dr5	2000-2018	BCm	Atech BCM system	Actuation	
dr5	2000-2018	BCm	Atech BCM system	Special Functions	Key Teach
dr5	2000-2018	BCm	Atech BCM system	Special Functions	Erase all keys
dr5	2000-2018	BCm	Atech BCM system	Special Functions	Reset function
dr5	2000-2018	APM	APM	Sys. Info.	
dr5	2000-2018	APM	APM	Read code	
dr5	2000-2018	APM	APM	Clear code	
dr5	2000-2018	APM	APM	Data Stream	
dr5	2000-2018	APM	APM	Actuation	
dr5	2000-2018	APM	APM	Special Functions	Special operation
dr5	2000-2018	RRM	RRM	Sys. Info.	
dr5	2000-2018	RRM	RRM	Read code	
dr5	2000-2018	RRM	RRM	Clear code	
dr5	2000-2018	RRM	RRM	Data Stream	
dr5	2000-2018	RRM	RRM	Actuation	
dr5	2000-2018	RRM	RRM	Special Functions	Special operation
dr5	2000-2018	ERG	ERG	Sys. Info.	
dr5	2000-2018	ERG	ERG	Read code	
dr5	2000-2018	ERG	ERG	Clear code	
dr5	2000-2018	ERG	ERG	Data Stream	
dr5	2000-2018	ERG	ERG	Special Functions	Special operation
dr5	2000-2018	MFM	MFM	Sys. Info.	
dr5	2000-2018	MFM	MFM	Read code	
dr5	2000-2018	MFM	MFM	Clear code	
dr5	2000-2018	MFM	MFM	Data Stream	
dr5	2000-2018	MFM	MFM	Actuation	
new dr5	2000-2018	ENG	Delphi system 2. 0L/2. 4L (4G63/4G64)	Sys. Info.	
new dr5	2000-2018	ENG	Delphi system 2. 0L/2. 4L (4G63/4G64)	Read code	
new dr5	2000-2018	ENG	Delphi system 2. 0L/2. 4L (4G63/4G64)	Clear code	
new dr5	2000-2018	ENG	Delphi system 2. 0L/2. 4L (4G63/4G64)	Data Stream	
new dr5	2000-2018	ENG	Delphi system 2. 0L/2. 4L (4G63/4G64)	Actuation	
new dr5	2000-2018	ENG	Delphi system 1. 6L (481F)	Sys. Info.	
new dr5	2000-2018	ENG	Delphi system 1. 6L (481F)	Read code	
new dr5	2000-2018	ENG	Delphi system 1. 6L (481F)	Clear code	

model	year	system	subitem	function	subfunction
new dr5	2000-2018	ENG	Delphi system 1.6L(481F)	Data Stream	
new dr5	2000-2018	ENG	Delphi system 1.6L(481F)	Actuation	
new dr5	2000-2018	ENG	Delphi system 1.6L(481F)	Special Functions	Write VIN
new dr5	2000-2018	ENG	Delphi system 1.6L(481F)	Special Functions	Gear information learning
new dr5	2000-2018	ENG	Delphi system 1.6L(481F)	Special Functions	EBOD diagnostic Function
new dr5	2000-2018	ENG	Mitsubishi system 2.0L/2.4L(4G63/4G64)	Read code	
new dr5	2000-2018	ENG	Mitsubishi system 2.0L/2.4L(4G63/4G64)	Clear code	
new dr5	2000-2018	ENG	Mitsubishi system 2.0L/2.4L(4G63/4G64)	Data Stream	
new dr5	2000-2018	ENG	Mitsubishi system 2.0L/2.4L(4G63/4G64)	Actuation	
new dr5	2000-2018	ENG	UAES system 1.6L(484F)	Sys. Info.	
new dr5	2000-2018	ENG	UAES system 1.6L(484F)	Read code	
new dr5	2000-2018	ENG	UAES system 1.6L(484F)	Clear code	
new dr5	2000-2018	ENG	UAES system 1.6L(484F)	Data Stream	
new dr5	2000-2018	ENG	UAES system 1.6L(484F)	Actuation	
new dr5	2000-2018	ENG	UAES system 2.0L(484F)	Sys. Info.	
new dr5	2000-2018	ENG	UAES system 2.0L(484F)	Read code	
new dr5	2000-2018	ENG	UAES system 2.0L(484F)	Clear code	
new dr5	2000-2018	ENG	UAES system 2.0L(484F)	Data Stream	
new dr5	2000-2018	ENG	UAES system 2.0L(484F)	Actuation	
new dr5	2000-2018	ENG	UAES system module 1.6L/2.0MT(481F/484F)	Read code	
new dr5	2000-2018	ENG	UAES system module 1.6L/2.0MT(481F/484F)	Clear code	
new dr5	2000-2018	ENG	UAES system module 1.6L/2.0MT(481F/484F)	Data Stream	
new dr5	2000-2018	ENG	DPO UAES system module 2.0AT(484F)	Read code	

model	year	system	subitem	function	subfunction
new dr5	2000-2018	ENG	DPO UAES system module 2.0AT(484F)	Clear code	
new dr5	2000-2018	ENG	DPO UAES system module 2.0AT(484F)	Data Stream	
new dr5	2000-2018	ENG	MM system 1.8L(481FC)	Sys. Info.	
new dr5	2000-2018	ENG	MM system 1.8L(481FC)	Read code	
new dr5	2000-2018	ENG	MM system 1.8L(481FC)	Clear code	
new dr5	2000-2018	ENG	MM system 1.8L(481FC)	Data Stream	
new dr5	2000-2018	ENG	MM system 1.8L(481FC)	Actuation	
new dr5	2000-2018	ENG	MM system 1.8L(481FC)	Special Functions	freeze frame data
new dr5	2000-2018	ENG	MM system 1.8L(481FC)	Special Functions	Reset To Default
new dr5	2000-2018	ENG	MM system EOBD module 1.8L(481FC)	Read code	
new dr5	2000-2018	ENG	MM system EOBD module 1.8L(481FC)	Clear code	
new dr5	2000-2018	ENG	MM system EOBD module 1.8L(481FC)	Data Stream	
new dr5	2000-2018	ENG	UAES system 1.6L(VVT)	Sys. Info.	
new dr5	2000-2018	ENG	UAES system 1.6L(VVT)	Read code	
new dr5	2000-2018	ENG	UAES system 1.6L(VVT)	Clear code	
new dr5	2000-2018	ENG	UAES system 1.6L(VVT)	Data Stream	
new dr5	2000-2018	ENG	UAES system 1.6L(VVT)	Actuation	
new dr5	2000-2018	ENG	UAES system 1.6L(VVT)	Special Functions	ECU reset
new dr5	2000-2018	ENG	UAES system 1.6L(VVT)	Special Functions	Start routine
new dr5	2000-2018	ENG	UAES system 1.6L(VVT)	Special Functions	VVT function test
new dr5	2000-2018	ENG	BOSCH diesel system 1.9L(481A)	Sys. Info.	
new dr5	2000-2018	ENG	BOSCH diesel system 1.9L(481A)	Read code	
new dr5	2000-2018	ENG	BOSCH diesel system 1.9L(481A)	Clear code	
new dr5	2000-2018	ENG	BOSCH diesel system 1.9L(481A)	Data Stream	

model	year	system	subitem	function	subfunction
new dr5	2000-2018	ENG	BOSCH diesel system 1.9L(481A)	Actuation	
new dr5	2000-2018	ENG	BOSCH diesel system 1.9L(481A)	Special Functions	IQA
new dr5	2000-2018	ENG	BOSCH diesel system 1.9L(481A)	Special Functions	Freeze frame
new dr5	2000-2018	ENG	BOSCH diesel system 1.9L(481A)	Special Functions	VSA self-learning
new dr5	2000-2018	ENG	BOSCH diesel system 1.9L(481A)	Special Functions	ECU internal data area setting
new dr5	2000-2018	ENG	UAES system 2.0D(VVT)	Sys. Info.	
new dr5	2000-2018	ENG	UAES system 2.0D(VVT)	Read code	
new dr5	2000-2018	ENG	UAES system 2.0D(VVT)	Clear code	
new dr5	2000-2018	ENG	UAES system 2.0D(VVT)	Data Stream	
new dr5	2000-2018	ENG	UAES system 2.0D(VVT)	Actuation	
new dr5	2000-2018	ENG	UAES system 2.0D(VVT)	Special Functions	ECU reset
new dr5	2000-2018	ENG	T11FL2 CEMS	Sys. Info.	
new dr5	2000-2018	ENG	T11FL2 CEMS	Read code	
new dr5	2000-2018	ENG	T11FL2 CEMS	Clear code	
new dr5	2000-2018	ENG	T11FL2 CEMS	Data Stream	
new dr5	2000-2018	ENG	T11FL2 CEMS	Actuation	
new dr5	2000-2018	ENG	T11FL2 CEMS	Special Functions	Request Current Powertrain Diagnostic Data
new dr5	2000-2018	ENG	T11FL2 CEMS	Special Functions	Request Powertrain Freeze Frame Data
new dr5	2000-2018	ENG	T11FL2 CEMS	Special Functions	Request Vehicle Information
new dr5	2000-2018	SRS	HYUNDAI SRS system	Sys. Info.	
new dr5	2000-2018	SRS	HYUNDAI SRS system	Read code	

model	year	system	subitem	function	subfunction
new dr5	2000-2018	SRS	HYUNDAI SRS system	Clear code	
new dr5	2000-2018	SRS	Continental SRS system	Sys. Info.	
new dr5	2000-2018	SRS	Continental SRS system	Read code	
new dr5	2000-2018	SRS	Continental SRS system	Clear code	
new dr5	2000-2018	SRS	Continental SRS system	Data Stream	
new dr5	2000-2018	SRS	Continental SRS system	Actuation	
new dr5	2000-2018	SRS	Continental SRS system	Special Functions	Write data
new dr5	2000-2018	SRS	Continental SRS system	Special Functions	ECU reset (power on)
new dr5	2000-2018	ABS	MGH-25 ABS system	Sys. Info.	
new dr5	2000-2018	ABS	MGH-25 ABS system	Read code	
new dr5	2000-2018	ABS	MGH-25 ABS system	Clear code	
new dr5	2000-2018	ABS	MGH-25 ABS system	Data Stream	
new dr5	2000-2018	ABS	MGH-25 ABS system	Actuation	
new dr5	2000-2018	ABS	MGH-40 ABS system	Sys. Info.	
new dr5	2000-2018	ABS	MGH-40 ABS system	Read code	
new dr5	2000-2018	ABS	MGH-40 ABS system	Clear code	
new dr5	2000-2018	ABS	MGH-40 ABS system	Data Stream	
new dr5	2000-2018	ABS	MGH-40 ABS system	Actuation	
new dr5	2000-2018	ABS	MGH-60 ABS system	Sys. Info.	
new dr5	2000-2018	ABS	MGH-60 ABS system	Read code	
new dr5	2000-2018	ABS	MGH-60 ABS system	Clear code	
new dr5	2000-2018	ABS	MGH-60 ABS system	Data Stream	
new dr5	2000-2018	ABS	MGH-60 ABS system	Actuation	
new dr5	2000-2018	ISU	ISU	Data Stream	

model	year	system	subitem	function	subfunction
new dr5	2000-2018	ISU	ISU	Actuation	
new dr5	2000-2018	ICM	Siemens system	Data Stream	
new dr5	2000-2018	ICM	Siemens system	Actuation	
new dr5	2000-2018	ICM	Atech system	Sys. Info.	
new dr5	2000-2018	ICM	Atech system	Read code	
new dr5	2000-2018	ICM	Atech system	Clear code	
new dr5	2000-2018	ICM	Atech system	Actuation	
new dr5	2000-2018	ICM	1.8AMT ATECH system	Sys. Info.	
new dr5	2000-2018	ICM	1.8AMT ATECH system	Read code	
new dr5	2000-2018	ICM	1.8AMT ATECH system	Clear code	
new dr5	2000-2018	ICM	1.8AMT ATECH system	Data Stream	
new dr5	2000-2018	ICM	1.8AMT ATECH system	Actuation	
new dr5	2000-2018	ICM	1.8AMT ATECH system	Special Functions	Car Maintenance
new dr5	2000-2018	ICM	1.6 VVT CVT ATECH system	Sys. Info.	
new dr5	2000-2018	ICM	1.6 VVT CVT ATECH system	Read code	
new dr5	2000-2018	ICM	1.6 VVT CVT ATECH system	Clear code	
new dr5	2000-2018	ICM	1.6 VVT CVT ATECH system	Data Stream	
new dr5	2000-2018	ICM	1.6 VVT CVT ATECH system	Actuation	
new dr5	2000-2018	ICM	1.6 VVT CVT ATECH system	Special Functions	Car Maintenance
new dr5	2000-2018	ICM	1.6 VVT CVT ATECH system	Special Functions	ECU reset
new dr5	2000-2018	ICM	T11 1.6 RHD ICM system	Sys. Info.	
new dr5	2000-2018	ICM	T11 1.6 RHD ICM system	Read code	
new dr5	2000-2018	ICM	T11 1.6 RHD ICM system	Clear code	
new dr5	2000-2018	ICM	T11 1.6 RHD ICM system	Data Stream	

model	year	system	subitem	function	subfunction
new dr5	2000-2018	ICM	T11 1.6 RHD ICM system	Actuation	
new dr5	2000-2018	ICM	T11 1.6 RHD ICM system	Special Functions	Car Maintenance
new dr5	2000-2018	ICM	T11 1.6 RHD ICM system	Special Functions	ECU reset
new dr5	2000-2018	ITM	ITM	Sys. Info.	
new dr5	2000-2018	ITM	ITM	Read code	
new dr5	2000-2018	ITM	ITM	Clear code	
new dr5	2000-2018	A/T	Mitsubishi system	Read code	
new dr5	2000-2018	A/T	Mitsubishi system	Clear code	
new dr5	2000-2018	A/T	Mitsubishi system	Data Stream	
new dr5	2000-2018	A/T	Mitsubishi system	Actuation	
new dr5	2000-2018	A/T	DPO system	Sys. Info.	
new dr5	2000-2018	A/T	DPO system	Read code	
new dr5	2000-2018	A/T	DPO system	Clear code	
new dr5	2000-2018	A/T	DPO system	Data Stream	
new dr5	2000-2018	A/T	DPO system	Actuation	
new dr5	2000-2018	A/T	DPO system	Special Functions	Routine
new dr5	2000-2018	A/T	DPO system	Special Functions	EOBD Mode
new dr5	2000-2018	A/T	DPO system	Special Functions	Freeze Frame
new dr5	2000-2018	A/T	MM CFC318C system	Sys. Info.	
new dr5	2000-2018	A/T	MM CFC318C system	Read code	
new dr5	2000-2018	A/T	MM CFC318C system	Clear code	
new dr5	2000-2018	A/T	MM CFC318C system	Data Stream	
new dr5	2000-2018	A/T	MM CFC318C system	Actuation	
new dr5	2000-2018	A/T	MM CFC318C system	Special Functions	EOL function

model	year	system	subitem	function	subfunction
new dr5	2000-2018	A/T	CVT TCU system	Read code	
new dr5	2000-2018	A/T	CVT TCU system	Clear code	
new dr5	2000-2018	A/T	CVT TCU system	Data Stream	
new dr5	2000-2018	A/T	CVT TCU system	Special Functions	Read Freeze Frame Data
new dr5	2000-2018	A/T	CVT TCU system	Special Functions	Clear adaptation of table
new dr5	2000-2018	IMMO	IMMO	Sys. Info.	
new dr5	2000-2018	IMMO	IMMO	Read code	
new dr5	2000-2018	IMMO	IMMO	Clear code	
new dr5	2000-2018	IMMO	IMMO	Data Stream	
new dr5	2000-2018	IMMO	IMMO	Special Functions	input code
new dr5	2000-2018	IMMO	IMMO	Special Functions	immobilizer adapt
new dr5	2000-2018	BCm	BCM(AWA)	Read code	
new dr5	2000-2018	BCm	BCM(AWA)	Clear code	
new dr5	2000-2018	BCm	BCM(AWA)	Data Stream	
new dr5	2000-2018	BCm	BCM(AWA)	Special Functions	key Teach
new dr5	2000-2018	BCm	BCM(AWA)	Special Functions	Auto window lifting by RKE
new dr5	2000-2018	BCm	Atech BCM system	Sys. Info.	
new dr5	2000-2018	BCm	Atech BCM system	Read code	
new dr5	2000-2018	BCm	Atech BCM system	Clear code	
new dr5	2000-2018	BCm	Atech BCM system	Data Stream	
new dr5	2000-2018	BCm	Atech BCM system	Actuation	
new dr5	2000-2018	BCm	Atech BCM system	Special Functions	Key Teach
new dr5	2000-2018	BCm	Atech BCM system	Special Functions	Erase all keys

model	year	system	subitem	function	subfunction
new dr5	2000-2018	BCm	Atech BCM system	Special Functions	Reset function
new dr5	2000-2018	APM	APM	Sys. Info.	
new dr5	2000-2018	APM	APM	Read code	
new dr5	2000-2018	APM	APM	Clear code	
new dr5	2000-2018	APM	APM	Data Stream	
new dr5	2000-2018	APM	APM	Actuation	
new dr5	2000-2018	APM	APM	Special Functions	Special operation
new dr5	2000-2018	RRM	RRM	Sys. Info.	
new dr5	2000-2018	RRM	RRM	Read code	
new dr5	2000-2018	RRM	RRM	Clear code	
new dr5	2000-2018	RRM	RRM	Data Stream	
new dr5	2000-2018	RRM	RRM	Actuation	
new dr5	2000-2018	RRM	RRM	Special Functions	Special operation
new dr5	2000-2018	ERG	ERG	Sys. Info.	
new dr5	2000-2018	ERG	ERG	Read code	
new dr5	2000-2018	ERG	ERG	Clear code	
new dr5	2000-2018	ERG	ERG	Data Stream	
new dr5	2000-2018	ERG	ERG	Special Functions	Special operation
new dr5	2000-2018	MFM	MFM	Sys. Info.	
new dr5	2000-2018	MFM	MFM	Read code	
new dr5	2000-2018	MFM	MFM	Clear code	
new dr5	2000-2018	MFM	MFM	Data Stream	
new dr5	2000-2018	MFM	MFM	Actuation	
dr evo5	2000-2018	ENG	Delphi system 2. 0L/2. 4L (4G63/4G64)	Sys. Info.	

model	year	system	subitem	function	subfunction
dr evo5	2000-2018	ENG	Delphi system 2. 0L/2. 4L (4G63/4G64)	Read code	
dr evo5	2000-2018	ENG	Delphi system 2. 0L/2. 4L (4G63/4G64)	Clear code	
dr evo5	2000-2018	ENG	Delphi system 2. 0L/2. 4L (4G63/4G64)	Data Stream	
dr evo5	2000-2018	ENG	Delphi system 2. 0L/2. 4L (4G63/4G64)	Actuation	
dr evo5	2000-2018	ENG	Delphi system 1. 6L (481F)	Sys. Info.	
dr evo5	2000-2018	ENG	Delphi system 1. 6L (481F)	Read code	
dr evo5	2000-2018	ENG	Delphi system 1. 6L (481F)	Clear code	
dr evo5	2000-2018	ENG	Delphi system 1. 6L (481F)	Data Stream	
dr evo5	2000-2018	ENG	Delphi system 1. 6L (481F)	Actuation	
dr evo5	2000-2018	ENG	Delphi system 1. 6L (481F)	Special Functions	Write VIN
dr evo5	2000-2018	ENG	Delphi system 1. 6L (481F)	Special Functions	Gear information learning
dr evo5	2000-2018	ENG	Delphi system 1. 6L (481F)	Special Functions	EBOD diagnostic Function
dr evo5	2000-2018	ENG	Mitsubishi system 2. 0L/2. 4L (4G63/4G64)	Read code	
dr evo5	2000-2018	ENG	Mitsubishi system 2. 0L/2. 4L (4G63/4G64)	Clear code	
dr evo5	2000-2018	ENG	Mitsubishi system 2. 0L/2. 4L (4G63/4G64)	Data Stream	
dr evo5	2000-2018	ENG	Mitsubishi system 2. 0L/2. 4L (4G63/4G64)	Actuation	
dr evo5	2000-2018	ENG	UAES system 1. 6L (484F)	Sys. Info.	
dr evo5	2000-2018	ENG	UAES system 1. 6L (484F)	Read code	
dr evo5	2000-2018	ENG	UAES system 1. 6L (484F)	Clear code	
dr evo5	2000-2018	ENG	UAES system 1. 6L (484F)	Data Stream	
dr evo5	2000-2018	ENG	UAES system 1. 6L (484F)	Actuation	
dr evo5	2000-2018	ENG	UAES system 2. 0L (484F)	Sys. Info.	
dr evo5	2000-2018	ENG	UAES system 2. 0L (484F)	Read code	

model	year	system	subitem	function	subfunction
dr evo5	2000-2018	ENG	UAES system 2.0L(484F)	Clear code	
dr evo5	2000-2018	ENG	UAES system 2.0L(484F)	Data Stream	
dr evo5	2000-2018	ENG	UAES system 2.0L(484F)	Actuation	
dr evo5	2000-2018	ENG	UAES system module 1.6L/2.0MT(481F/484F)	Read code	
dr evo5	2000-2018	ENG	UAES system module 1.6L/2.0MT(481F/484F)	Clear code	
dr evo5	2000-2018	ENG	UAES system module 1.6L/2.0MT(481F/484F)	Data Stream	
dr evo5	2000-2018	ENG	DPO UAES system module 2.0AT(484F)	Read code	
dr evo5	2000-2018	ENG	DPO UAES system module 2.0AT(484F)	Clear code	
dr evo5	2000-2018	ENG	DPO UAES system module 2.0AT(484F)	Data Stream	
dr evo5	2000-2018	ENG	MM system 1.8L(481FC)	Sys. Info.	
dr evo5	2000-2018	ENG	MM system 1.8L(481FC)	Read code	
dr evo5	2000-2018	ENG	MM system 1.8L(481FC)	Clear code	
dr evo5	2000-2018	ENG	MM system 1.8L(481FC)	Data Stream	
dr evo5	2000-2018	ENG	MM system 1.8L(481FC)	Actuation	
dr evo5	2000-2018	ENG	MM system 1.8L(481FC)	Special Functions	freeze frame data
dr evo5	2000-2018	ENG	MM system 1.8L(481FC)	Special Functions	Reset To Default
dr evo5	2000-2018	ENG	MM system EOBD module 1.8L(481FC)	Read code	
dr evo5	2000-2018	ENG	MM system EOBD module 1.8L(481FC)	Clear code	
dr evo5	2000-2018	ENG	MM system EOBD module 1.8L(481FC)	Data Stream	
dr evo5	2000-2018	ENG	UAES system 1.6L(VVT)	Sys. Info.	
dr evo5	2000-2018	ENG	UAES system 1.6L(VVT)	Read code	
dr evo5	2000-2018	ENG	UAES system 1.6L(VVT)	Clear code	
dr evo5	2000-2018	ENG	UAES system 1.6L(VVT)	Data Stream	
dr evo5	2000-2018	ENG	UAES system 1.6L(VVT)	Actuation	

model	year	system	subitem	function	subfunction
dr evo5	2000-2018	ENG	UAES system 1.6L(VVT)	Special Functions	ECU reset
dr evo5	2000-2018	ENG	UAES system 1.6L(VVT)	Special Functions	Start routine
dr evo5	2000-2018	ENG	UAES system 1.6L(VVT)	Special Functions	VVT function test
dr evo5	2000-2018	ENG	BOSCH diesel system 1.9L(481A)	Sys. Info.	
dr evo5	2000-2018	ENG	BOSCH diesel system 1.9L(481A)	Read code	
dr evo5	2000-2018	ENG	BOSCH diesel system 1.9L(481A)	Clear code	
dr evo5	2000-2018	ENG	BOSCH diesel system 1.9L(481A)	Data Stream	
dr evo5	2000-2018	ENG	BOSCH diesel system 1.9L(481A)	Actuation	
dr evo5	2000-2018	ENG	BOSCH diesel system 1.9L(481A)	Special Functions	IQA
dr evo5	2000-2018	ENG	BOSCH diesel system 1.9L(481A)	Special Functions	Freeze frame
dr evo5	2000-2018	ENG	BOSCH diesel system 1.9L(481A)	Special Functions	VSA self-learning
dr evo5	2000-2018	ENG	BOSCH diesel system 1.9L(481A)	Special Functions	ECU internal data area setting
dr evo5	2000-2018	ENG	UAES system 2.0D(VVT)	Sys. Info.	
dr evo5	2000-2018	ENG	UAES system 2.0D(VVT)	Read code	
dr evo5	2000-2018	ENG	UAES system 2.0D(VVT)	Clear code	
dr evo5	2000-2018	ENG	UAES system 2.0D(VVT)	Data Stream	
dr evo5	2000-2018	ENG	UAES system 2.0D(VVT)	Actuation	
dr evo5	2000-2018	ENG	UAES system 2.0D(VVT)	Special Functions	ECU reset
dr evo5	2000-2018	ENG	T11FL2 CEMS	Sys. Info.	
dr evo5	2000-2018	ENG	T11FL2 CEMS	Read code	
dr evo5	2000-2018	ENG	T11FL2 CEMS	Clear code	
dr evo5	2000-2018	ENG	T11FL2 CEMS	Data Stream	
dr evo5	2000-2018	ENG	T11FL2 CEMS	Actuation	

model	year	system	subitem	function	subfunction
dr evo5	2000-2018	ENG	T11FL2 CEMS	Special Functions	Request Current Powertrain Diagnostic Data
dr evo5	2000-2018	ENG	T11FL2 CEMS	Special Functions	Request Powertrain Freeze Frame Data
dr evo5	2000-2018	ENG	T11FL2 CEMS	Special Functions	Request Vehicle Information
dr evo5	2000-2018	SRS	HYUNDAI SRS system	Sys. Info.	
dr evo5	2000-2018	SRS	HYUNDAI SRS system	Read code	
dr evo5	2000-2018	SRS	HYUNDAI SRS system	Clear code	
dr evo5	2000-2018	SRS	Continental SRS system	Sys. Info.	
dr evo5	2000-2018	SRS	Continental SRS system	Read code	
dr evo5	2000-2018	SRS	Continental SRS system	Clear code	
dr evo5	2000-2018	SRS	Continental SRS system	Data Stream	
dr evo5	2000-2018	SRS	Continental SRS system	Actuation	
dr evo5	2000-2018	SRS	Continental SRS system	Special Functions	Write data
dr evo5	2000-2018	SRS	Continental SRS system	Special Functions	ECU reset (power on)
dr evo5	2000-2018	ABS	MGH-25 ABS system	Sys. Info.	
dr evo5	2000-2018	ABS	MGH-25 ABS system	Read code	
dr evo5	2000-2018	ABS	MGH-25 ABS system	Clear code	
dr evo5	2000-2018	ABS	MGH-25 ABS system	Data Stream	
dr evo5	2000-2018	ABS	MGH-25 ABS system	Actuation	
dr evo5	2000-2018	ABS	MGH-40 ABS system	Sys. Info.	
dr evo5	2000-2018	ABS	MGH-40 ABS system	Read code	
dr evo5	2000-2018	ABS	MGH-40 ABS system	Clear code	

model	year	system	subitem	function	subfunction
dr evo5	2000-2018	ABS	MGH-40 ABS system	Data Stream	
dr evo5	2000-2018	ABS	MGH-40 ABS system	Actuation	
dr evo5	2000-2018	ABS	MGH-60 ABS system	Sys. Info.	
dr evo5	2000-2018	ABS	MGH-60 ABS system	Read code	
dr evo5	2000-2018	ABS	MGH-60 ABS system	Clear code	
dr evo5	2000-2018	ABS	MGH-60 ABS system	Data Stream	
dr evo5	2000-2018	ABS	MGH-60 ABS system	Actuation	
dr evo5	2000-2018	ISU	ISU	Data Stream	
dr evo5	2000-2018	ISU	ISU	Actuation	
dr evo5	2000-2018	ICM	Siemens system	Data Stream	
dr evo5	2000-2018	ICM	Siemens system	Actuation	
dr evo5	2000-2018	ICM	Atech system	Sys. Info.	
dr evo5	2000-2018	ICM	Atech system	Read code	
dr evo5	2000-2018	ICM	Atech system	Clear code	
dr evo5	2000-2018	ICM	Atech system	Actuation	
dr evo5	2000-2018	ICM	1.8AMT ATECH system	Sys. Info.	
dr evo5	2000-2018	ICM	1.8AMT ATECH system	Read code	
dr evo5	2000-2018	ICM	1.8AMT ATECH system	Clear code	
dr evo5	2000-2018	ICM	1.8AMT ATECH system	Data Stream	
dr evo5	2000-2018	ICM	1.8AMT ATECH system	Actuation	
dr evo5	2000-2018	ICM	1.8AMT ATECH system	Special Functions	Car Maintenance
dr evo5	2000-2018	ICM	1.6 VVT CVT ATECH system	Sys. Info.	
dr evo5	2000-2018	ICM	1.6 VVT CVT ATECH system	Read code	
dr evo5	2000-2018	ICM	1.6 VVT CVT ATECH system	Clear code	

model	year	system	subitem	function	subfunction
dr evo5	2000-2018	ICM	1.6 VVT CVT ATECH system	Data Stream	
dr evo5	2000-2018	ICM	1.6 VVT CVT ATECH system	Actuation	
dr evo5	2000-2018	ICM	1.6 VVT CVT ATECH system	Special Functions	Car Maintenance
dr evo5	2000-2018	ICM	1.6 VVT CVT ATECH system	Special Functions	ECU reset
dr evo5	2000-2018	ICM	T11 1.6 RHD ICM system	Sys. Info.	
dr evo5	2000-2018	ICM	T11 1.6 RHD ICM system	Read code	
dr evo5	2000-2018	ICM	T11 1.6 RHD ICM system	Clear code	
dr evo5	2000-2018	ICM	T11 1.6 RHD ICM system	Data Stream	
dr evo5	2000-2018	ICM	T11 1.6 RHD ICM system	Actuation	
dr evo5	2000-2018	ICM	T11 1.6 RHD ICM system	Special Functions	Car Maintenance
dr evo5	2000-2018	ICM	T11 1.6 RHD ICM system	Special Functions	ECU reset
dr evo5	2000-2018	ITM	ITM	Sys. Info.	
dr evo5	2000-2018	ITM	ITM	Read code	
dr evo5	2000-2018	ITM	ITM	Clear code	
dr evo5	2000-2018	A/T	Mitsubishi system	Read code	
dr evo5	2000-2018	A/T	Mitsubishi system	Clear code	
dr evo5	2000-2018	A/T	Mitsubishi system	Data Stream	
dr evo5	2000-2018	A/T	Mitsubishi system	Actuation	
dr evo5	2000-2018	A/T	DPO system	Sys. Info.	
dr evo5	2000-2018	A/T	DPO system	Read code	
dr evo5	2000-2018	A/T	DPO system	Clear code	
dr evo5	2000-2018	A/T	DPO system	Data Stream	
dr evo5	2000-2018	A/T	DPO system	Actuation	
dr evo5	2000-2018	A/T	DPO system	Special Functions	Routine

model	year	system	subitem	function	subfunction
dr evo5	2000-2018	A/T	DPO system	Special Functions	EOBD Mode
dr evo5	2000-2018	A/T	DPO system	Special Functions	Freeze Frame
dr evo5	2000-2018	A/T	MM CFC318C system	Sys. Info.	
dr evo5	2000-2018	A/T	MM CFC318C system	Read code	
dr evo5	2000-2018	A/T	MM CFC318C system	Clear code	
dr evo5	2000-2018	A/T	MM CFC318C system	Data Stream	
dr evo5	2000-2018	A/T	MM CFC318C system	Actuation	
dr evo5	2000-2018	A/T	MM CFC318C system	Special Functions	EOL function
dr evo5	2000-2018	A/T	CVT TCU system	Read code	
dr evo5	2000-2018	A/T	CVT TCU system	Clear code	
dr evo5	2000-2018	A/T	CVT TCU system	Data Stream	
dr evo5	2000-2018	A/T	CVT TCU system	Special Functions	Read Freeze Frame Data
dr evo5	2000-2018	A/T	CVT TCU system	Special Functions	Clear adaptation of table
dr evo5	2000-2018	IMMO	IMMO	Sys. Info.	
dr evo5	2000-2018	IMMO	IMMO	Read code	
dr evo5	2000-2018	IMMO	IMMO	Clear code	
dr evo5	2000-2018	IMMO	IMMO	Data Stream	
dr evo5	2000-2018	IMMO	IMMO	Special Functions	input code
dr evo5	2000-2018	IMMO	IMMO	Special Functions	immobilizer adapt
dr evo5	2000-2018	BCm	BCM(AWA)	Read code	
dr evo5	2000-2018	BCm	BCM(AWA)	Clear code	
dr evo5	2000-2018	BCm	BCM(AWA)	Data Stream	
dr evo5	2000-2018	BCm	BCM(AWA)	Special Functions	key Teach

model	year	system	subitem	function	subfunction
dr evo5	2000-2018	BCm	BCM(AWA)	Special Functions	Auto window lifting by RKE
dr evo5	2000-2018	BCm	Atech BCM system	Sys. Info.	
dr evo5	2000-2018	BCm	Atech BCM system	Read code	
dr evo5	2000-2018	BCm	Atech BCM system	Clear code	
dr evo5	2000-2018	BCm	Atech BCM system	Data Stream	
dr evo5	2000-2018	BCm	Atech BCM system	Actuation	
dr evo5	2000-2018	BCm	Atech BCM system	Special Functions	Key Teach
dr evo5	2000-2018	BCm	Atech BCM system	Special Functions	Erase all keys
dr evo5	2000-2018	BCm	Atech BCM system	Special Functions	Reset function
dr evo5	2000-2018	APM	APM	Sys. Info.	
dr evo5	2000-2018	APM	APM	Read code	
dr evo5	2000-2018	APM	APM	Clear code	
dr evo5	2000-2018	APM	APM	Data Stream	
dr evo5	2000-2018	APM	APM	Actuation	
dr evo5	2000-2018	APM	APM	Special Functions	Special operation
dr evo5	2000-2018	RRM	RRM	Sys. Info.	
dr evo5	2000-2018	RRM	RRM	Read code	
dr evo5	2000-2018	RRM	RRM	Clear code	
dr evo5	2000-2018	RRM	RRM	Data Stream	
dr evo5	2000-2018	RRM	RRM	Actuation	
dr evo5	2000-2018	RRM	RRM	Special Functions	Special operation
dr evo5	2000-2018	ERG	ERG	Sys. Info.	
dr evo5	2000-2018	ERG	ERG	Read code	
dr evo5	2000-2018	ERG	ERG	Clear code	

model	year	system	subitem	function	subfunction
dr evo5	2000-2018	ERG	ERG	Data Stream	
dr evo5	2000-2018	ERG	ERG	Special Functions	Special operation
dr evo5	2000-2018	MFM	MFM	Sys. Info.	
dr evo5	2000-2018	MFM	MFM	Read code	
dr evo5	2000-2018	MFM	MFM	Clear code	
dr evo5	2000-2018	MFM	MFM	Data Stream	
dr evo5	2000-2018	MFM	MFM	Actuation	
dr6	2000-2018	ENG	ENG	Sys. Info.	
dr6	2000-2018	ENG	ENG	Read code	
dr6	2000-2018	ENG	ENG	Clear code	
dr6	2000-2018	ENG	ENG	Data Stream	
dr6	2000-2018	ENG	ENG	Actuation	
dr6	2000-2018	ENG	ENG	Special Functions	Routine Control service
dr6	2000-2018	ABS	ABS	Sys. Info.	
dr6	2000-2018	ABS	ABS	Read code	
dr6	2000-2018	ABS	ABS	Clear code	
dr6	2000-2018	ABS	ABS	Data Stream	
dr6	2000-2018	ABS	ABS	Special Functions	freeze frame data
dr6	2000-2018	ABS	ABS	Special Functions	Special operation
dr6	2000-2018	SRS	SRS	Sys. Info.	
dr6	2000-2018	SRS	SRS	Read code	
dr6	2000-2018	SRS	SRS	Clear code	
dr6	2000-2018	SRS	SRS	Data Stream	
dr6	2000-2018	SRS	SRS	Special Functions	Special operation
dr6	2000-2018	BCM	BCM	Sys. Info.	
dr6	2000-2018	BCM	BCM	Read code	
dr6	2000-2018	BCM	BCM	Clear code	
dr6	2000-2018	BCM	BCM	Data Stream	
dr6	2000-2018	BCM	BCM	Actuation	
dr6	2000-2018	BCM	BCM	Special Functions	Write Data
dr6	2000-2018	BCM	BCM	Special Functions	ECU reset
dr6	2000-2018	ICM	ICM	Sys. Info.	
dr6	2000-2018	ICM	ICM	Read code	
dr6	2000-2018	ICM	ICM	Clear code	
dr6	2000-2018	ICM	ICM	Data Stream	

model	year	system	subitem	function	subfunction
dr6	2000-2018	ICM	ICM	Actuation	
dr6	2000-2018	ICM	ICM	Special Functions	Special operation
dr6	2000-2018	PEPS	PEPS	Sys. Info.	
dr6	2000-2018	PEPS	PEPS	Read code	
dr6	2000-2018	PEPS	PEPS	Clear code	
dr6	2000-2018	PEPS	PEPS	Data Stream	
dr6	2000-2018	PEPS	PEPS	Special Functions	Special operation
dr6	2000-2018	IMMO	IMMO	Sys. Info.	
dr6	2000-2018	IMMO	IMMO	Read code	
dr6	2000-2018	IMMO	IMMO	Clear code	
dr6	2000-2018	IMMO	IMMO	Special Functions	Write Data
dr6	2000-2018	IMMO	IMMO	Special Functions	After sale function
dr6	2000-2018	DVD	DVD	Clear code	
dr6	2000-2018	DVD	DVD	Special Functions	Write Data
dr6	2000-2018	AT	AT	Sys. Info.	
dr6	2000-2018	AT	AT	Read code	
dr6	2000-2018	AT	AT	Clear code	
dr6	2000-2018	AT	AT	Special Functions	Read Freeze Frame Data
dr6	2000-2018	AT	AT	Special Functions	Clear adaptation of table
dr6	2000-2018	CLM	CLM	Sys. Info.	
dr6	2000-2018	CLM	CLM	Read code	
dr6	2000-2018	CLM	CLM	Clear code	
dr6	2000-2018	CLM	CLM	Data Stream	
dr6	2000-2018	SAM	SAM	Sys. Info.	
dr6	2000-2018	SAM	SAM	Read code	
dr6	2000-2018	SAM	SAM	Special Functions	Re-calibration
dr6	2000-2018	SAM	SAM	Special Functions	Initial calibration
dr6	2000-2018	EPS	EPS	Sys. Info.	
dr6	2000-2018	EPS	EPS	Read code	
dr6	2000-2018	EPS	EPS	Clear code	
dr6	2000-2018	EPS	EPS	Special Functions	Special function
dr6	2000-2018	TPMS	TPMS	Sys. Info.	
dr6	2000-2018	TPMS	TPMS	Read code	
dr6	2000-2018	TPMS	TPMS	Clear code	
dr6	2000-2018	TPMS	TPMS	Data Stream	
dr6	2000-2018	TPMS	TPMS	Special Functions	freeze frame data
dr6	2000-2018	RADAR	RADAR	Sys. Info.	

model	year	system	subitem	function	subfunction
dr6	2000-2018	RADAR	RADAR	Read code	
dr6	2000-2018	RADAR	RADAR	Clear code	
dr6	2000-2018	RADAR	RADAR	Data Stream	
dr6	2000-2018	ADB	ADB	Sys. Info.	
dr6	2000-2018	ADB	ADB	Data Stream	
dr6	2000-2018	ADB	ADB	Special Functions	SFVM-alignment calibration
dr city cross	2000-2018	ENG	UAES 473MT	Read code	
dr city cross	2000-2018	ENG	UAES 473MT	Clear code	
dr city cross	2000-2018	ENG	UAES 473MT	Data Stream	
dr city cross	2000-2018	ENG	UAES 473MT	Sys. Info.	
dr city cross	2000-2018	ENG	UAES 473MT	Actuation	
dr city cross	2000-2018	ENG	MM 473AMT	Read code	
dr city cross	2000-2018	ENG	MM 473AMT	Clear code	
dr city cross	2000-2018	ENG	MM 473AMT	Data Stream	
dr city cross	2000-2018	ENG	MM 473AMT	Sys. Info.	
dr city cross	2000-2018	ENG	MM 473AMT	Actuation	
dr city cross	2000-2018	ENG	CEMS1.0 engine system 1.5L(477F)	Read code	
dr city cross	2000-2018	ENG	CEMS1.0 engine system 1.5L(477F)	Clear code	
dr city cross	2000-2018	ENG	CEMS1.0 engine system 1.5L(477F)	Data Stream	

model	year	system	subitem	function	subfunction
dr city cross	2000-2018	ENG	CEMS1.0 engine system 1.5L(477F)	Sys. Info.	
dr city cross	2000-2018	ENG	CEMS1.0 engine system 1.5L(477F)	Special Functions	Read freeze frame
dr city cross	2000-2018	ENG	CEMS1.0 engine system 1.5L(477F)	Special Functions	Write data
dr city cross	2000-2018	ENG	CEMS1.0 engine system 1.5L(477F)	Special Functions	EOBD function
dr city cross	2000-2018	ABS	ABS	Read code	
dr city cross	2000-2018	ABS	ABS	Clear code	
dr city cross	2000-2018	ABS	ABS	Data Stream	
dr city cross	2000-2018	ABS	ABS	Sys. Info.	
dr city cross	2000-2018	ABS	ABS	Special Functions	Hydraulic unit test
dr city cross	2000-2018	ABS	ABS	Special Functions	bleeding and fill brake fluid
dr city cross	2000-2018	IMMO	IMMO	Read code	
dr city cross	2000-2018	IMMO	IMMO	Clear code	
dr city cross	2000-2018	IMMO	IMMO	Data Stream	
dr city cross	2000-2018	IMMO	IMMO	Sys. Info.	
dr city cross	2000-2018	BCM	BCM	Read code	
dr city cross	2000-2018	BCM	BCM	Clear code	

model	year	system	subitem	function	subfunction
dr city cross	2000-2018	BCM	BCM	Data Stream	
dr city cross	2000-2018	BCM	BCM	Sys. Info.	
dr city cross	2000-2018	BCM	BCM	Actuation	
dr city cross	2000-2018	BCM	BCM	Special Functions	Key teach
dr city cross	2000-2018	SRS	EASTJOY SRS	Read code	
dr city cross	2000-2018	SRS	EASTJOY SRS	Clear code	
dr city cross	2000-2018	SRS	EASTJOY SRS	Data Stream	
dr city cross	2000-2018	SRS	EASTJOY SRS	Sys. Info.	
dr city cross	2000-2018	SRS	BOSCH SRS	Read code	
dr city cross	2000-2018	SRS	BOSCH SRS	Clear code	
dr city cross	2000-2018	SRS	BOSCH SRS	Data Stream	
dr city cross	2000-2018	SRS	BOSCH SRS	Sys. Info.	
dr city cross	2000-2018	ICM	MT ICM	Read code	
dr city cross	2000-2018	ICM	MT ICM	Clear code	
dr city cross	2000-2018	ICM	MT ICM	Data Stream	
dr city cross	2000-2018	ICM	MT ICM	Sys. Info.	

model	year	system	subitem	function	subfunction
dr city cross	2000-2018	ICM	MT ICM	Actuation	
dr city cross	2000-2018	ICM	MT ICM	Special Functions	Car Maintenance
dr city cross	2000-2018	ICM	MT ICM	Special Functions	ECU Reset
dr city cross	2000-2018	ICM	AMT ICM	Read code	
dr city cross	2000-2018	ICM	AMT ICM	Clear code	
dr city cross	2000-2018	ICM	AMT ICM	Data Stream	
dr city cross	2000-2018	ICM	AMT ICM	Sys. Info.	
dr city cross	2000-2018	ICM	AMT ICM	Actuation	
dr city cross	2000-2018	ICM	AMT ICM	Special Functions	Car Maintenance
dr city cross	2000-2018	ICM	ICM	Read code	
dr city cross	2000-2018	ICM	ICM	Clear code	
dr city cross	2000-2018	ICM	ICM	Data Stream	
dr city cross	2000-2018	ICM	ICM	Sys. Info.	
dr city cross	2000-2018	ICM	ICM	Actuation	
dr city cross	2000-2018	ICM	ICM	Special Functions	Car Maintenance
dr city cross	2000-2018	ICM	ICM	Special Functions	ECU Reset

model	year	system	subitem	function	subfunction
dr city cross	2000-2018	AT	MM CFC318C AT	Read code	
dr city cross	2000-2018	AT	MM CFC318C AT	Clear code	
dr city cross	2000-2018	AT	MM CFC318C AT	Data Stream	
dr city cross	2000-2018	AT	MM CFC318C AT	Sys. Info.	
dr city cross	2000-2018	AT	MM CFC318C AT	Actuation	
dr city cross	2000-2018	AT	MM CFC318C AT	Special Functions	EOL function
dr zero	2000-2018	ENG	CEMS371	Sys. Info.	
dr zero	2000-2018	ENG	CEMS371	Read code	
dr zero	2000-2018	ENG	CEMS371	Clear code	
dr zero	2000-2018	ENG	CEMS371	Data Stream	
dr zero	2000-2018	ENG	CEMS371	Special Functions	Write Data
dr zero	2000-2018	ENG	CEMS371	Special Functions	EOBD funtion
dr zero	2000-2018	ENG	UAES engine	Sys. Info.	
dr zero	2000-2018	ENG	UAES engine	Read code	
dr zero	2000-2018	ENG	UAES engine	Clear code	
dr zero	2000-2018	ENG	UAES engine	Data Stream	
dr zero	2000-2018	ENG	UAES engine	Actuation	
dr zero	2000-2018	ENG	UAES engine	Special Functions	Special operation
dr zero	2000-2018	ENG	S15 Europe V EMS	Sys. Info.	
dr zero	2000-2018	ENG	S15 Europe V EMS	Read code	
dr zero	2000-2018	ENG	S15 Europe V EMS	Clear code	

model	year	system	subitem	function	subfunction
dr zero	2000-2018	ENG	S15 Europe V EMS	Data Stream	
dr zero	2000-2018	ENG	S15 Europe V EMS	Actuation	
dr zero	2000-2018	ENG	S15 Europe V EMS	Special Functions	Special operation
dr zero	2000-2018	ENG	MM engine system	Sys. Info.	
dr zero	2000-2018	ENG	MM engine system	Read code	
dr zero	2000-2018	ENG	MM engine system	Clear code	
dr zero	2000-2018	ENG	MM engine system	Data Stream	
dr zero	2000-2018	ENG	MM engine system	Actuation	
dr zero	2000-2018	ENG	MM engine system	Special Functions	Write VIN
dr zero	2000-2018	ENG	CEMS E2.0	Sys. Info.	
dr zero	2000-2018	ENG	CEMS E2.0	Read code	
dr zero	2000-2018	ENG	CEMS E2.0	Clear code	
dr zero	2000-2018	ENG	CEMS E2.0	Data Stream	
dr zero	2000-2018	ENG	CEMS E2.0	Actuation	
dr zero	2000-2018	ENG	CEMS E2.0	Special Functions	Request Current Powertrain Diagnostic Data
dr zero	2000-2018	ENG	CEMS E2.0	Special Functions	Request Powertrain Freeze Frame Data
dr zero	2000-2018	ABS	ABS	Sys. Info.	
dr zero	2000-2018	ABS	ABS	Read code	
dr zero	2000-2018	ABS	ABS	Clear code	
dr zero	2000-2018	ABS	ABS	Data Stream	
dr zero	2000-2018	ABS	ABS	Actuation	
dr zero	2000-2018	ABS	ABS	Special Functions	Read Freeze Frame Data

model	year	system	subitem	function	subfunction
dr zero	2000-2018	ABS	ABS	Special Functions	bleeding
dr zero	2000-2018	SRS	JINGHENG SRS	Sys. Info.	
dr zero	2000-2018	SRS	JINGHENG SRS	Read code	
dr zero	2000-2018	SRS	JINGHENG SRS	Clear code	
dr zero	2000-2018	SRS	JINGHENG SRS	Data Stream	
dr zero	2000-2018	BCM	A TECH BCM	Sys. Info.	
dr zero	2000-2018	BCM	A TECH BCM	Read code	
dr zero	2000-2018	BCM	A TECH BCM	Clear code	
dr zero	2000-2018	BCM	A TECH BCM	Special Functions	key Teach
dr zero	2000-2018	ICM	S15 ICM	Sys. Info.	
dr zero	2000-2018	ICM	S15 ICM	Read code	
dr zero	2000-2018	ICM	S15 ICM	Clear code	
dr zero	2000-2018	ICM	S15 ICM	Data Stream	
dr zero	2000-2018	ICM	S15 ICM	Actuation	
dr zero	2000-2018	ICM	S15 ICM	Special Functions	Maintenance
dr zero	2000-2018	IMMO	IMMO	Sys. Info.	
dr zero	2000-2018	IMMO	IMMO	Read code	
dr zero	2000-2018	IMMO	IMMO	Clear code	
dr zero	2000-2018	IMMO	IMMO	Data Stream	
dr zero	2000-2018	IMMO	IMMO	Special Functions	input code
dr zero	2000-2018	IMMO	IMMO	Special Functions	immobilizer adapt