

Maserati Diagnostics List(Note:For reference only)

model	year	system	subitem	function	subfunction
3200 GT	All Year	Electronic Injection	Marelli Engine Management System 3200 GT	Version Information	
3200 GT	All Year	Electronic Injection	Marelli Engine Management System 3200 GT	Read Fault Code;Clear Fault Memory	
3200 GT	All Year	Electronic Injection	Marelli Engine Management System 3200 GT	Read Data Stream	
3200 GT	All Year	Electronic Injection	Marelli Engine Management System 3200 GT	Active Test	
3200 GT	All Year	Electronic Injection	Marelli Engine Management System 3200 GT - Obd Version	Version Information	
3200 GT	All Year	Electronic Injection	Marelli Engine Management System 3200 GT - Obd Version	Read Fault Code;Clear Fault Memory	
3200 GT	All Year	Electronic Injection	Marelli Engine Management System 3200 GT - Obd Version	Read Data Stream	
3200 GT	All Year	Electronic Injection	Marelli Engine Management System 3200 GT - Obd Version	Active Test	
3200 GT	All Year	Airbags	Airbag Control Unit TRW 3200 GT	Version Information	
3200 GT	All Year	Airbags	Airbag Control Unit TRW 3200 GT	Read Fault Code;Clear Fault Memory	
3200 GT	All Year	Airbags	Airbag Control Unit TRW 3200 GT	Read Data Stream	
3200 GT	All Year	Automatic Gearbox	Automatic Gearbox BTR 3200 GT	Version Information	
3200 GT	All Year	Automatic Gearbox	Automatic Gearbox BTR 3200 GT	Read Fault Code;Clear Fault Memory	
3200 GT	All Year	Automatic Gearbox	Automatic Gearbox BTR 3200 GT	Read Data Stream	
3200 GT	All Year	Automatic Gearbox	Automatic Gearbox BTR 3200 GT - Obd version	Version Information	
3200 GT	All Year	Automatic Gearbox	Automatic Gearbox BTR 3200 GT - Obd version	Read Fault Code;Clear Fault Memory	
3200 GT	All Year	Automatic Gearbox	Automatic Gearbox BTR 3200 GT - Obd version	Read Data Stream	
Ghibli(M157)	2014-2015	Engine	Engine Control Module (ECM_V6)	Version Information	
Ghibli(M157)	2014-2015	Engine	Engine Control Module (ECM_V6)	Read Fault Code;Clear Fault Memory	
Ghibli(M157)	2014-2015	Engine	Engine Control Module (ECM_V6)	Read Data Stream	
Ghibli(M157)	2014-2015	Engine	Engine Control Module V6 Diesel (ECM_V6D)	Version Information	
Ghibli(M157)	2014-2015	Engine	Engine Control Module V6 Diesel (ECM_V6D)	Read Fault Code;Clear Fault Memory	

model	year	system	subitem	function	subfunction
GHIBLI(M157)	2014-2015	Engine	Engine Control Module V6 Diesel (ECM_V6D)	Read Data Stream	
GHIBLI(M157)	2014-2015	Braking Systems	Electrical Parking Brake (EPB)	Version Information	
GHIBLI(M157)	2014-2015	Braking Systems	Electrical Parking Brake (EPB)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Braking Systems	Electrical Parking Brake (EPB)	Read Data Stream	
GHIBLI(M157)	2014-2015	Braking Systems	Electronic Stability Control (ESC)	Version Information	
GHIBLI(M157)	2014-2015	Braking Systems	Electronic Stability Control (ESC)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Braking Systems	Electronic Stability Control (ESC)	Read Data Stream	
GHIBLI(M157)	2014-2015	Transmission	All Wheel Drive (AWD)	Version Information	
GHIBLI(M157)	2014-2015	Transmission	All Wheel Drive (AWD)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Transmission	All Wheel Drive (AWD)	Read Data Stream	
GHIBLI(M157)	2014-2015	Transmission	Transmission Control Module (TCM)	Version Information	
GHIBLI(M157)	2014-2015	Transmission	Transmission Control Module (TCM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Transmission	Transmission Control Module (TCM)	Read Data Stream	
GHIBLI(M157)	2014-2015	Gearbox	Electronic Shifter Module (ESM)	Version Information	
GHIBLI(M157)	2014-2015	Gearbox	Electronic Shifter Module (ESM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Gearbox	Electronic Shifter Module (ESM)	Read Data Stream	
GHIBLI(M157)	2014-2015	Suspensions	Active Damping Control Module (ADCM)	Version Information	
GHIBLI(M157)	2014-2015	Suspensions	Active Damping Control Module (ADCM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Suspensions	Active Damping Control Module (ADCM)	Read Data Stream	
GHIBLI(M157)	2014-2015	Heaters	Comfort Rear Seats Module(CRSM)	Version Information	
GHIBLI(M157)	2014-2015	Heaters	Comfort Rear Seats Module(CRSM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Heaters	Comfort Rear Seats Module(CRSM)	Read Data Stream	
GHIBLI(M157)	2014-2015	Heaters	Comfort Seats And Wheel Module (CSWM)	Version Information	
GHIBLI(M157)	2014-2015	Heaters	Comfort Seats And Wheel Module (CSWM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Heaters	Comfort Seats And Wheel Module (CSWM)	Read Data Stream	
GHIBLI(M157)	2014-2015	Alarm	Intrusion Transceiver Module (ITM)	Version Information	

model	year	system	subitem	function	subfunction
GHIBLI(M157)	2014-2015	Alarm	Intrusion Transceiver Module (ITM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Alarm	Intrusion Transceiver Module (ITM)	Read Data Stream	
GHIBLI(M157)	2014-2015	Dashboard	Instrument Panel Cluster (IPC)	Version Information	
GHIBLI(M157)	2014-2015	Dashboard	Instrument Panel Cluster (IPC)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Dashboard	Instrument Panel Cluster (IPC)	Read Data Stream	
GHIBLI(M157)	2014-2015	Dashboard	Instrument Panel Cluster (IPC)	Additional Functions	Write Service Information
GHIBLI(M157)	2014-2015	Security	Occupant Restraint Controller (ORC)	Version Information	
GHIBLI(M157)	2014-2015	Security	Occupant Restraint Controller (ORC)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Security	Occupant Restraint Controller (ORC)	Read Data Stream	
GHIBLI(M157)	2014-2015	Climate Control	Heating, Ventilation And Air Conditioning (HVAC)	Version Information	
GHIBLI(M157)	2014-2015	Climate Control	Heating, Ventilation And Air Conditioning (HVAC)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Climate Control	Heating, Ventilation And Air Conditioning (HVAC)	Read Data Stream	
GHIBLI(M157)	2014-2015	Climate Control	Heating, Ventilation And Air Conditioning Rear (HVACR)	Version Information	
GHIBLI(M157)	2014-2015	Climate Control	Heating, Ventilation And Air Conditioning Rear (HVACR)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Climate Control	Heating, Ventilation And Air Conditioning Rear (HVACR)	Read Data Stream	
GHIBLI(M157)	2014-2015	Telematic	Amplifier (AMP)	Version Information	
GHIBLI(M157)	2014-2015	Telematic	Amplifier (AMP)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Telematic	Amplifier (AMP)	Read Data Stream	
GHIBLI(M157)	2014-2015	Telematic	Hands Free Module (HFM)	Version Information	
GHIBLI(M157)	2014-2015	Telematic	Hands Free Module (HFM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Telematic	Hands Free Module (HFM)	Read Data Stream	
GHIBLI(M157)	2014-2015	Telematic	Integrated Center Stack (ICS)	Version Information	
GHIBLI(M157)	2014-2015	Telematic	Integrated Center Stack (ICS)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Telematic	Integrated Center Stack (ICS)	Read Data Stream	
GHIBLI(M157)	2014-2015	Telematic	Telematics Gateway (TGW)	Version Information	
GHIBLI(M157)	2014-2015	Telematic	Telematics Gateway (TGW)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Telematic	Telematics Gateway (TGW)	Read Data Stream	
GHIBLI(M157)	2014-2015	Electrical Systems	Active Noise Cancelation (ANC)	Version Information	

model	year	system	subitem	function	subfunction
GHIBLI(M157)	2014-2015	Electrical Systems	Active Noise Cancelation (ANC)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Electrical Systems	Active Noise Cancelation (ANC)	Read Data Stream	
GHIBLI(M157)	2014-2015	Electrical Systems	Adaptive Front Light System (AFLS_M157)	Version Information	
GHIBLI(M157)	2014-2015	Electrical Systems	Adaptive Front Light System (AFLS_M157)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Electrical Systems	Adaptive Front Light System (AFLS_M157)	Read Data Stream	
GHIBLI(M157)	2014-2015	Electrical Systems	Body Control Module (BCM_M157)	Version Information	
GHIBLI(M157)	2014-2015	Electrical Systems	Body Control Module (BCM_M157)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Electrical Systems	Body Control Module (BCM_M157)	Read Data Stream	
GHIBLI(M157)	2014-2015	Electrical Systems	CSG Sagem Servocontrol	Version Information	
GHIBLI(M157)	2014-2015	Electrical Systems	CSG Sagem Servocontrol	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Electrical Systems	CSG Sagem Servocontrol	Read Data Stream	
GHIBLI(M157)	2014-2015	Electrical Systems	Door Module Rear Left(DMRL)	Version Information	
GHIBLI(M157)	2014-2015	Electrical Systems	Door Module Rear Left(DMRL)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Electrical Systems	Door Module Rear Left(DMRL)	Read Data Stream	
GHIBLI(M157)	2014-2015	Electrical Systems	Door Module Rear Right(DMRR)	Version Information	
GHIBLI(M157)	2014-2015	Electrical Systems	Door Module Rear Right(DMRR)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Electrical Systems	Door Module Rear Right(DMRR)	Read Data Stream	
GHIBLI(M157)	2014-2015	Electrical Systems	Driver Door Module (DDM)	Version Information	
GHIBLI(M157)	2014-2015	Electrical Systems	Driver Door Module (DDM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Electrical Systems	Driver Door Module (DDM)	Read Data Stream	
GHIBLI(M157)	2014-2015	Electrical Systems	Memory Seat Module(MSM)	Version Information	
GHIBLI(M157)	2014-2015	Electrical Systems	Memory Seat Module(MSM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Electrical Systems	Memory Seat Module(MSM)	Read Data Stream	
GHIBLI(M157)	2014-2015	Electrical Systems	Parktronics Module (PTS)	Version Information	
GHIBLI(M157)	2014-2015	Electrical Systems	Parktronics Module (PTS)	Read Fault Code;Clear Fault Memory	

model	year	system	subitem	function	subfunction
GHIBLI(M157)	2014-2015	Electrical Systems	Parktronics Module (PTS)	Read Data Stream	
GHIBLI(M157)	2014-2015	Electrical Systems	Passenger Door Module (PDM)	Version Information	
GHIBLI(M157)	2014-2015	Electrical Systems	Passenger Door Module (PDM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Electrical Systems	Passenger Door Module (PDM)	Read Data Stream	
GHIBLI(M157)	2014-2015	Electrical Systems	Rf Hub (RFH)	Version Information	
GHIBLI(M157)	2014-2015	Electrical Systems	Rf Hub (RFH)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Electrical Systems	Rf Hub (RFH)	Read Data Stream	
GHIBLI(M157)	2014-2015	Electrical Systems	Steering Column Control Module (SCCM)	Version Information	
GHIBLI(M157)	2014-2015	Electrical Systems	Steering Column Control Module (SCCM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Electrical Systems	Steering Column Control Module (SCCM)	Read Data Stream	
GHIBLI(M157)	2014-2015	Pneumatic Systems	Tyre Pressure Monitor (TPM)	Version Information	
GHIBLI(M157)	2014-2015	Pneumatic Systems	Tyre Pressure Monitor (TPM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2014-2015	Pneumatic Systems	Tyre Pressure Monitor (TPM)	Read Data Stream	
GHIBLI(M157)	2016	Engine	Engine Control Module Diesel (ECM_V6D)	Version Information	
GHIBLI(M157)	2016	Engine	Engine Control Module Diesel (ECM_V6D)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2016	Engine	Engine Control Module Diesel (ECM_V6D)	Read Data Stream	
GHIBLI(M157)	2016	Engine	Engine Control Module V6 (ECM_V6_)	Version Information	
GHIBLI(M157)	2016	Engine	Engine Control Module V6 (ECM_V6_)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2016	Engine	Engine Control Module V6 (ECM_V6_)	Read Data Stream	
GHIBLI(M157)	2016	Braking Systems	Electrical Parking Brake (EPB)	Version Information	
GHIBLI(M157)	2016	Braking Systems	Electrical Parking Brake (EPB)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2016	Braking Systems	Electrical Parking Brake (EPB)	Read Data Stream	
GHIBLI(M157)	2016	Braking Systems	Electronic Stability Control (ESC)	Version Information	
GHIBLI(M157)	2016	Braking Systems	Electronic Stability Control (ESC)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2016	Braking Systems	Electronic Stability Control (ESC)	Read Data Stream	

model	year	system	subitem	function	subfunction
Ghibli(M157)	2016	Transmission	All Wheel Drive (AWD)	Version Information	
Ghibli(M157)	2016	Transmission	All Wheel Drive (AWD)	Read Fault Code;Clear Fault Memory	
Ghibli(M157)	2016	Transmission	All Wheel Drive (AWD)	Read Data Stream	
Ghibli(M157)	2016	Transmission	Transmission Control Module (TCM)	Version Information	
Ghibli(M157)	2016	Transmission	Transmission Control Module (TCM)	Read Fault Code;Clear Fault Memory	
Ghibli(M157)	2016	Transmission	Transmission Control Module (TCM)	Read Data Stream	
Ghibli(M157)	2016	Gearbox	Electronic Shifter Module (ESM)	Version Information	
Ghibli(M157)	2016	Gearbox	Electronic Shifter Module (ESM)	Read Fault Code;Clear Fault Memory	
Ghibli(M157)	2016	Gearbox	Electronic Shifter Module (ESM)	Read Data Stream	
Ghibli(M157)	2016	Suspensions	Active Damping Control Module (ADCM)	Version Information	
Ghibli(M157)	2016	Suspensions	Active Damping Control Module (ADCM)	Read Fault Code;Clear Fault Memory	
Ghibli(M157)	2016	Suspensions	Active Damping Control Module (ADCM)	Read Data Stream	
Ghibli(M157)	2016	Heaters	Comfort Rear Seats Module(CRSM)	Version Information	
Ghibli(M157)	2016	Heaters	Comfort Rear Seats Module(CRSM)	Read Fault Code;Clear Fault Memory	
Ghibli(M157)	2016	Heaters	Comfort Rear Seats Module(CRSM)	Read Data Stream	
Ghibli(M157)	2016	Heaters	Comfort Seats And Wheel Module (CSWM)	Version Information	
Ghibli(M157)	2016	Heaters	Comfort Seats And Wheel Module (CSWM)	Read Fault Code;Clear Fault Memory	
Ghibli(M157)	2016	Heaters	Comfort Seats And Wheel Module (CSWM)	Read Data Stream	
Ghibli(M157)	2016	Alarm	Intrusion Transceiver Module (ITM)	Version Information	
Ghibli(M157)	2016	Alarm	Intrusion Transceiver Module (ITM)	Read Fault Code;Clear Fault Memory	
Ghibli(M157)	2016	Alarm	Intrusion Transceiver Module (ITM)	Read Data Stream	
Ghibli(M157)	2016	Dashboard	Instrument Panel Cluster (IPC)	Version Information	
Ghibli(M157)	2016	Dashboard	Instrument Panel Cluster (IPC)	Read Fault Code;Clear Fault Memory	
Ghibli(M157)	2016	Dashboard	Instrument Panel Cluster (IPC)	Read Data Stream	
Ghibli(M157)	2016	Dashboard	Instrument Panel Cluster (IPC)	Additional Functions	Write Service Information
Ghibli(M157)	2016	Security	Left Blind Spot Sensor	Version Information	

model	year	system	subitem	function	subfunction
GHIBLI(M157)	2016	Security	Left Blind Spot Sensor (LBSS)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2016	Security	Right Blind Spot Sensor (RBSS)	Version Information	
GHIBLI(M157)	2016	Security	Right Blind Spot Sensor (RBSS)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2016	Security	Occupant Restraint Controller (ORC)	Version Information	
GHIBLI(M157)	2016	Security	Occupant Restraint Controller (ORC)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2016	Security	Occupant Restraint Controller (ORC)	Read Data Stream	
GHIBLI(M157)	2016	Climate Control	Heating, Ventilation And Air Conditioning (HVAC)	Version Information	
GHIBLI(M157)	2016	Climate Control	Heating, Ventilation And Air Conditioning (HVAC)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2016	Climate Control	Heating, Ventilation And Air Conditioning (HVAC)	Read Data Stream	
GHIBLI(M157)	2016	Climate Control	Heating, Ventilation And Air Conditioning Rear (HVACR)	Version Information	
GHIBLI(M157)	2016	Climate Control	Heating, Ventilation And Air Conditioning Rear (HVACR)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2016	Climate Control	Heating, Ventilation And Air Conditioning Rear (HVACR)	Read Data Stream	
GHIBLI(M157)	2016	Telematic	Amplifier (AMP)	Version Information	
GHIBLI(M157)	2016	Telematic	Amplifier (AMP)	Read Data Stream	
GHIBLI(M157)	2016	Telematic	Amplifier New Premium 9 Chn (AMP_P9)	Version Information	
GHIBLI(M157)	2016	Telematic	Amplifier New Premium 9 Chn (AMP_P9)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2016	Telematic	Amplifier New Premium 9 Chn (AMP_P9)	Read Data Stream	
GHIBLI(M157)	2016	Telematic	Hands Free Module (HFM)	Version Information	
GHIBLI(M157)	2016	Telematic	Hands Free Module (HFM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2016	Telematic	Hands Free Module (HFM)	Read Data Stream	
GHIBLI(M157)	2016	Telematic	Integrated Center Stack (ICS)	Version Information	
GHIBLI(M157)	2016	Telematic	Integrated Center Stack (ICS)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2016	Telematic	Integrated Center Stack (ICS)	Read Data Stream	
GHIBLI(M157)	2016	Telematic	Telematics Gateway (TGW)	Version Information	
GHIBLI(M157)	2016	Telematic	Telematics Gateway (TGW)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2016	Telematic	Telematics Gateway (TGW)	Read Data Stream	
GHIBLI(M157)	2016	Electrical Systems	Active Noise Cancelation (ANC)	Version Information	
GHIBLI(M157)	2016	Electrical Systems	Active Noise Cancelation (ANC)	Read Fault Code;Clear Fault Memory	

model	year	system	subitem	function	subfunction
GHIBLI(M157)	2016	Electrical Systems	Active Noise Cancelation (ANC)	Read Data Stream	
GHIBLI(M157)	2016	Electrical Systems	Adaptive Front Light System (AFLS_M157)	Version Information	
GHIBLI(M157)	2016	Electrical Systems	Adaptive Front Light System (AFLS_M157)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2016	Electrical Systems	Adaptive Front Light System (AFLS_M157)	Read Data Stream	
GHIBLI(M157)	2016	Electrical Systems	Body Control Module (BCM_M157)	Version Information	
GHIBLI(M157)	2016	Electrical Systems	Body Control Module (BCM_M157)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2016	Electrical Systems	Body Control Module (BCM_M157)	Read Data Stream	
GHIBLI(M157)	2016	Electrical Systems	CSG Sagem Servocontrol	Version Information	
GHIBLI(M157)	2016	Electrical Systems	CSG Sagem Servocontrol	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2016	Electrical Systems	CSG Sagem Servocontrol	Read Data Stream	
GHIBLI(M157)	2016	Electrical Systems	Door Module Rear Left(DMRL)	Version Information	
GHIBLI(M157)	2016	Electrical Systems	Door Module Rear Left(DMRL)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2016	Electrical Systems	Door Module Rear Left(DMRL)	Read Data Stream	
GHIBLI(M157)	2016	Electrical Systems	Door Module Rear Right(DMRR)	Version Information	
GHIBLI(M157)	2016	Electrical Systems	Door Module Rear Right(DMRR)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2016	Electrical Systems	Door Module Rear Right(DMRR)	Read Data Stream	
GHIBLI(M157)	2016	Electrical Systems	Driver Door Module (DDM)	Version Information	
GHIBLI(M157)	2016	Electrical Systems	Driver Door Module (DDM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2016	Electrical Systems	Driver Door Module (DDM)	Read Data Stream	
GHIBLI(M157)	2016	Electrical Systems	Memory Seat Module(MSM)	Version Information	
GHIBLI(M157)	2016	Electrical Systems	Memory Seat Module(MSM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2016	Electrical Systems	Memory Seat Module(MSM)	Read Data Stream	
GHIBLI(M157)	2016	Electrical Systems	Parktronics Module (PTS)	Version Information	
GHIBLI(M157)	2016	Electrical Systems	Parktronics Module (PTS)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2016	Electrical Systems	Parktronics Module (PTS)	Read Data Stream	

model	year	system	subitem	function	subfunction
GHIBLI(M157)	2016	Electrical Systems	Passenger Door Module (PDM)	Version Information	
GHIBLI(M157)	2016	Electrical Systems	Passenger Door Module (PDM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2016	Electrical Systems	Passenger Door Module (PDM)	Read Data Stream	
GHIBLI(M157)	2016	Electrical Systems	Rf Hub (RFH)	Version Information	
GHIBLI(M157)	2016	Electrical Systems	Rf Hub (RFH)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2016	Electrical Systems	Rf Hub (RFH)	Read Data Stream	
GHIBLI(M157)	2016	Electrical Systems	Power Lift Gate Module (PLGM)	Version Information	
GHIBLI(M157)	2016	Electrical Systems	Power Lift Gate Module (PLGM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2016	Electrical Systems	Power Lift Gate Module (PLGM)	Read Data Stream	
GHIBLI(M157)	2016	Electrical Systems	Steering Column Control Module (SCCM)	Version Information	
GHIBLI(M157)	2016	Electrical Systems	Steering Column Control Module (SCCM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2016	Electrical Systems	Steering Column Control Module (SCCM)	Read Data Stream	
GHIBLI(M157)	2016	Pneumatic Systems	Tyre Pressure Monitor (TPM)	Version Information	
GHIBLI(M157)	2016	Pneumatic Systems	Tyre Pressure Monitor (TPM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2016	Pneumatic Systems	Tyre Pressure Monitor (TPM)	Read Data Stream	
GHIBLI(M157)	2017	Engine	Engine Control Module (ECM_MY17)	Version Information	
GHIBLI(M157)	2017	Engine	Engine Control Module (ECM_MY17)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Engine	Engine Control Module (ECM_MY17)	Read Data Stream	
GHIBLI(M157)	2017	Engine	Engine Control Module Diesel (ECM_V6D_MY17)	Version Information	
GHIBLI(M157)	2017	Engine	Engine Control Module Diesel (ECM_V6D_MY17)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Engine	Engine Control Module Diesel (ECM_V6D_MY17)	Read Data Stream	
GHIBLI(M157)	2017	Engine	Engine Control Module V6 (ECM_V6_MY17)	Version Information	
GHIBLI(M157)	2017	Engine	Engine Control Module V6 (ECM_V6_MY17)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Engine	Engine Control Module V6 (Ecm_V6_My17)	Read Data Stream	
GHIBLI(M157)	2017	Braking Systems	Electrical Stability Control(ESC_MY17)	Version Information	

model	year	system	subitem	function	subfunction
GHIBLI(M157)	2017	Braking Systems	Electrical Stability Control (ESC_MY17)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Braking Systems	Electrical Stability Control (ESC_MY17)	Read Data Stream	
GHIBLI(M157)	2017	Transmission	All Wheel Drive (AWD)	Version Information	
GHIBLI(M157)	2017	Transmission	All Wheel Drive (AWD)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Transmission	All Wheel Drive (AWD)	Read Data Stream	
GHIBLI(M157)	2017	Transmission	Transmission Control Module(TCM_MY17)	Version Information	
GHIBLI(M157)	2017	Transmission	Transmission Control Module(TCM_MY17)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Transmission	Transmission Control Module(TCM_MY17)	Read Data Stream	
GHIBLI(M157)	2017	Gearbox	Electronic Shifter Module (ESM)	Version Information	
GHIBLI(M157)	2017	Gearbox	Electronic Shifter Module (ESM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Gearbox	Electronic Shifter Module (ESM)	Read Data Stream	
GHIBLI(M157)	2017	Suspensions	Active Damping Control Module (ADCM)	Version Information	
GHIBLI(M157)	2017	Suspensions	Active Damping Control Module (ADCM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Suspensions	Active Damping Control Module (ADCM)	Read Data Stream	
GHIBLI(M157)	2017	Heaters	Comfort Rear Seats Module (CRSM)	Version Information	
GHIBLI(M157)	2017	Heaters	Comfort Rear Seats Module (CRSM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Heaters	Comfort Rear Seats Module (CRSM)	Read Data Stream	
GHIBLI(M157)	2017	Heaters	Comfort Seats And Wheel Module (CSWM_MY17)	Version Information	
GHIBLI(M157)	2017	Heaters	Comfort Seats And Wheel Module (CSWM_MY17)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Heaters	Comfort Seats And Wheel Module (CSWM_MY17)	Read Data Stream	
GHIBLI(M157)	2017	Alarm	Intrusion Transceiver Module (ITM)	Version Information	
GHIBLI(M157)	2017	Alarm	Intrusion Transceiver Module (ITM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Alarm	Intrusion Transceiver Module (ITM)	Read Data Stream	
GHIBLI(M157)	2017	Dashboard	Instrument Panel Cluster(IPC_MY17)	Version Information	
GHIBLI(M157)	2017	Dashboard	instrument panel cluster(IPC_MY17)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Dashboard	Instrument Panel Cluster(IPC_MY17)	Read Data Stream	

model	year	system	subitem	function	subfunction
GHIBLI(M157)	2017	Dashboard	Instrument Panel Cluster(IPC_MY17)	Additional Functions	Write Service Information
GHIBLI(M157)	2017	Security	Driver Assistance System Module(DASM)	Version Information	
GHIBLI(M157)	2017	Security	Driver Assistance System Module(DASM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Security	Driver Assistance System Module(DASM)	Read Data Stream	
GHIBLI(M157)	2017	Security	Haptic Lane Feedback Module(HALF)	Version Information	
GHIBLI(M157)	2017	Security	Haptic Lane Feedback Module(HALF)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Security	Haptic Lane Feedback Module(HALF)	Read Data Stream	
GHIBLI(M157)	2017	Security	Left Blind Spot Sensor	Version Information	
GHIBLI(M157)	2017	Security	Left Blind Spot Sensor (LBSS)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Security	Occupant Restraint Controller(ORC_MY17)	Version Information	
GHIBLI(M157)	2017	Security	Occupant Restraint Controller(ORC_MY17)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Security	Occupant Restraint Controller(ORC_MY17)	Read Data Stream	
GHIBLI(M157)	2017	Security	Right Blind Spot Sensor (RBSS)	Version Information	
GHIBLI(M157)	2017	Security	Right Blind Spot Sensor (RBSS)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Climate Control	Heating, Ventilation And Air Conditioning (HVAC)	Version Information	
GHIBLI(M157)	2017	Climate Control	Heating, Ventilation And Air Conditioning (HVAC)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Climate Control	Heating, Ventilation And Air Conditioning (HVAC)	Read Data Stream	
GHIBLI(M157)	2017	Climate Control	Heating, Ventilation And Air Conditioning Rear (HVACR)	Version Information	
GHIBLI(M157)	2017	Climate Control	Heating, Ventilation And Air Conditioning Rear (HVACR)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Climate Control	Heating, Ventilation And Air Conditioning Rear (HVACR)	Read Data Stream	
GHIBLI(M157)	2017	Telematic	Amplifier High Premium 16 Chn(AMP_HP16)	Version Information	
GHIBLI(M157)	2017	Telematic	Amplifier High Premium 16 Chn(AMP_HP16)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Telematic	Amplifier High Premium 16 Chn(AMP_HP16)	Read Data Stream	
GHIBLI(M157)	2017	Telematic	Amplifier New Premium 9 Chn (AMP_P9)	Version Information	
GHIBLI(M157)	2017	Telematic	Amplifier New Premium 9 Chn (AMP_P9)	Read Fault Code;Clear Fault Memory	

model	year	system	subitem	function	subfunction
GHIBLI(M157)	2017	Telematic	Amplifier New Premium 9 Chn (AMP_P9)	Read Data Stream	
GHIBLI(M157)	2017	Telematic	Central Vision Processing Module(CVPM)	Version Information	
GHIBLI(M157)	2017	Telematic	Central Vision Processing Module(CVPM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Telematic	Central Vision Processing Module(CVPM)	Read Data Stream	
GHIBLI(M157)	2017	Telematic	Digital Television(DTV)	Version Information	
GHIBLI(M157)	2017	Telematic	Digital Television(DTV)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Telematic	Digital Television(DTV)	Read Data Stream	
GHIBLI(M157)	2017	Telematic	Entertainment	Version Information	
GHIBLI(M157)	2017	Telematic	Entertainment Module(ETM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Telematic	Entertainment	Read Data Stream	
GHIBLI(M157)	2017	Telematic	Integrated Center Stack(ICS_MY17)	Version Information	
GHIBLI(M157)	2017	Telematic	Integrated Center Stack(ICS_MY17)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Telematic	Integrated Center Stack(ICS_MY17)	Read Data Stream	
GHIBLI(M157)	2017	Telematic	Telematic Box	Version Information	
GHIBLI(M157)	2017	Telematic	Telematic Box Module(TBM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Telematic	Telematic Box	Read Data Stream	
GHIBLI(M157)	2017	Electrical Systems	Active Noise Cancelation (ANC)	Version Information	
GHIBLI(M157)	2017	Electrical Systems	Active Noise Cancelation (ANC)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Electrical Systems	Active Noise Cancelation (ANC)	Read Data Stream	
GHIBLI(M157)	2017	Electrical Systems	Adaptive Front Light System (AFLS_M157)	Version Information	
GHIBLI(M157)	2017	Electrical Systems	Adaptive Front Light System (AFLS_M157)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Electrical Systems	Adaptive Front Light System (AFLS_M157)	Read Data Stream	
GHIBLI(M157)	2017	Electrical Systems	Body Computer Module(BCM_M157_Y17)	Version Information	
GHIBLI(M157)	2017	Electrical Systems	Body Computer Module(BCM_M157_Y17)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Electrical Systems	Body Computer Module(BCM_M157_Y17)	Read Data Stream	
GHIBLI(M157)	2017	Electrical Systems	Door Module Rear Left(DMRL)	Version Information	
GHIBLI(M157)	2017	Electrical Systems	Door Module Rear Left(DMRL)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Electrical Systems	Door Module Rear Left(DMRL)	Read Data Stream	

model	year	system	subitem	function	subfunction
GHIBLI(M157)	2017	Electrical Systems	Door Module Rear Right(DMRR)	Version Information	
GHIBLI(M157)	2017	Electrical Systems	Door Module Rear Right(DMRR)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Electrical Systems	Door Module Rear Right(DMRR)	Read Data Stream	
GHIBLI(M157)	2017	Electrical Systems	Driver Door Module (DDM)	Version Information	
GHIBLI(M157)	2017	Electrical Systems	Driver Door Module (DDM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Electrical Systems	Driver Door Module (DDM)	Read Data Stream	
GHIBLI(M157)	2017	Electrical Systems	Memory Seat Module(MSM)	Version Information	
GHIBLI(M157)	2017	Electrical Systems	Memory Seat Module(MSM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Electrical Systems	Memory Seat Module(MSM)	Read Data Stream	
GHIBLI(M157)	2017	Electrical Systems	Parktronics Module (PTS)	Version Information	
GHIBLI(M157)	2017	Electrical Systems	Parktronics Module (PTS)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Electrical Systems	Parktronics Module (PTS)	Read Data Stream	
GHIBLI(M157)	2017	Electrical Systems	Passenger Door Module (PDM)	Version Information	
GHIBLI(M157)	2017	Electrical Systems	Passenger Door Module (PDM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Electrical Systems	Passenger Door Module (PDM)	Read Data Stream	
GHIBLI(M157)	2017	Electrical Systems	Power Lift Gate Module (PLGM)	Version Information	
GHIBLI(M157)	2017	Electrical Systems	Power Lift Gate Module (PLGM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Electrical Systems	Power Lift Gate Module (PLGM)	Read Data Stream	
GHIBLI(M157)	2017	Electrical Systems	Radio Frequency Hub(RFH_MY17)	Version Information	
GHIBLI(M157)	2017	Electrical Systems	Radio Frequency Hub(RFH_MY17)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Electrical Systems	Radio Frequency Hub(RFH_MY17)	Read Data Stream	
GHIBLI(M157)	2017	Electrical Systems	Steering Column Control Module (SCCM)	Version Information	
GHIBLI(M157)	2017	Electrical Systems	Steering Column Control Module (SCCM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Electrical Systems	Steering Column Control Module (SCCM)	Read Data Stream	
GHIBLI(M157)	2017	Pneumatic Systems	Tyre Pressure Monitor (TPM)	Version Information	

model	year	system	subitem	function	subfunction
GHIBLI(M157)	2017	Pneumatic Systems	Tyre Pressure Monitor (TPM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2017	Pneumatic Systems	Tyre Pressure Monitor (TPM)	Read Data Stream	
GHIBLI(M157)	2018	Engine	Engine Control Module V6 (ECM_V6_MY18)	Version Information	
GHIBLI(M157)	2018	Engine	Engine Control Module V6 (ECM_V6_MY18)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Engine	Engine Control Module V6 (ECM_V6_MY18)	Read Data Stream	
GHIBLI(M157)	2018	Engine	Engine Control Module Diesel (ECM_V6D_MY18)	Version Information	
GHIBLI(M157)	2018	Engine	Engine Control Module Diesel (ECM_V6D_MY18)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Engine	Engine Control Module Diesel (ECM_V6D_MY18)	Read Data Stream	
GHIBLI(M157)	2018	Braking Systems	Electrical Stability Control(ESC_MY18)	Version Information	
GHIBLI(M157)	2018	Braking Systems	Electrical Stability Control (ESC_MY18)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Braking Systems	Electrical Stability Control (ESC_MY18)	Read Data Stream	
GHIBLI(M157)	2018	Transmission	All Wheel Drive (AWD)	Version Information	
GHIBLI(M157)	2018	Transmission	All Wheel Drive (AWD)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Transmission	All Wheel Drive (AWD)	Read Data Stream	
GHIBLI(M157)	2018	Transmission	Transmission Control Module(TCM_MY17)	Version Information	
GHIBLI(M157)	2018	Transmission	Transmission Control Module(TCM_MY17)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Transmission	Transmission Control Module(TCM_MY17)	Read Data Stream	
GHIBLI(M157)	2018	Gearbox	Electronic Shifter Module (ESM)	Version Information	
GHIBLI(M157)	2018	Gearbox	Electronic Shifter Module (ESM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Gearbox	Electronic Shifter Module (ESM)	Read Data Stream	
GHIBLI(M157)	2018	Suspensions	Active Damping Control Module (ADCM)	Version Information	
GHIBLI(M157)	2018	Suspensions	Active Damping Control Module (ADCM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Suspensions	Active Damping Control Module (ADCM)	Read Data Stream	
GHIBLI(M157)	2018	Heaters	Comfort Seats And Wheel Module (CSWM_MY17)	Version Information	
GHIBLI(M157)	2018	Heaters	Comfort Seats And Wheel Module (CSWM_MY17)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Heaters	Comfort Seats And Wheel Module (CSWM_MY17)	Read Data Stream	

model	year	system	subitem	function	subfunction
GHIBLI(M157)	2018	Alarm	Intrusion Transceiver Module (ITM)	Version Information	
GHIBLI(M157)	2018	Alarm	Intrusion Transceiver Module (ITM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Alarm	Intrusion Transceiver Module (ITM)	Read Data Stream	
GHIBLI(M157)	2018	Dashboard	Instrument Panel Cluster(IPC_MY17)	Version Information	
GHIBLI(M157)	2018	Dashboard	Instrument panel cluster(IPC_MY17)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Dashboard	Instrument Panel Cluster(IPC_MY17)	Read Data Stream	
GHIBLI(M157)	2018	Dashboard	Instrument Panel Cluster(IPC_MY17)	Additional Functions	Write Service Information
GHIBLI(M157)	2018	Security	Driver Assistance System Module(DASM)	Version Information	
GHIBLI(M157)	2018	Security	Driver Assistance System Module(DASM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Security	Driver Assistance System Module(DASM)	Read Data Stream	
GHIBLI(M157)	2018	Security	Haptic Lane Feedback Module(HALF)	Version Information	
GHIBLI(M157)	2018	Security	Haptic Lane Feedback Module(HALF)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Security	Haptic Lane Feedback Module(HALF)	Read Data Stream	
GHIBLI(M157)	2018	Security	Left Blind Spot Sensor	Version Information	
GHIBLI(M157)	2018	Security	Left Blind Spot Sensor (LBSS)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Security	Occupant Restraint Controller(ORC_MY18)	Version Information	
GHIBLI(M157)	2018	Security	Occupant Restraint Controller(ORC_MY18)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Security	Occupant Restraint Controller(ORC_MY18)	Read Data Stream	
GHIBLI(M157)	2018	Security	Right Blind Spot Sensor (RBSS)	Version Information	
GHIBLI(M157)	2018	Security	Right Blind Spot Sensor (RBSS)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Climate Control	Heating, Ventilation And Air Conditioning (HVAC)	Version Information	
GHIBLI(M157)	2018	Climate Control	Heating, Ventilation And Air Conditioning (HVAC)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Climate Control	Heating, Ventilation And Air Conditioning (HVAC)	Read Data Stream	
GHIBLI(M157)	2018	Telematic	Amplifier High Premium 16 Chn(AMP_HP16)	Version Information	
GHIBLI(M157)	2018	Telematic	Amplifier High Premium 16 Chn(AMP_HP16)	Read Fault Code;Clear Fault Memory	

model	year	system	subitem	function	subfunction
GHIBLI(M157)	2018	Telematic	Amplifier High Premium 16 Chn(AMP_HP16)	Read Data Stream	
GHIBLI(M157)	2018	Telematic	Amplifier New Premium 9 Chn (AMP_P9)	Version Information	
GHIBLI(M157)	2018	Telematic	Amplifier New Premium 9 Chn (AMP_P9)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Telematic	Amplifier New Premium 9 Chn (AMP_P9)	Read Data Stream	
GHIBLI(M157)	2018	Telematic	Central Vision Processing Module(CVPM)	Version Information	
GHIBLI(M157)	2018	Telematic	Central Vision Processing Module(CVPM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Telematic	Central Vision Processing Module(CVPM)	Read Data Stream	
GHIBLI(M157)	2018	Telematic	Digital Television(DTV)	Version Information	
GHIBLI(M157)	2018	Telematic	Digital Television(DTV)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Telematic	Digital Television(DTV)	Read Data Stream	
GHIBLI(M157)	2018	Telematic	Entertainment	Version Information	
GHIBLI(M157)	2018	Telematic	Entertainment Module(ETM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Telematic	Entertainment	Read Data Stream	
GHIBLI(M157)	2018	Telematic	Integrated Center Stack(ICS_MY17)	Version Information	
GHIBLI(M157)	2018	Telematic	Integrated Center Stack(ICS_MY17)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Telematic	Integrated Center Stack(ICS_MY17)	Read Data Stream	
GHIBLI(M157)	2018	Telematic	Telematic Box	Version Information	
GHIBLI(M157)	2018	Telematic	Telematic Box Module(TBM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Telematic	Telematic Box	Read Data Stream	
GHIBLI(M157)	2018	Electrical Systems	Active Noise Cancelation (ANC)	Version Information	
GHIBLI(M157)	2018	Electrical Systems	Active Noise Cancelation (ANC)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Electrical Systems	Active Noise Cancelation (ANC)	Read Data Stream	
GHIBLI(M157)	2018	Electrical Systems	Adaptative Front Lighting System (AFLS_M157_MY18)	Version Information	
GHIBLI(M157)	2018	Electrical Systems	Adaptative Front Lighting System (AFLS_M157_MY18)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Electrical Systems	Adaptative Front Lighting System (AFLS_M157_MY18)	Read Data Stream	
GHIBLI(M157)	2018	Electrical Systems	Body Computer Module(BCM_MY18)	Version Information	
GHIBLI(M157)	2018	Electrical Systems	Body Computer Module(BCM_MY18)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Electrical Systems	Body Computer Module(BCM_MY18)	Read Data Stream	

model	year	system	subitem	function	subfunction
GHIBLI(M157)	2018	Electrical Systems	Door Module Rear Left(DMRL)	Version Information	
GHIBLI(M157)	2018	Electrical Systems	Door Module Rear Left(DMRL)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Electrical Systems	Door Module Rear Left(DMRL)	Read Data Stream	
GHIBLI(M157)	2018	Electrical Systems	Door Module Rear Right(DMRR)	Version Information	
GHIBLI(M157)	2018	Electrical Systems	Door Module Rear Right(DMRR)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Electrical Systems	Door Module Rear Right(DMRR)	Read Data Stream	
GHIBLI(M157)	2018	Electrical Systems	Driver Door Module (DDM)	Version Information	
GHIBLI(M157)	2018	Electrical Systems	Driver Door Module (DDM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Electrical Systems	Driver Door Module (DDM)	Read Data Stream	
GHIBLI(M157)	2018	Electrical Systems	Memory Seat Module(MSM)	Version Information	
GHIBLI(M157)	2018	Electrical Systems	Memory Seat Module(MSM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Electrical Systems	Memory Seat Module(MSM)	Read Data Stream	
GHIBLI(M157)	2018	Electrical Systems	Parktronics Module (PTS)	Version Information	
GHIBLI(M157)	2018	Electrical Systems	Parktronics Module (PTS)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Electrical Systems	Parktronics Module (PTS)	Read Data Stream	
GHIBLI(M157)	2018	Electrical Systems	Passenger Door Module (PDM)	Version Information	
GHIBLI(M157)	2018	Electrical Systems	Passenger Door Module (PDM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Electrical Systems	Passenger Door Module (PDM)	Read Data Stream	
GHIBLI(M157)	2018	Electrical Systems	Power Lift Gate Module (PLGM)	Version Information	
GHIBLI(M157)	2018	Electrical Systems	Power Lift Gate Module (PLGM)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Electrical Systems	Power Lift Gate Module (PLGM)	Read Data Stream	
GHIBLI(M157)	2018	Electrical Systems	Radio Frequency Hub(RFH_MY17)	Version Information	
GHIBLI(M157)	2018	Electrical Systems	Radio Frequency Hub(RFH_MY17)	Read Fault Code;Clear Fault Memory	
GHIBLI(M157)	2018	Electrical Systems	Radio Frequency Hub(RFH_MY17)	Read Data Stream	
GHIBLI(M157)	2018	Electrical Systems	Steering Column Control Module (SCCM)	Version Information	

model	year	system	subitem	function	subfunction
Ghibli(M157)	2018	Electrical Systems	Steering Column Control Module (SCCM)	Read Fault Code;Clear Fault Memory	
Ghibli(M157)	2018	Electrical Systems	Steering Column Control Module (SCCM)	Read Data Stream	
Ghibli(M157)	2018	Electrical Systems	Electronic Steering Power (EPS)	Version Information	
Ghibli(M157)	2018	Electrical Systems	Electronic Steering Power (EPS)	Read Fault Code;Clear Fault Memory	
Ghibli(M157)	2018	Electrical Systems	Electronic Steering Power (EPS)	Read Data Stream	
Ghibli(M157)	2018	Electrical Systems	Security Gateway (SGW)	Version Information	
Ghibli(M157)	2018	Electrical Systems	Security Gateway (SGW)	Read Fault Code;Clear Fault Memory	
Ghibli(M157)	2018	Electrical Systems	Security Gateway (SGW)	Read Data Stream	
Ghibli(M157)	2018	Pneumatic Systems	Tyre Pressure Monitor (TPM)	Version Information	
Ghibli(M157)	2018	Pneumatic Systems	Tyre Pressure Monitor (TPM)	Read Fault Code;Clear Fault Memory	
Ghibli(M157)	2018	Pneumatic Systems	Tyre Pressure Monitor (TPM)	Read Data Stream	
Gransport	All Year	Electronic Injection	Motronic Bosch Engine Management System ME 7.1.1	Version Information	
Gransport	All Year	Electronic Injection	Motronic Bosch Engine Management System ME 7.1.1	Read Fault Code;Clear Fault Memory	
Gransport	All Year	Electronic Injection	Motronic Bosch Engine Management System ME 7.1.1	Read Data Stream	
Gransport	All Year	Electronic Injection	Motronic Bosch Engine Management System ME 7.1.1	Active Test	
Gransport	All Year	Airbags	Iso Airbag Control	Version Information	
Gransport	All Year	Airbags	Iso Airbag Control	Read Fault Code;Clear Fault Memory	
Gransport	All Year	Airbags	Iso Airbag Control	Read Data Stream	
Gransport	All Year	Semi-Auto Gearbox	Semi-Auto GearBox CFC201 - First Version	Version Information	
Gransport	All Year	Semi-Auto Gearbox	Semi-Auto GearBox CFC201 - First Version	Read Fault Code;Clear Fault Memory	
Gransport	All Year	Semi-Auto Gearbox	Semi-Auto GearBox CFC201 - First Version	Read Data Stream	
Gransport	All Year	Semi-Auto Gearbox	Semi-Auto GearBox CFC201 - First Version	Additional Functions	Clutch configuration
Gransport	All Year	Semi-Auto Gearbox	Semi-Auto GearBox CFC201 - First Version	Additional Functions	PIS Adaptation
Gransport	All Year	Semi-Auto Gearbox	Semi-Auto GearBox CFC201 - First Version	Additional Functions	Clutch bleeding actuator

model	year	system	subitem	function	subfunction
Gransport	All Year	Semi-Auto Gearbox	Semi-Auto GearBox CFC201 - First Version	Additional Functions	Engagement selection bleeding
Gransport	All Year	Semi-Auto Gearbox	Semi-Auto GearBox CFC201 - Second Version	Version Information	
Gransport	All Year	Semi-Auto Gearbox	Semi-Auto GearBox CFC201 - Second Version	Read Fault Code;Clear Fault Memory	
Gransport	All Year	Semi-Auto Gearbox	Semi-Auto GearBox CFC201 - Second Version	Read Data Stream	
Gransport	All Year	Semi-Auto Gearbox	Semi-Auto GearBox CFC201 - Second Version	Additional Functions	Clutch configuration
Gransport	All Year	Semi-Auto Gearbox	Semi-Auto GearBox CFC201 - Second Version	Additional Functions	PIS Adaptation
Gransport	All Year	Semi-Auto Gearbox	Semi-Auto GearBox CFC201 - Second Version	Additional Functions	Clutch bleeding actuator
Gransport	All Year	Semi-Auto Gearbox	Semi-Auto GearBox CFC201 - Second Version	Additional Functions	Engagement selection bleeding
GT	All Year	Electronic Injection	Motronic Bosch Engine Management System ME 7.1.1	Version Information	
GT	All Year	Electronic Injection	Motronic Bosch Engine Management System ME 7.1.1	Read Fault Code;Clear Fault Memory	
GT	All Year	Electronic Injection	Motronic Bosch Engine Management System ME 7.1.1	Read Data Stream	
GT	All Year	Electronic Injection	Motronic Bosch Engine Management System ME 7.1.1	Active Test	
GT	All Year	Airbags	Iso Airbag Control	Version Information	
GT	All Year	Airbags	Iso Airbag Control	Read Fault Code;Clear Fault Memory	
GT	All Year	Airbags	Iso Airbag Control	Read Data Stream	
GT	All Year	Semi-Auto Gearbox	Semi-Auto GearBox CFC201 - First Version	Version Information	
GT	All Year	Semi-Auto Gearbox	Semi-Auto GearBox CFC201 - First Version	Read Fault Code;Clear Fault Memory	
GT	All Year	Semi-Auto Gearbox	Semi-Auto GearBox CFC201 - First Version	Read Data Stream	
GT	All Year	Semi-Auto Gearbox	Semi-Auto GearBox CFC201 - First Version	Additional Functions	Clutch configuration
GT	All Year	Semi-Auto Gearbox	Semi-Auto GearBox CFC201 - First Version	Additional Functions	PIS Adaptation
GT	All Year	Semi-Auto Gearbox	Semi-Auto GearBox CFC201 - First Version	Additional Functions	Clutch bleeding actuator
GT	All Year	Semi-Auto Gearbox	Semi-Auto GearBox CFC201 - First Version	Additional Functions	Engagement selection bleeding
GT	All Year	Semi-Auto Gearbox	Semi-Auto GearBox CFC201 - Second Version	Version Information	
GT	All Year	Semi-Auto Gearbox	Semi-Auto GearBox CFC201 - Second Version	Read Fault Code;Clear Fault Memory	

model	year	system	subitem	function	subfunction
GT	All Year	Semi-Auto Gearbox	Semi-Auto GearBox CFC201 - Second Version	Read Data Stream	
GT	All Year	Semi-Auto Gearbox	Semi-Auto GearBox CFC201 - Second Version	Additional Functions	Clutch configuration
GT	All Year	Semi-Auto Gearbox	Semi-Auto GearBox CFC201 - Second Version	Additional Functions	PIS Adaptation
GT	All Year	Semi-Auto Gearbox	Semi-Auto GearBox CFC201 - Second Version	Additional Functions	Clutch bleeding actuator
GT	All Year	Semi-Auto Gearbox	Semi-Auto GearBox CFC201 - Second Version	Additional Functions	Engagement selection bleeding
Quattroporte M139	2004-2006	Engine	NCM ME7 Engine	Version Information	
Quattroporte M139	2004-2006	Engine	NCM ME7 Engine	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2004-2006	Engine	NCM ME7 Engine	Read Data Stream	
Quattroporte M139	2004-2006	Brakes	NFR Braking System Node	Version Information	
Quattroporte M139	2004-2006	Brakes	NFR Braking System Node	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2004-2006	Brakes	NFR Braking System Node	Read Data Stream	
Quattroporte M139	2004-2006	Transmission	NCR F1 Gearbox	Version Information	
Quattroporte M139	2004-2006	Transmission	NCR F1 Gearbox	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2004-2006	Transmission	NCR F1 Gearbox	Read Data Stream	
Quattroporte M139	2004-2006	Suspensions	NCS Skyhook Suspensions	Version Information	
Quattroporte M139	2004-2006	Suspensions	NCS Skyhook Suspensions	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2004-2006	Suspensions	NCS Skyhook Suspensions	Read Data Stream	
Quattroporte M139	2004-2006	Dashboard	NQS Dashboard	Version Information	
Quattroporte M139	2004-2006	Dashboard	NQS Dashboard	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2004-2006	Dashboard	NQS Dashboard	Read Data Stream	
Quattroporte M139	2004-2006	Dashboard	NQS Dashboard	Additional Functions	Service Information Reset
Quattroporte M139	2004-2006	Security	NAB Airbag TRW Node	Version Information	
Quattroporte M139	2004-2006	Security	NAB Airbag TRW Node	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2004-2006	Security	NAB Airbag TRW Node	Read Data Stream	
Quattroporte M139	2004-2006	Climate Control	NCL Air Conditioning System	Version Information	

model	year	system	subitem	function	subfunction
Quattroporte M139	2004-2006	Climate Control	NCL Air Conditioning System	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2004-2006	Climate Control	NCL Air Conditioning System	Read Data Stream	
Quattroporte M139	2004-2006	Telematic	NIT Infotelematic Node	Version Information	
Quattroporte M139	2004-2006	Telematic	NIT Infotelematic Node	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2004-2006	Telematic	NIT Infotelematic Node	Read Data Stream	
Quattroporte M139	2004-2006	Telematic	NTV Television Receiver	Version Information	
Quattroporte M139	2004-2006	Telematic	NTV Television Receiver	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2004-2006	Telematic	NTV Television Receiver	Read Data Stream	
Quattroporte M139	2004-2006	Electrical Systems	CAF Headlamp Alignment	Version Information	
Quattroporte M139	2004-2006	Electrical Systems	CAF Headlamp Alignment	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2004-2006	Electrical Systems	CAF Headlamp Alignment	Read Data Stream	
Quattroporte M139	2004-2006	Electrical Systems	CSG Sagem Servocontrol	Version Information	
Quattroporte M139	2004-2006	Electrical Systems	CSG Sagem Servocontrol	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2004-2006	Electrical Systems	CSG Sagem Servocontrol	Read Data Stream	
Quattroporte M139	2004-2006	Electrical Systems	NAG Guide Adjust	Version Information	
Quattroporte M139	2004-2006	Electrical Systems	NAG Guide Adjust	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2004-2006	Electrical Systems	NAG Guide Adjust	Read Data Stream	
Quattroporte M139	2004-2006	Electrical Systems	NBC Body Computer	Version Information	
Quattroporte M139	2004-2006	Electrical Systems	NBC Body Computer	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2004-2006	Electrical Systems	NBC Body Computer	Read Data Stream	
Quattroporte M139	2004-2006	Electrical Systems	NIM Internal Roof Node	Version Information	
Quattroporte M139	2004-2006	Electrical Systems	NIM Internal Roof Node	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2004-2006	Electrical Systems	NIM Internal Roof Node	Read Data Stream	
Quattroporte M139	2004-2006	Electrical Systems	NPG Driver Door	Version Information	
Quattroporte M139	2004-2006	Electrical Systems	NPG Driver Door	Read Fault Code;Clear Fault Memory	

model	year	system	subitem	function	subfunction
Quattroporte M139	2004-2006	Electrical Systems	NPG Driver Door	Read Data Stream	
Quattroporte M139	2004-2006	Electrical Systems	NPP Passenger Door	Version Information	
Quattroporte M139	2004-2006	Electrical Systems	NPP Passenger Door	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2004-2006	Electrical Systems	NPP Passenger Door	Read Data Stream	
Quattroporte M139	2004-2006	Electrical Systems	NSP Parking Sensors	Version Information	
Quattroporte M139	2004-2006	Electrical Systems	NSP Parking Sensors	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2004-2006	Electrical Systems	NSP Parking Sensors	Read Data Stream	
Quattroporte M139	2004-2006	Electrical Systems	NVB Luggage Compartment Node	Version Information	
Quattroporte M139	2004-2006	Electrical Systems	NVB Luggage Compartment Node	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2004-2006	Electrical Systems	NVB Luggage Compartment Node	Read Data Stream	
Quattroporte M139	2004-2006	Pneumatic Systems	NTP Tyre Pressure Beru	Version Information	
Quattroporte M139	2004-2006	Pneumatic Systems	NTP Tyre Pressure Beru	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2004-2006	Pneumatic Systems	NTP Tyre Pressure Beru	Read Data Stream	
Quattroporte M139	2007-2009	Engine	NCM ME7 Engine	Version Information	
Quattroporte M139	2007-2009	Engine	NCM ME7 Engine	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2007-2009	Engine	NCM ME7 Engine	Read Data Stream	
Quattroporte M139	2007-2009	Engine	NCM ME9 Engine	Version Information	
Quattroporte M139	2007-2009	Engine	NCM ME9 Engine	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2007-2009	Engine	NCM ME9 Engine	Read Data Stream	
Quattroporte M139	2007-2009	Brakes	EPB Elec. Parking Brake	Version Information	
Quattroporte M139	2007-2009	Brakes	EPB Elec. Parking Brake	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2007-2009	Brakes	EPB Elec. Parking Brake	Read Data Stream	
Quattroporte M139	2007-2009	Brakes	NFR Braking System Node	Version Information	
Quattroporte M139	2007-2009	Brakes	NFR Braking System Node	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2007-2009	Brakes	NFR Braking System Node	Read Data Stream	

model	year	system	subitem	function	subfunction
Quattroporte M139	2007-2009	Transmission	NCA Automatic Gearbox Node	Version Information	
Quattroporte M139	2007-2009	Transmission	NCA Automatic Gearbox Node	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2007-2009	Transmission	NCA Automatic Gearbox Node	Read Data Stream	
Quattroporte M139	2007-2009	Transmission	NCR F1 Gearbox	Version Information	
Quattroporte M139	2007-2009	Transmission	NCR F1 Gearbox	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2007-2009	Transmission	NCR F1 Gearbox	Read Data Stream	
Quattroporte M139	2007-2009	Suspensions	NCS Skyhook Suspensions	Version Information	
Quattroporte M139	2007-2009	Suspensions	NCS Skyhook Suspensions	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2007-2009	Suspensions	NCS Skyhook Suspensions	Read Data Stream	
Quattroporte M139	2007-2009	Dashboard	NQS Dashboard	Version Information	
Quattroporte M139	2007-2009	Dashboard	NQS Dashboard	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2007-2009	Dashboard	NQS Dashboard	Read Data Stream	
Quattroporte M139	2007-2009	Dashboard	NQS Dashboard	Additional Functions	Service Information Reset
Quattroporte M139	2007-2009	Security	AWS Siemens	Version Information	
Quattroporte M139	2007-2009	Security	AWS Siemens	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2007-2009	Security	AWS Siemens	Read Data Stream	
Quattroporte M139	2007-2009	Security	NAB Airbag TRW Node	Version Information	
Quattroporte M139	2007-2009	Security	NAB Airbag TRW Node	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2007-2009	Security	NAB Airbag TRW Node	Read Data Stream	
Quattroporte M139	2007-2009	Climate Control	NCL Air Conditioning System	Version Information	
Quattroporte M139	2007-2009	Climate Control	NCL Air Conditioning System	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2007-2009	Climate Control	NCL Air Conditioning System	Read Data Stream	
Quattroporte M139	2007-2009	Telematic	NIT Infotelematic Node	Version Information	
Quattroporte M139	2007-2009	Telematic	NIT Infotelematic Node	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2007-2009	Telematic	NIT Infotelematic Node	Read Data Stream	

model	year	system	subitem	function	subfunction
Quattroporte M139	2007-2009	Telematic	NTV Television Receiver	Version Information	
Quattroporte M139	2007-2009	Telematic	NTV Television Receiver	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2007-2009	Telematic	NTV Television Receiver	Read Data Stream	
Quattroporte M139	2007-2009	Electrical Systems	CAF Headlamp Alignment	Version Information	
Quattroporte M139	2007-2009	Electrical Systems	CAF Headlamp Alignment	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2007-2009	Electrical Systems	CAF Headlamp Alignment	Read Data Stream	
Quattroporte M139	2007-2009	Electrical Systems	CSG Sagem Servocontrol	Version Information	
Quattroporte M139	2007-2009	Electrical Systems	CSG Sagem Servocontrol	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2007-2009	Electrical Systems	CSG Sagem Servocontrol	Read Data Stream	
Quattroporte M139	2007-2009	Electrical Systems	NAG Guide Adjust	Version Information	
Quattroporte M139	2007-2009	Electrical Systems	NAG Guide Adjust	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2007-2009	Electrical Systems	NAG Guide Adjust	Read Data Stream	
Quattroporte M139	2007-2009	Electrical Systems	NBC Body Computer	Version Information	
Quattroporte M139	2007-2009	Electrical Systems	NBC Body Computer	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2007-2009	Electrical Systems	NBC Body Computer	Read Data Stream	
Quattroporte M139	2007-2009	Electrical Systems	NFA Headlight Master	Version Information	
Quattroporte M139	2007-2009	Electrical Systems	NFA Headlight Master	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2007-2009	Electrical Systems	NFA Headlight Master	Read Data Stream	
Quattroporte M139	2007-2009	Electrical Systems	NFA Node Adaptative Headlight AI-Box Slave	Version Information	
Quattroporte M139	2007-2009	Electrical Systems	NFA Node Adaptative Headlight AI-Box Slave	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2007-2009	Electrical Systems	NFA Node Adaptative Headlight AI-Box Slave	Read Data Stream	
Quattroporte M139	2007-2009	Electrical Systems	NIM Internal Roof Node	Version Information	
Quattroporte M139	2007-2009	Electrical Systems	NIM Internal Roof Node	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2007-2009	Electrical Systems	NIM Internal Roof Node	Read Data Stream	
Quattroporte M139	2007-2009	Electrical Systems	NPG Driver Door	Version Information	

model	year	system	subitem	function	subfunction
Quattroporte M139	2007-2009	Electrical Systems	NPG Driver Door	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2007-2009	Electrical Systems	NPG Driver Door	Read Data Stream	
Quattroporte M139	2007-2009	Electrical Systems	NPP Passenger Door	Version Information	
Quattroporte M139	2007-2009	Electrical Systems	NPP Passenger Door	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2007-2009	Electrical Systems	NPP Passenger Door	Read Data Stream	
Quattroporte M139	2007-2009	Electrical Systems	NSP Parking Sensors	Version Information	
Quattroporte M139	2007-2009	Electrical Systems	NSP Parking Sensors	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2007-2009	Electrical Systems	NSP Parking Sensors	Read Data Stream	
Quattroporte M139	2007-2009	Electrical Systems	NVB Luggage Compartment Node	Version Information	
Quattroporte M139	2007-2009	Electrical Systems	NVB Luggage Compartment Node	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2007-2009	Electrical Systems	NVB Luggage Compartment Node	Read Data Stream	
Quattroporte M139	2007-2009	Pneumatic Systems	NTP 2.5 MY11	Version Information	
Quattroporte M139	2007-2009	Pneumatic Systems	NTP 2.5 MY11	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2007-2009	Pneumatic Systems	NTP 2.5 MY11	Read Data Stream	
Quattroporte M139	2007-2009	Pneumatic Systems	NTP Tyre Pressure Beru	Version Information	
Quattroporte M139	2007-2009	Pneumatic Systems	NTP Tyre Pressure Beru	Read Fault Code;Clear Fault Memory	
Quattroporte M139	2007-2009	Pneumatic Systems	NTP Tyre Pressure Beru	Read Data Stream	
Quattroporte M156	2014-2015	Engine	Engine Control Module (ECM_V6)	Version Information	
Quattroporte M156	2014-2015	Engine	Engine Control Module (ECM_V6)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Engine	Engine Control Module (ECM_V6)	Read Data Stream	
Quattroporte M156	2014-2015	Engine	Engine Control Module (ECM_V8)	Version Information	
Quattroporte M156	2014-2015	Engine	Engine Control Module (ECM_V8)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Engine	Engine Control Module (ECM_V8)	Read Data Stream	
Quattroporte M156	2014-2015	Engine	Engine Control Module V6 Diesel (ECM_V6D)	Version Information	
Quattroporte M156	2014-2015	Engine	Engine Control Module V6 Diesel (ECM_V6D)	Read Fault Code;Clear Fault Memory	

model	year	system	subitem	function	subfunction
Quattroporte M156	2014-2015	Engine	Engine Control Module V6 Diesel (ECM_V6D)	Read Data Stream	
Quattroporte M156	2014-2015	Braking Systems	Electrical Parking Brake (EPB)	Version Information	
Quattroporte M156	2014-2015	Braking Systems	Electrical Parking Brake (EPB)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Braking Systems	Electrical Parking Brake (EPB)	Read Data Stream	
Quattroporte M156	2014-2015	Braking Systems	Electronic Stability Control (ESC)	Version Information	
Quattroporte M156	2014-2015	Braking Systems	Electronic Stability Control (ESC)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Braking Systems	Electronic Stability Control (ESC)	Read Data Stream	
Quattroporte M156	2014-2015	Transmission	All Wheel Drive (AWD)	Version Information	
Quattroporte M156	2014-2015	Transmission	All Wheel Drive (AWD)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Transmission	All Wheel Drive (AWD)	Read Data Stream	
Quattroporte M156	2014-2015	Transmission	Transmission Control Module (TCM)	Version Information	
Quattroporte M156	2014-2015	Transmission	Transmission Control Module (TCM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Transmission	Transmission Control Module (TCM)	Read Data Stream	
Quattroporte M156	2014-2015	Gearbox	Electronic Shifter Module (ESM)	Version Information	
Quattroporte M156	2014-2015	Gearbox	Electronic Shifter Module (ESM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Gearbox	Electronic Shifter Module (ESM)	Read Data Stream	
Quattroporte M156	2014-2015	Suspensions	Active Damping Control Module (ADCM)	Version Information	
Quattroporte M156	2014-2015	Suspensions	Active Damping Control Module (ADCM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Suspensions	Active Damping Control Module (ADCM)	Read Data Stream	
Quattroporte M156	2014-2015	Heaters	Comfort Rear Seats Module(CRSM)	Version Information	
Quattroporte M156	2014-2015	Heaters	Comfort Rear Seats Module(CRSM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Heaters	Comfort Rear Seats Module(CRSM)	Read Data Stream	
Quattroporte M156	2014-2015	Heaters	Comfort Seats And Wheel Module (CSWM)	Version Information	
Quattroporte M156	2014-2015	Heaters	Comfort Seats And Wheel Module (CSWM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Heaters	Comfort Seats And Wheel Module (CSWM)	Read Data Stream	

model	year	system	subitem	function	subfunction
Quattroporte M156	2014-2015	Alarm	Intrusion Transceiver Module (ITM)	Version Information	
Quattroporte M156	2014-2015	Alarm	Intrusion Transceiver Module (ITM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Alarm	Intrusion Transceiver Module (ITM)	Read Data Stream	
Quattroporte M156	2014-2015	Dashboard	Instrument Panel Cluster (IPC)	Version Information	
Quattroporte M156	2014-2015	Dashboard	Instrument Panel Cluster (IPC)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Dashboard	Instrument Panel Cluster (IPC)	Read Data Stream	
Quattroporte M156	2014-2015	Dashboard	Instrument Panel Cluster (IPC)	Additional Functions	Write Service Information
Quattroporte M156	2014-2015	Security	Occupant Restraint Controller (ORC)	Version Information	
Quattroporte M156	2014-2015	Security	Occupant Restraint Controller (ORC)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Security	Occupant Restraint Controller (ORC)	Read Data Stream	
Quattroporte M156	2014-2015	Climate Control	Heating, Ventilation And Air Conditioning (HVAC)	Version Information	
Quattroporte M156	2014-2015	Climate Control	Heating, Ventilation And Air Conditioning (HVAC)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Climate Control	Heating, Ventilation And Air Conditioning (HVAC)	Read Data Stream	
Quattroporte M156	2014-2015	Climate Control	Heating, Ventilation And Air Conditioning Rear (HVACR)	Version Information	
Quattroporte M156	2014-2015	Climate Control	Heating, Ventilation And Air Conditioning Rear (HVACR)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Climate Control	Heating, Ventilation And Air Conditioning Rear (HVACR)	Read Data Stream	
Quattroporte M156	2014-2015	Telematic	Amplifier (AMP)	Version Information	
Quattroporte M156	2014-2015	Telematic	Amplifier (AMP)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Telematic	Amplifier (AMP)	Read Data Stream	
Quattroporte M156	2014-2015	Telematic	Hands Free Module (HFM)	Version Information	
Quattroporte M156	2014-2015	Telematic	Hands Free Module (HFM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Telematic	Hands Free Module (HFM)	Read Data Stream	
Quattroporte M156	2014-2015	Telematic	Integrated Center Stack (ICS)	Version Information	
Quattroporte M156	2014-2015	Telematic	Integrated Center Stack (ICS)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Telematic	Integrated Center Stack (ICS)	Read Data Stream	

model	year	system	subitem	function	subfunction
Quattroporte M156	2014-2015	Telematic	Telematics Gateway (TGW)	Version Information	
Quattroporte M156	2014-2015	Telematic	Telematics Gateway (TGW)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Telematic	Telematics Gateway (TGW)	Read Data Stream	
Quattroporte M156	2014-2015	Electrical Systems	Active Noise Cancelation (ANC)	Version Information	
Quattroporte M156	2014-2015	Electrical Systems	Active Noise Cancelation (ANC)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Electrical Systems	Active Noise Cancelation (ANC)	Read Data Stream	
Quattroporte M156	2014-2015	Electrical Systems	Adaptive Front Light System (AFLS)	Version Information	
Quattroporte M156	2014-2015	Electrical Systems	Adaptive Front Light System (AFLS)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Electrical Systems	Adaptive Front Light System (AFLS)	Read Data Stream	
Quattroporte M156	2014-2015	Electrical Systems	Body Control Module (BCM)	Version Information	
Quattroporte M156	2014-2015	Electrical Systems	Body Control Module (BCM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Electrical Systems	Body Control Module (BCM)	Read Data Stream	
Quattroporte M156	2014-2015	Electrical Systems	CSG Sagem Servocontrol	Version Information	
Quattroporte M156	2014-2015	Electrical Systems	CSG Sagem Servocontrol	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Electrical Systems	CSG Sagem Servocontrol	Read Data Stream	
Quattroporte M156	2014-2015	Electrical Systems	Door Module Rear Left(DMRL)	Version Information	
Quattroporte M156	2014-2015	Electrical Systems	Door Module Rear Left(DMRL)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Electrical Systems	Door Module Rear Left(DMRL)	Read Data Stream	
Quattroporte M156	2014-2015	Electrical Systems	Door Module Rear Right(DMRR)	Version Information	
Quattroporte M156	2014-2015	Electrical Systems	Door Module Rear Right(DMRR)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Electrical Systems	Door Module Rear Right(DMRR)	Read Data Stream	
Quattroporte M156	2014-2015	Electrical Systems	Driver Door Module (DDM)	Version Information	
Quattroporte M156	2014-2015	Electrical Systems	Driver Door Module (DDM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Electrical Systems	Driver Door Module (DDM)	Read Data Stream	
Quattroporte M156	2014-2015	Electrical Systems	Memory Seat Module(MSM)	Version Information	

model	year	system	subitem	function	subfunction
Quattroporte M156	2014-2015	Electrical Systems	Memory Seat Module(MSM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Electrical Systems	Memory Seat Module(MSM)	Read Data Stream	
Quattroporte M156	2014-2015	Electrical Systems	Parktronics Module (PTS)	Version Information	
Quattroporte M156	2014-2015	Electrical Systems	Parktronics Module (PTS)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Electrical Systems	Parktronics Module (PTS)	Read Data Stream	
Quattroporte M156	2014-2015	Electrical Systems	Passenger Door Module (PDM)	Version Information	
Quattroporte M156	2014-2015	Electrical Systems	Passenger Door Module (PDM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Electrical Systems	Passenger Door Module (PDM)	Read Data Stream	
Quattroporte M156	2014-2015	Electrical Systems	Rf Hub (RFH)	Version Information	
Quattroporte M156	2014-2015	Electrical Systems	Rf Hub (RFH)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Electrical Systems	Rf Hub (RFH)	Read Data Stream	
Quattroporte M156	2014-2015	Electrical Systems	Steering Column Control Module (SCCM)	Version Information	
Quattroporte M156	2014-2015	Electrical Systems	Steering Column Control Module (SCCM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Electrical Systems	Steering Column Control Module (SCCM)	Read Data Stream	
Quattroporte M156	2014-2015	Pneumatic Systems	Tyre Pressure Monitor (TPM)	Version Information	
Quattroporte M156	2014-2015	Pneumatic Systems	Tyre Pressure Monitor (TPM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2014-2015	Pneumatic Systems	Tyre Pressure Monitor (TPM)	Read Data Stream	
Quattroporte M156	2016	Engine	Engine Control Module Diesel (ECM_V6D)	Version Information	
Quattroporte M156	2016	Engine	Engine Control Module Diesel (ECM_V6D)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Engine	Engine Control Module Diesel (ECM_V6D)	Read Data Stream	
Quattroporte M156	2016	Engine	Engine Control Module V6 (ECM_V6_)	Version Information	
Quattroporte M156	2016	Engine	Engine Control Module V6 (ECM_V6_)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Engine	Engine Control Module V6 (ECM_V6_)	Read Data Stream	
Quattroporte M156	2016	Braking Systems	Electrical Parking Brake (EPB)	Version Information	
Quattroporte M156	2016	Braking Systems	Electrical Parking Brake (EPB)	Read Fault Code;Clear Fault Memory	

model	year	system	subitem	function	subfunction
Quattroporte M156	2016	Braking Systems	Electrical Parking Brake (EPB)	Read Data Stream	
Quattroporte M156	2016	Braking Systems	Electronic Stability Control (ESC)	Version Information	
Quattroporte M156	2016	Braking Systems	Electronic Stability Control (ESC)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Braking Systems	Electronic Stability Control (ESC)	Read Data Stream	
Quattroporte M156	2016	Transmission	All Wheel Drive (AWD)	Version Information	
Quattroporte M156	2016	Transmission	All Wheel Drive (AWD)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Transmission	All Wheel Drive (AWD)	Read Data Stream	
Quattroporte M156	2016	Transmission	Transmission Control Module (TCM)	Version Information	
Quattroporte M156	2016	Transmission	Transmission Control Module (TCM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Transmission	Transmission Control Module (TCM)	Read Data Stream	
Quattroporte M156	2016	Gearbox	Electronic Shifter Module (ESM)	Version Information	
Quattroporte M156	2016	Gearbox	Electronic Shifter Module (ESM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Gearbox	Electronic Shifter Module (ESM)	Read Data Stream	
Quattroporte M156	2016	Suspensions	Active Damping Control Module (ADCM)	Version Information	
Quattroporte M156	2016	Suspensions	Active Damping Control Module (ADCM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Suspensions	Active Damping Control Module (ADCM)	Read Data Stream	
Quattroporte M156	2016	Heaters	Comfort Rear Seats Module(CRSM)	Version Information	
Quattroporte M156	2016	Heaters	Comfort Rear Seats Module(CRSM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Heaters	Comfort Rear Seats Module(CRSM)	Read Data Stream	
Quattroporte M156	2016	Heaters	Comfort Seats And Wheel Module (CSWM)	Version Information	
Quattroporte M156	2016	Heaters	Comfort Seats And Wheel Module (CSWM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Heaters	Comfort Seats And Wheel Module (CSWM)	Read Data Stream	
Quattroporte M156	2016	Alarm	Intrusion Transceiver Module (ITM)	Version Information	
Quattroporte M156	2016	Alarm	Intrusion Transceiver Module (ITM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Alarm	Intrusion Transceiver Module (ITM)	Read Data Stream	

model	year	system	subitem	function	subfunction
Quattroporte M156	2016	Dashboard	Instrument Panel Cluster (IPC)	Version Information	
Quattroporte M156	2016	Dashboard	Instrument Panel Cluster (IPC)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Dashboard	Instrument Panel Cluster (IPC)	Read Data Stream	
Quattroporte M156	2016	Dashboard	Instrument Panel Cluster (IPC)	Additional Functions	Write Service Information
Quattroporte M156	2016	Security	Left Blind Spot Sensor (LBSS)	Version Information	
Quattroporte M156	2016	Security	Left Blind Spot Sensor (LBSS)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Security	Right Blind Spot Sensor (RBSS)	Version Information	
Quattroporte M156	2016	Security	Right Blind Spot Sensor (RBSS)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Security	Occupant Restraint Controller (ORC)	Version Information	
Quattroporte M156	2016	Security	Occupant Restraint Controller (ORC)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Security	Occupant Restraint Controller (ORC)	Read Data Stream	
Quattroporte M156	2016	Climate Control	Heating, Ventilation And Air Conditioning (HVAC)	Version Information	
Quattroporte M156	2016	Climate Control	Heating, Ventilation And Air Conditioning (HVAC)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Climate Control	Heating, Ventilation And Air Conditioning (HVAC)	Read Data Stream	
Quattroporte M156	2016	Climate Control	Heating, Ventilation And Air Conditioning Rear (HVACR)	Version Information	
Quattroporte M156	2016	Climate Control	Heating, Ventilation And Air Conditioning Rear (HVACR)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Climate Control	Heating, Ventilation And Air Conditioning Rear (HVACR)	Read Data Stream	
Quattroporte M156	2016	Telematic	Amplifier (AMP)	Version Information	
Quattroporte M156	2016	Telematic	Amplifier (AMP)	Read Data Stream	
Quattroporte M156	2016	Telematic	Amplifier New Premium 9 Chn (AMP_P9)	Version Information	
Quattroporte M156	2016	Telematic	Amplifier New Premium 9 Chn (AMP_P9)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Telematic	Amplifier New Premium 9 Chn (AMP_P9)	Read Data Stream	
Quattroporte M156	2016	Telematic	Hands Free Module (HFM)	Version Information	
Quattroporte M156	2016	Telematic	Hands Free Module (HFM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Telematic	Hands Free Module (HFM)	Read Data Stream	

model	year	system	subitem	function	subfunction
Quattroporte M156	2016	Telematic	Integrated Center Stack (ICS)	Version Information	
Quattroporte M156	2016	Telematic	Integrated Center Stack (ICS)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Telematic	Integrated Center Stack (ICS)	Read Data Stream	
Quattroporte M156	2016	Telematic	Telematics Gateway (TGW)	Version Information	
Quattroporte M156	2016	Telematic	Telematics Gateway (TGW)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Telematic	Telematics Gateway (TGW)	Read Data Stream	
Quattroporte M156	2016	Electrical Systems	Active Noise Cancelation (ANC)	Version Information	
Quattroporte M156	2016	Electrical Systems	Active Noise Cancelation (ANC)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Electrical Systems	Active Noise Cancelation (ANC)	Read Data Stream	
Quattroporte M156	2016	Electrical Systems	Adaptive Front Light System (AFLS)	Version Information	
Quattroporte M156	2016	Electrical Systems	Adaptive Front Light System (AFLS)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Electrical Systems	Adaptive Front Light System (AFLS)	Read Data Stream	
Quattroporte M156	2016	Electrical Systems	Body Control Module (BCM)	Version Information	
Quattroporte M156	2016	Electrical Systems	Body Control Module (BCM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Electrical Systems	Body Control Module (BCM)	Read Data Stream	
Quattroporte M156	2016	Electrical Systems	CSG Sagem Servocontrol	Version Information	
Quattroporte M156	2016	Electrical Systems	CSG Sagem Servocontrol	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Electrical Systems	CSG Sagem Servocontrol	Read Data Stream	
Quattroporte M156	2016	Electrical Systems	Door Module Rear Left(DMRL)	Version Information	
Quattroporte M156	2016	Electrical Systems	Door Module Rear Left(DMRL)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Electrical Systems	Door Module Rear Left(DMRL)	Read Data Stream	
Quattroporte M156	2016	Electrical Systems	Door Module Rear Right(DMRR)	Version Information	
Quattroporte M156	2016	Electrical Systems	Door Module Rear Right(DMRR)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Electrical Systems	Door Module Rear Right(DMRR)	Read Data Stream	
Quattroporte M156	2016	Electrical Systems	Driver Door Module (DDM)	Version Information	

model	year	system	subitem	function	subfunction
Quattroporte M156	2016	Electrical Systems	Driver Door Module (DDM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Electrical Systems	Driver Door Module (DDM)	Read Data Stream	
Quattroporte M156	2016	Electrical Systems	Memory Seat Module(MSM)	Version Information	
Quattroporte M156	2016	Electrical Systems	Memory Seat Module(MSM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Electrical Systems	Memory Seat Module(MSM)	Read Data Stream	
Quattroporte M156	2016	Electrical Systems	Parktronics Module (PTS)	Version Information	
Quattroporte M156	2016	Electrical Systems	Parktronics Module (PTS)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Electrical Systems	Parktronics Module (PTS)	Read Data Stream	
Quattroporte M156	2016	Electrical Systems	Passenger Door Module (PDM)	Version Information	
Quattroporte M156	2016	Electrical Systems	Passenger Door Module (PDM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Electrical Systems	Passenger Door Module (PDM)	Read Data Stream	
Quattroporte M156	2016	Electrical Systems	Rf Hub (RFH)	Version Information	
Quattroporte M156	2016	Electrical Systems	Rf Hub (RFH)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Electrical Systems	Rf Hub (RFH)	Read Data Stream	
Quattroporte M156	2016	Electrical Systems	Power Lift Gate Module (PLGM)	Version Information	
Quattroporte M156	2016	Electrical Systems	Power Lift Gate Module (PLGM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Electrical Systems	Power Lift Gate Module (PLGM)	Read Data Stream	
Quattroporte M156	2016	Electrical Systems	Steering Column Control Module (SCCM)	Version Information	
Quattroporte M156	2016	Electrical Systems	Steering Column Control Module (SCCM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Electrical Systems	Steering Column Control Module (SCCM)	Read Data Stream	
Quattroporte M156	2016	Pneumatic Systems	Tyre Pressure Monitor (TPM)	Version Information	
Quattroporte M156	2016	Pneumatic Systems	Tyre Pressure Monitor (TPM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2016	Pneumatic Systems	Tyre Pressure Monitor (TPM)	Read Data Stream	
Quattroporte M156	2017	Engine	Engine Control Module (ECM_MY17)	Version Information	
Quattroporte M156	2017	Engine	Engine Control Module (ECM_MY17)	Read Fault Code;Clear Fault Memory	

model	year	system	subitem	function	subfunction
Quattroporte M156	2017	Engine	Engine Control Module (ECM_MY17)	Read Data Stream	
Quattroporte M156	2017	Engine	Engine Control Module Diesel (ECM_V6D_MY17)	Version Information	
Quattroporte M156	2017	Engine	Engine Control Module Diesel (ECM_V6D_MY17)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Engine	Engine Control Module Diesel (ECM_V6D_MY17)	Read Data Stream	
Quattroporte M156	2017	Engine	Engine Control Module V6 (ECM_V6_MY17)	Version Information	
Quattroporte M156	2017	Engine	Engine Control Module V6 (ECM_V6_MY17)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Engine	Engine Control Module V6 (Ecm_V6_My17)	Read Data Stream	
Quattroporte M156	2017	Braking Systems	Electrical Stability Control(ESC_MY17)	Version Information	
Quattroporte M156	2017	Braking Systems	Electrical Stability Control (ESC_MY17)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Braking Systems	Electrical Stability Control (ESC_MY17)	Read Data Stream	
Quattroporte M156	2017	Transmission	All Wheel Drive (AWD)	Version Information	
Quattroporte M156	2017	Transmission	All Wheel Drive (AWD)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Transmission	All Wheel Drive (AWD)	Read Data Stream	
Quattroporte M156	2017	Transmission	Transmission Control Module(TCM_MY17)	Version Information	
Quattroporte M156	2017	Transmission	Transmission Control Module(TCM_MY17)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Transmission	Transmission Control Module(TCM_MY17)	Read Data Stream	
Quattroporte M156	2017	Gearbox	Electronic Shifter Module (ESM)	Version Information	
Quattroporte M156	2017	Gearbox	Electronic Shifter Module (ESM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Gearbox	Electronic Shifter Module (ESM)	Read Data Stream	
Quattroporte M156	2017	Suspensions	Active Damping Control Module (ADCM)	Version Information	
Quattroporte M156	2017	Suspensions	Active Damping Control Module (ADCM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Suspensions	Active Damping Control Module (ADCM)	Read Data Stream	
Quattroporte M156	2017	Heaters	Comfort Rear Seats Module (CRSM)	Version Information	
Quattroporte M156	2017	Heaters	Comfort Rear Seats Module (CRSM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Heaters	Comfort Rear Seats Module (CRSM)	Read Data Stream	

model	year	system	subitem	function	subfunction
Quattroporte M156	2017	Heaters	Comfort Seats And Wheel Module (CSWM_MY17)	Version Information	
Quattroporte M156	2017	Heaters	Comfort Seats And Wheel Module (CSWM_MY17)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Heaters	Comfort Seats And Wheel Module (CSWM_MY17)	Read Data Stream	
Quattroporte M156	2017	Alarm	Intrusion Transceiver Module (ITM)	Version Information	
Quattroporte M156	2017	Alarm	Intrusion Transceiver Module (ITM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Alarm	Intrusion Transceiver Module (ITM)	Read Data Stream	
Quattroporte M156	2017	Dashboard	Instrument Panel Cluster(IPC_MY17)	Version Information	
Quattroporte M156	2017	Dashboard	instrument panel cluster(IPC_MY17)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Dashboard	Instrument Panel Cluster(IPC_MY17)	Read Data Stream	
Quattroporte M156	2017	Dashboard	Instrument Panel Cluster(IPC_MY17)	Additional Functions	Write Service Information
Quattroporte M156	2017	Security	Driver Assistance System Module(DASM)	Version Information	
Quattroporte M156	2017	Security	Driver Assistance System Module(DASM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Security	Driver Assistance System Module(DASM)	Read Data Stream	
Quattroporte M156	2017	Security	Haptic Lane Feedback Module(HALF)	Version Information	
Quattroporte M156	2017	Security	Haptic Lane Feedback Module(HALF)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Security	Haptic Lane Feedback Module(HALF)	Read Data Stream	
Quattroporte M156	2017	Security	Left Blind Spot Sensor (LBSS)	Version Information	
Quattroporte M156	2017	Security	Left Blind Spot Sensor (LBSS)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Security	Occupant Restraint Controller(ORC_MY17)	Version Information	
Quattroporte M156	2017	Security	Occupant Restraint Controller(ORC_MY17)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Security	Occupant Restraint Controller(ORC_MY17)	Read Data Stream	
Quattroporte M156	2017	Security	Right Blind Spot Sensor (RBSS)	Version Information	
Quattroporte M156	2017	Security	Right Blind Spot Sensor (RBSS)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Climate Control	Heating, Ventilation And Air Conditioning (HVAC)	Version Information	
Quattroporte M156	2017	Climate Control	Heating, Ventilation And Air Conditioning (HVAC)	Read Fault Code;Clear Fault Memory	

model	year	system	subitem	function	subfunction
Quattroporte M156	2017	Climate Control	Heating, Ventilation And Air Conditioning (HVAC)	Read Data Stream	
Quattroporte M156	2017	Climate Control	Heating, Ventilation And Air Conditioning Rear (HVACR)	Version Information	
Quattroporte M156	2017	Climate Control	Heating, Ventilation And Air Conditioning Rear (HVACR)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Climate Control	Heating, Ventilation And Air Conditioning Rear (HVACR)	Read Data Stream	
Quattroporte M156	2017	Telematic	Amplifier High Premium 16 Chn(AMP_HP16)	Version Information	
Quattroporte M156	2017	Telematic	Amplifier High Premium 16 Chn(AMP_HP16)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Telematic	Amplifier High Premium 16 Chn(AMP_HP16)	Read Data Stream	
Quattroporte M156	2017	Telematic	Amplifier New Premium 9 Chn (AMP_P9)	Version Information	
Quattroporte M156	2017	Telematic	Amplifier New Premium 9 Chn (AMP_P9)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Telematic	Amplifier New Premium 9 Chn (AMP_P9)	Read Data Stream	
Quattroporte M156	2017	Telematic	Central Vision Processing Module(CVPM)	Version Information	
Quattroporte M156	2017	Telematic	Central Vision Processing Module(CVPM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Telematic	Central Vision Processing Module(CVPM)	Read Data Stream	
Quattroporte M156	2017	Telematic	Digital Television(DTV)	Version Information	
Quattroporte M156	2017	Telematic	Digital Television(DTV)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Telematic	Digital Television(DTV)	Read Data Stream	
Quattroporte M156	2017	Telematic	Entertainment Module(ETM)	Version Information	
Quattroporte M156	2017	Telematic	Entertainment Module(ETM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Telematic	Entertainment Module(ETM)	Read Data Stream	
Quattroporte M156	2017	Telematic	Integrated Center Stack(ICS_MY17)	Version Information	
Quattroporte M156	2017	Telematic	Integrated Center Stack(ICS_MY17)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Telematic	Integrated Center Stack(ICS_MY17)	Read Data Stream	
Quattroporte M156	2017	Telematic	Telematic Box Module(TBM)	Version Information	
Quattroporte M156	2017	Telematic	Telematic Box Module(TBM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Telematic	Telematic Box Module(TBM)	Read Data Stream	

model	year	system	subitem	function	subfunction
Quattroporte M156	2017	Electrical Systems	Active Noise Cancelation (ANC)	Version Information	
Quattroporte M156	2017	Electrical Systems	Active Noise Cancelation (ANC)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Electrical Systems	Active Noise Cancelation (ANC)	Read Data Stream	
Quattroporte M156	2017	Electrical Systems	Adaptive Front Light System (AFLS_MY17)	Version Information	
Quattroporte M156	2017	Electrical Systems	Adaptive Front Light System (AFLS_MY17)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Electrical Systems	Adaptive Front Light System (AFLS_MY17)	Read Data Stream	
Quattroporte M156	2017	Electrical Systems	Body Computer Module(BCM_Y17)	Version Information	
Quattroporte M156	2017	Electrical Systems	Body Computer Module(BCM_Y17)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Electrical Systems	Body Computer Module(BCM_Y17)	Read Data Stream	
Quattroporte M156	2017	Electrical Systems	Door Module Rear Left(DMRL)	Version Information	
Quattroporte M156	2017	Electrical Systems	Door Module Rear Left(DMRL)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Electrical Systems	Door Module Rear Left(DMRL)	Read Data Stream	
Quattroporte M156	2017	Electrical Systems	Door Module Rear Right(DMRR)	Version Information	
Quattroporte M156	2017	Electrical Systems	Door Module Rear Right(DMRR)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Electrical Systems	Door Module Rear Right(DMRR)	Read Data Stream	
Quattroporte M156	2017	Electrical Systems	Driver Door Module (DDM)	Version Information	
Quattroporte M156	2017	Electrical Systems	Driver Door Module (DDM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Electrical Systems	Driver Door Module (DDM)	Read Data Stream	
Quattroporte M156	2017	Electrical Systems	Memory Seat Module(MSM)	Version Information	
Quattroporte M156	2017	Electrical Systems	Memory Seat Module(MSM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Electrical Systems	Memory Seat Module(MSM)	Read Data Stream	
Quattroporte M156	2017	Electrical Systems	Parktronics Module (PTS)	Version Information	
Quattroporte M156	2017	Electrical Systems	Parktronics Module (PTS)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Electrical Systems	Parktronics Module (PTS)	Read Data Stream	
Quattroporte M156	2017	Electrical Systems	Passenger Door Module (PDM)	Version Information	

model	year	system	subitem	function	subfunction
Quattroporte M156	2017	Electrical Systems	Passenger Door Module (PDM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Electrical Systems	Passenger Door Module (PDM)	Read Data Stream	
Quattroporte M156	2017	Electrical Systems	Power Lift Gate Module (PLGM)	Version Information	
Quattroporte M156	2017	Electrical Systems	Power Lift Gate Module (PLGM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Electrical Systems	Power Lift Gate Module (PLGM)	Read Data Stream	
Quattroporte M156	2017	Electrical Systems	Radio Frequency Hub(RFH_MY17)	Version Information	
Quattroporte M156	2017	Electrical Systems	Radio Frequency Hub(RFH_MY17)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Electrical Systems	Radio Frequency Hub(RFH_MY17)	Read Data Stream	
Quattroporte M156	2017	Electrical Systems	Steering Column Control Module (SCCM)	Version Information	
Quattroporte M156	2017	Electrical Systems	Steering Column Control Module (SCCM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Electrical Systems	Steering Column Control Module (SCCM)	Read Data Stream	
Quattroporte M156	2017	Pneumatic Systems	Tyre Pressure Monitor (TPM)	Version Information	
Quattroporte M156	2017	Pneumatic Systems	Tyre Pressure Monitor (TPM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2017	Pneumatic Systems	Tyre Pressure Monitor (TPM)	Read Data Stream	
Quattroporte M156	2018	Engine	Engine Control Module (ECM_MY18)	Version Information	
Quattroporte M156	2018	Engine	Engine Control Module (ECM_MY18)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Engine	Engine Control Module (ECM_MY18)	Read Data Stream	
Quattroporte M156	2018	Engine	Engine Control Module Diesel (ECM_V6D_MY18)	Version Information	
Quattroporte M156	2018	Engine	Engine Control Module Diesel (ECM_V6D_MY18)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Engine	Engine Control Module Diesel (ECM_V6D_MY18)	Read Data Stream	
Quattroporte M156	2018	Engine	Engine Control Module V6 (ECM_V6_MY18)	Version Information	
Quattroporte M156	2018	Engine	Engine Control Module V6 (ECM_V6_MY18)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Engine	Engine Control Module V6 (Ecm_V6_MY18)	Read Data Stream	
Quattroporte M156	2018	Braking Systems	Electrical Stability Control(ESC_MY18)	Version Information	
Quattroporte M156	2018	Braking Systems	Electrical Stability Control (ESC_MY18)	Read Fault Code;Clear Fault Memory	

model	year	system	subitem	function	subfunction
Quattroporte M156	2018	Braking Systems	Electrical Stability Control (ESC_MY18)	Read Data Stream	
Quattroporte M156	2018	Transmission	All Wheel Drive (AWD)	Version Information	
Quattroporte M156	2018	Transmission	All Wheel Drive (AWD)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Transmission	All Wheel Drive (AWD)	Read Data Stream	
Quattroporte M156	2018	Transmission	Transmission Control Module(TCM_MY17)	Version Information	
Quattroporte M156	2018	Transmission	Transmission Control Module(TCM_MY17)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Transmission	Transmission Control Module(TCM_MY17)	Read Data Stream	
Quattroporte M156	2018	Gearbox	Electronic Shifter Module (ESM)	Version Information	
Quattroporte M156	2018	Gearbox	Electronic Shifter Module (ESM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Gearbox	Electronic Shifter Module (ESM)	Read Data Stream	
Quattroporte M156	2018	Suspensions	Active Damping Control Module (ADCM)	Version Information	
Quattroporte M156	2018	Suspensions	Active Damping Control Module (ADCM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Suspensions	Active Damping Control Module (ADCM)	Read Data Stream	
Quattroporte M156	2018	Heaters	Comfort Rear Seats Module (CRSM)	Version Information	
Quattroporte M156	2018	Heaters	Comfort Rear Seats Module (CRSM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Heaters	Comfort Rear Seats Module (CRSM)	Read Data Stream	
Quattroporte M156	2018	Heaters	Comfort Seats And Wheel Module (CSWM_MY17)	Version Information	
Quattroporte M156	2018	Heaters	Comfort Seats And Wheel Module (CSWM_MY17)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Heaters	Comfort Seats And Wheel Module (CSWM_MY17)	Read Data Stream	
Quattroporte M156	2018	Alarm	Intrusion Transceiver Module (ITM)	Version Information	
Quattroporte M156	2018	Alarm	Intrusion Transceiver Module (ITM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Alarm	Intrusion Transceiver Module (ITM)	Read Data Stream	
Quattroporte M156	2018	Dashboard	Instrument Panel Cluster(IPC_MY17)	Version Information	
Quattroporte M156	2018	Dashboard	instrument panel cluster(IPC_MY17)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Dashboard	Instrument Panel Cluster(IPC_MY17)	Read Data Stream	

model	year	system	subitem	function	subfunction
Quattroporte M156	2018	Dashboard	Instrument Panel Cluster(IPC_MY17)	Additional Functions	Write Service Information
Quattroporte M156	2018	Security	Driver Assistance System Module(DASM)	Version Information	
Quattroporte M156	2018	Security	Driver Assistance System Module(DASM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Security	Driver Assistance System Module(DASM)	Read Data Stream	
Quattroporte M156	2018	Security	Haptic Lane Feedback Module(HALF)	Version Information	
Quattroporte M156	2018	Security	Haptic Lane Feedback Module(HALF)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Security	Haptic Lane Feedback Module(HALF)	Read Data Stream	
Quattroporte M156	2018	Security	Left Blind Spot Sensor (LBSS)	Version Information	
Quattroporte M156	2018	Security	Left Blind Spot Sensor (LBSS)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Security	Occupant Restraint Controller(ORC_MY18)	Version Information	
Quattroporte M156	2018	Security	Occupant Restraint Controller(ORC_MY18)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Security	Occupant Restraint Controller(ORC_MY18)	Read Data Stream	
Quattroporte M156	2018	Security	Right Blind Spot Sensor (RBSS)	Version Information	
Quattroporte M156	2018	Security	Right Blind Spot Sensor (RBSS)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Climate Control	Heating, Ventilation And Air Conditioning (HVAC)	Version Information	
Quattroporte M156	2018	Climate Control	Heating, Ventilation And Air Conditioning (HVAC)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Climate Control	Heating, Ventilation And Air Conditioning (HVAC)	Read Data Stream	
Quattroporte M156	2018	Climate Control	Heating, Ventilation And Air Conditioning Rear (HVACR)	Version Information	
Quattroporte M156	2018	Climate Control	Heating, Ventilation And Air Conditioning Rear (HVACR)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Climate Control	Heating, Ventilation And Air Conditioning Rear (HVACR)	Read Data Stream	
Quattroporte M156	2018	Telematic	Amplifier High Premium 16 Chn(AMP_HP16)	Version Information	
Quattroporte M156	2018	Telematic	Amplifier High Premium 16 Chn(AMP_HP16)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Telematic	Amplifier High Premium 16 Chn(AMP_HP16)	Read Data Stream	
Quattroporte M156	2018	Telematic	Amplifier New Premium 9 Chn (AMP_P9)	Version Information	
Quattroporte M156	2018	Telematic	Amplifier New Premium 9 Chn (AMP_P9)	Read Fault Code;Clear Fault Memory	

model	year	system	subitem	function	subfunction
Quattroporte M156	2018	Telematic	Amplifier New Premium 9 Chn (AMP_P9)	Read Data Stream	
Quattroporte M156	2018	Telematic	Central Vision Processing Module(CVPM)	Version Information	
Quattroporte M156	2018	Telematic	Central Vision Processing Module(CVPM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Telematic	Central Vision Processing Module(CVPM)	Read Data Stream	
Quattroporte M156	2018	Telematic	Digital Television(DTV)	Version Information	
Quattroporte M156	2018	Telematic	Digital Television(DTV)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Telematic	Digital Television(DTV)	Read Data Stream	
Quattroporte M156	2018	Telematic	Entertainment Module(ETM)	Version Information	
Quattroporte M156	2018	Telematic	Entertainment Module(ETM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Telematic	Entertainment Module(ETM)	Read Data Stream	
Quattroporte M156	2018	Telematic	Integrated Center Stack(ICS_MY17)	Version Information	
Quattroporte M156	2018	Telematic	Integrated Center Stack(ICS_MY17)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Telematic	Integrated Center Stack(ICS_MY17)	Read Data Stream	
Quattroporte M156	2018	Telematic	Telematic Box Module(TBM)	Version Information	
Quattroporte M156	2018	Telematic	Telematic Box Module(TBM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Telematic	Telematic Box Module(TBM)	Read Data Stream	
Quattroporte M156	2018	Electrical Systems	Active Noise Cancelation (ANC)	Version Information	
Quattroporte M156	2018	Electrical Systems	Active Noise Cancelation (ANC)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Electrical Systems	Active Noise Cancelation (ANC)	Read Data Stream	
Quattroporte M156	2018	Electrical Systems	Adaptive Front Lighting System Full LED (AFLS_LED)	Version Information	
Quattroporte M156	2018	Electrical Systems	Adaptive Front Lighting System Full LED (AFLS_LED)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Electrical Systems	Adaptive Front Lighting System Full LED (AFLS_LED)	Read Data Stream	
Quattroporte M156	2018	Electrical Systems	Body Computer Module(BCM_MY18)	Version Information	
Quattroporte M156	2018	Electrical Systems	Body Computer Module(BCM_MY18)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Electrical Systems	Body Computer Module(BCM_MY18)	Read Data Stream	

model	year	system	subitem	function	subfunction
Quattroporte M156	2018	Electrical Systems	Door Module Rear Left(DMRL)	Version Information	
Quattroporte M156	2018	Electrical Systems	Door Module Rear Left(DMRL)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Electrical Systems	Door Module Rear Left(DMRL)	Read Data Stream	
Quattroporte M156	2018	Electrical Systems	Door Module Rear Right(DMRR)	Version Information	
Quattroporte M156	2018	Electrical Systems	Door Module Rear Right(DMRR)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Electrical Systems	Door Module Rear Right(DMRR)	Read Data Stream	
Quattroporte M156	2018	Electrical Systems	Driver Door Module (DDM)	Version Information	
Quattroporte M156	2018	Electrical Systems	Driver Door Module (DDM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Electrical Systems	Driver Door Module (DDM)	Read Data Stream	
Quattroporte M156	2018	Electrical Systems	Memory Seat Module(MSM)	Version Information	
Quattroporte M156	2018	Electrical Systems	Memory Seat Module(MSM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Electrical Systems	Memory Seat Module(MSM)	Read Data Stream	
Quattroporte M156	2018	Electrical Systems	Parktronics Module (PTS)	Version Information	
Quattroporte M156	2018	Electrical Systems	Parktronics Module (PTS)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Electrical Systems	Parktronics Module (PTS)	Read Data Stream	
Quattroporte M156	2018	Electrical Systems	Passenger Door Module (PDM)	Version Information	
Quattroporte M156	2018	Electrical Systems	Passenger Door Module (PDM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Electrical Systems	Passenger Door Module (PDM)	Read Data Stream	
Quattroporte M156	2018	Electrical Systems	Power Lift Gate Module (PLGM)	Version Information	
Quattroporte M156	2018	Electrical Systems	Power Lift Gate Module (PLGM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Electrical Systems	Power Lift Gate Module (PLGM)	Read Data Stream	
Quattroporte M156	2018	Electrical Systems	Radio Frequency Hub(RFH_MY17)	Version Information	
Quattroporte M156	2018	Electrical Systems	Radio Frequency Hub(RFH_MY17)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Electrical Systems	Radio Frequency Hub(RFH_MY17)	Read Data Stream	
Quattroporte M156	2018	Electrical Systems	Steering Column Control Module (SCCM)	Version Information	

model	year	system	subitem	function	subfunction
Quattroporte M156	2018	Electrical Systems	Steering Column Control Module (SCCM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Electrical Systems	Steering Column Control Module (SCCM)	Read Data Stream	
Quattroporte M156	2018	Electrical Systems	Electronic Steering Power (EPS)	Version Information	
Quattroporte M156	2018	Electrical Systems	Electronic Steering Power (EPS)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Electrical Systems	Electronic Steering Power (EPS)	Read Data Stream	
Quattroporte M156	2018	Electrical Systems	Security Gateway (SGW)	Version Information	
Quattroporte M156	2018	Electrical Systems	Security Gateway (SGW)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Electrical Systems	Security Gateway (SGW)	Read Data Stream	
Quattroporte M156	2018	Pneumatic Systems	Tyre Pressure Monitor (TPM)	Version Information	
Quattroporte M156	2018	Pneumatic Systems	Tyre Pressure Monitor (TPM)	Read Fault Code;Clear Fault Memory	
Quattroporte M156	2018	Pneumatic Systems	Tyre Pressure Monitor (TPM)	Read Data Stream	
Quattroporte MY	All Year	Electronic Injection	Motronic Bosch Engine Management System	Version Information	
Quattroporte MY	All Year	Electronic Injection	Motronic Bosch Engine Management System	Read Fault Code;Clear Fault Memory	
Quattroporte MY	All Year	Electronic Injection	Motronic Bosch Engine Management System	Read Data Stream	
Quattroporte MY	All Year	Electronic Injection	Bosch ME9 Left Engine ECU	Version Information	
Quattroporte MY	All Year	Electronic Injection	Bosch ME9 Left Engine ECU	Read Fault Code;Clear Fault Memory	
Quattroporte MY	All Year	Electronic Injection	Bosch ME9 Left Engine ECU	Read Data Stream	
Quattroporte MY	All Year	Electronic Injection	Bosch ME9 Right Engine ECU	Version Information	
Quattroporte MY	All Year	Electronic Injection	Bosch ME9 Right Engine ECU	Read Fault Code;Clear Fault Memory	
Quattroporte MY	All Year	Electronic Injection	Bosch ME9 Right Engine ECU	Read Data Stream	
Quattroporte MY	All Year	Abs/Eds	Abs Bosch Braking System	Version Information	
Quattroporte MY	All Year	Abs/Eds	Abs Bosch Braking System	Read Fault Code;Clear Fault Memory	
Quattroporte MY	All Year	Abs/Eds	Abs Bosch Braking System	Read Data Stream	
Quattroporte MY	All Year	Abs/Eds	Abs Bosch Braking System	Additional Functions	Steering angle calibration
Quattroporte MY	All Year	Abs/Eds	Abs Bosch Braking System	Additional Functions	Brake bleed rear right

model	year	system	subitem	function	subfunction
Quattroporte MY	All Year	Abs/Eds	Abs Bosch Braking System	Additional Functions	Brake bleed rear left
Quattroporte MY	All Year	Airbags	Trw Airbag System	Version Information	
Quattroporte MY	All Year	Airbags	Trw Airbag System	Read Fault Code;Clear Fault Memory	
Quattroporte MY	All Year	Airbags	Trw Airbag System	Read Data Stream	
Quattroporte MY	All Year	Airbags	Trw Airbag System	Additional Functions	Init new ecu
Quattroporte MY	All Year	Airbags	Iso Airbag System	Version Information	
Quattroporte MY	All Year	Airbags	Iso Airbag System	Read Fault Code;Clear Fault Memory	
Quattroporte MY	All Year	Airbags	Iso Airbag System	Read Data Stream	
Quattroporte MY	All Year	Body computer	Body Computer	Version Information	
Quattroporte MY	All Year	Body computer	Body Computer	Read Fault Code;Clear Fault Memory	
Quattroporte MY	All Year	Body computer	Body Computer	Read Data Stream	
Quattroporte MY	All Year	Climate Control System	Delphi Climate Control	Version Information	
Quattroporte MY	All Year	Climate Control System	Delphi Climate Control	Read Fault Code;Clear Fault Memory	
Quattroporte MY	All Year	Climate Control System	Delphi Climate Control	Read Data Stream	
Quattroporte MY	All Year	Gearbox	Semi-automatic GearBox Magneti Marelli CFC231	Version Information	
Quattroporte MY	All Year	Gearbox	Semi-automatic GearBox Magneti Marelli CFC231	Read Fault Code;Clear Fault Memory	
Quattroporte MY	All Year	Gearbox	Semi-automatic GearBox Magneti Marelli CFC231	Read Data Stream	
Quattroporte MY	All Year	Gearbox	Semi-automatic GearBox Magneti Marelli CFC231	Additional Functions	PIS Adaptation
Quattroporte MY	All Year	Gearbox	Semi-automatic GearBox Magneti Marelli CFC231	Additional Functions	Self Learning
Quattroporte MY	All Year	Gearbox	Semi-automatic GearBox Magneti Marelli CFC231	Additional Functions	Reset wear index
Quattroporte MY	All Year	Gearbox	Semi-automatic GearBox Magneti Marelli CFC231	Additional Functions	Actuators calibration
Quattroporte MY	All Year	Gearbox	Semi-automatic GearBox Magneti Marelli CFC231	Additional Functions	Clutch configuration
Quattroporte MY	All Year	Gearbox	Semi-automatic GearBox Magneti Marelli CFC231	Additional Functions	Clutch actuator bleed

model	year	system	subitem	function	subfunction
Quattroporte MY	All Year	Gearbox	Semi-automatic GearBox Magneti Marelli CFC231	Additional Functions	Actuator bleed engagement and selection
Quattroporte MY	All Year	Gearbox	Semi-automatic GearBox Magneti Marelli CFC301	Version Information	
Quattroporte MY	All Year	Gearbox	Semi-automatic GearBox Magneti Marelli CFC301	Read Fault Code;Clear Fault Memory	
Quattroporte MY	All Year	Gearbox	Semi-automatic GearBox Magneti Marelli CFC301	Read Data Stream	
Quattroporte MY	All Year	Gearbox	Semi-automatic GearBox Magneti Marelli CFC301	Additional Functions	PIS Adaptation
Quattroporte MY	All Year	Gearbox	Semi-automatic GearBox Magneti Marelli CFC301	Additional Functions	Self Learning
Quattroporte MY	All Year	Gearbox	Semi-automatic GearBox Magneti Marelli CFC301	Additional Functions	Reset wear index
Quattroporte MY	All Year	Gearbox	Semi-automatic GearBox Magneti Marelli CFC301	Additional Functions	Clutch configuration
Quattroporte MY	All Year	Gearbox	Automatic Gearbox	Version Information	
Quattroporte MY	All Year	Gearbox	Automatic Gearbox	Read Fault Code;Clear Fault Memory	
Quattroporte MY	All Year	Gearbox	Automatic Gearbox	Read Data Stream	
Quattroporte MY	All Year	Instrument Cluster	Instrument Cluster Marelli	Version Information	
Quattroporte MY	All Year	Instrument Cluster	Instrument Cluster Marelli	Read Fault Code;Clear Fault Memory	
Quattroporte MY	All Year	Instrument Cluster	Instrument Cluster Marelli	Read Data Stream	
Quattroporte MY	All Year	Instrument Cluster	Instrument Cluster Marelli	Additional Functions	Odometer Set
Quattroporte MY	All Year	Instrument Cluster	Instrument Cluster Marelli	Additional Functions	Service information reset
Quattroporte MY	All Year	Parking Sensor System	Parking Sensor System	Version Information	
Quattroporte MY	All Year	Parking Sensor System	Parking Sensor System	Read Fault Code;Clear Fault Memory	
Quattroporte MY	All Year	Parking Sensor System	Parking Sensor System	Read Data Stream	
Quattroporte MY	All Year	Parking brake	Electronic Parking Brake	Version Information	
Quattroporte MY	All Year	Parking brake	Electronic Parking Brake	Read Fault Code;Clear Fault Memory	
Quattroporte MY	All Year	Parking brake	Electronic Parking Brake	Read Data Stream	
Quattroporte MY	All Year	Parking brake	Electronic Parking Brake	Additional Functions	Parking brake recalibration

model	year	system	subitem	function	subfunction
Quattroporte MY	All Year	Parking brake	Electronic Parking Brake	Additional Functions	Garages braking procedure
Quattroporte MY	All Year	Parking brake	Electronic Parking Brake	Additional Functions	Assembly/disassembly position
Quattroporte MY	All Year	Parking brake	Electronic Parking Brake	Additional Functions	Parking brake releasing,
Quattroporte MY	All Year	Parking brake	Electronic Parking Brake	Additional Functions	Parking brake application
Quattroporte MY	All Year	Parking brake	Electronic Parking Brake	Additional Functions	Cable bedding,
Quattroporte MY	All Year	Tyre Pressure	Beru Tyre Pressure System	Version Information	
Quattroporte MY	All Year	Tyre Pressure	Beru Tyre Pressure System	Read Fault Code;Clear Fault Memory	
Quattroporte MY	All Year	Tyre Pressure	Beru Tyre Pressure System	Read Data Stream	
Quattroporte MY	All Year	Tyre Pressure System	Beru Tyre Pressure System	Additional Functions	Writing of ID sensor identifier - FL
Quattroporte MY	All Year	Tyre Pressure System	Beru Tyre Pressure System	Additional Functions	Writing of ID sensor identifier - FR
Quattroporte MY	All Year	Tyre Pressure System	Beru Tyre Pressure System	Additional Functions	Writing of ID sensor identifier - RL
Quattroporte MY	All Year	Tyre Pressure System	Beru Tyre Pressure System	Additional Functions	Writing of ID sensor identifier - RR
Quattroporte MY	All Year	Tyre Pressure System	Beru Tyre Pressure System	Additional Functions	Writing of ID sensor identifier - SW
Quattroporte MY	All Year	Tyre Pressure	Beru Tyre Pressure System	Version Information	
Quattroporte MY	All Year	Tyre Pressure	Beru Tyre Pressure System	Read Fault Code;Clear Fault Memory	
Quattroporte MY	All Year	Tyre Pressure	Beru Tyre Pressure System	Read Data Stream	
Quattroporte MY	All Year	Tyre Pressure System	Beru Tyre Pressure System	Additional Functions	Writing of ID sensor identifier - FL
Quattroporte MY	All Year	Tyre Pressure System	Beru Tyre Pressure System	Additional Functions	Writing of ID sensor identifier - FR
Quattroporte MY	All Year	Tyre Pressure System	Beru Tyre Pressure System	Additional Functions	Writing of ID sensor identifier - RL
Quattroporte MY	All Year	Tyre Pressure System	Beru Tyre Pressure System	Additional Functions	Writing of ID sensor identifier - RR

model	year	system	subitem	function	subfunction
Quattroporte MY	All Year	Tyre Pressure System	Beru Tyre Pressure System	Additional Functions	Writing of ID sensor identifier - SW
GranTurismo	As of 2017	Engine	NCM ME7 Engine	Version Information	
GranTurismo	As of 2017	Engine	NCM ME7 Engine	Read Fault Code;Clear Fault Memory	
GranTurismo	As of 2017	Engine	NCM ME7 Engine	Read Data Stream	
GranTurismo	As of 2017	Engine	NCM ME9 Engine	Version Information	
GranTurismo	As of 2017	Engine	NCM ME9 Engine	Read Fault Code;Clear Fault Memory	
GranTurismo	As of 2017	Engine	NCM ME9 Engine	Read Data Stream	
GranTurismo	As of 2017	Brakes	EPB Elec. Parking Brake	Version Information	
GranTurismo	As of 2017	Brakes	EPB Elec. Parking Brake	Read Fault Code;Clear Fault Memory	
GranTurismo	As of 2017	Brakes	EPB Elec. Parking Brake	Read Data Stream	
GranTurismo	As of 2017	Brakes	NFR Braking System Node	Version Information	
GranTurismo	As of 2017	Brakes	NFR Braking System Node	Read Fault Code;Clear Fault Memory	
GranTurismo	As of 2017	Brakes	NFR Braking System Node	Read Data Stream	
GranTurismo	As of 2017	Transmission	NCA Automatic Gearbox Node	Version Information	
GranTurismo	As of 2017	Transmission	NCA Automatic Gearbox Node	Read Fault Code;Clear Fault Memory	
GranTurismo	As of 2017	Transmission	NCA Automatic Gearbox Node	Read Data Stream	
GranTurismo	As of 2017	Transmission	NCR F1 Gearbox	Version Information	
GranTurismo	As of 2017	Transmission	NCR F1 Gearbox	Read Fault Code;Clear Fault Memory	
GranTurismo	As of 2017	Transmission	NCR F1 Gearbox	Read Data Stream	
GranTurismo	As of 2017	Suspensions	NCS Skyhook Suspensions	Version Information	
GranTurismo	As of 2017	Suspensions	NCS Skyhook Suspensions	Read Fault Code;Clear Fault Memory	
GranTurismo	As of 2017	Suspensions	NCS Skyhook Suspensions	Read Data Stream	
GranTurismo	As of 2017	Dashboard	NQS Dashboard	Version Information	
GranTurismo	As of 2017	Dashboard	NQS Dashboard	Read Fault Code;Clear Fault Memory	
GranTurismo	As of 2017	Dashboard	NQS Dashboard	Read Data Stream	
GranTurismo	As of 2017	Dashboard	NQS Dashboard	Additional Functions	Service Information Reset
GranTurismo	As of 2017	Security	AWS Siemens	Version Information	
GranTurismo	As of 2017	Security	AWS Siemens	Read Fault Code;Clear Fault Memory	
GranTurismo	As of 2017	Security	AWS Siemens	Read Data Stream	
GranTurismo	As of 2017	Security	NAB Airbag TRW Node	Version Information	
GranTurismo	As of 2017	Security	NAB Airbag TRW Node	Read Fault Code;Clear Fault Memory	
GranTurismo	As of 2017	Security	NAB Airbag TRW Node	Read Data Stream	
GranTurismo	As of 2017	Climate Control	NCL Air Conditioning System	Version Information	

model	year	system	subitem	function	subfunction
GranTurismo	As of 2017	Climate Control	NCL Air Conditioning System	Read Fault Code;Clear Fault Memory	
GranTurismo	As of 2017	Climate Control	NCL Air Conditioning System	Read Data Stream	
GranTurismo	As of 2017	Telematic	NIT Infotelematic Node	Version Information	
GranTurismo	As of 2017	Telematic	NIT Infotelematic Node	Read Fault Code;Clear Fault Memory	
GranTurismo	As of 2017	Telematic	NIT Infotelematic Node	Read Data Stream	
GranTurismo	As of 2017	Electrical Systems	CSG Sagem Servocontrol	Version Information	
GranTurismo	As of 2017	Electrical Systems	CSG Sagem Servocontrol	Read Fault Code;Clear Fault Memory	
GranTurismo	As of 2017	Electrical Systems	CSG Sagem Servocontrol	Read Data Stream	
GranTurismo	As of 2017	Electrical Systems	NAG Guide Adjust	Version Information	
GranTurismo	As of 2017	Electrical Systems	NAG Guide Adjust	Read Fault Code;Clear Fault Memory	
GranTurismo	As of 2017	Electrical Systems	NAG Guide Adjust	Read Data Stream	
GranTurismo	As of 2017	Electrical Systems	NBC Body Computer	Version Information	
GranTurismo	As of 2017	Electrical Systems	NBC Body Computer	Read Fault Code;Clear Fault Memory	
GranTurismo	As of 2017	Electrical Systems	NBC Body Computer	Read Data Stream	
GranTurismo	As of 2017	Electrical Systems	NCP Roof	Version Information	
GranTurismo	As of 2017	Electrical Systems	NCP Roof	Read Fault Code;Clear Fault Memory	
GranTurismo	As of 2017	Electrical Systems	NCP Roof	Read Data Stream	
GranTurismo	As of 2017	Electrical Systems	NFA Headlight Master	Version Information	
GranTurismo	As of 2017	Electrical Systems	NFA Headlight Master	Read Fault Code;Clear Fault Memory	
GranTurismo	As of 2017	Electrical Systems	NFA Headlight Master	Read Data Stream	
GranTurismo	As of 2017	Electrical Systems	NFA Node Adaptative Headlight AI-Box Slave	Version Information	
GranTurismo	As of 2017	Electrical Systems	NFA Node Adaptative Headlight AI-Box Slave	Read Fault Code;Clear Fault Memory	
GranTurismo	As of 2017	Electrical Systems	NFA Node Adaptative Headlight AI-Box Slave	Read Data Stream	
GranTurismo	As of 2017	Electrical Systems	NIM Internal Roof Node	Version Information	
GranTurismo	As of 2017	Electrical Systems	NIM Internal Roof Node	Read Fault Code;Clear Fault Memory	
GranTurismo	As of 2017	Electrical Systems	NIM Internal Roof Node	Read Data Stream	

model	year	system	subitem	function	subfunction
GranTurismo	As of 2017	Electrical Systems	NPG Driver Door	Version Information	
GranTurismo	As of 2017	Electrical Systems	NPG Driver Door	Read Fault Code;Clear Fault Memory	
GranTurismo	As of 2017	Electrical Systems	NPG Driver Door	Read Data Stream	
GranTurismo	As of 2017	Electrical Systems	NPP Passenger Door	Version Information	
GranTurismo	As of 2017	Electrical Systems	NPP Passenger Door	Read Fault Code;Clear Fault Memory	
GranTurismo	As of 2017	Electrical Systems	NPP Passenger Door	Read Data Stream	
GranTurismo	As of 2017	Electrical Systems	NSP Parking Sensors	Version Information	
GranTurismo	As of 2017	Electrical Systems	NSP Parking Sensors	Read Fault Code;Clear Fault Memory	
GranTurismo	As of 2017	Electrical Systems	NSP Parking Sensors	Read Data Stream	
GranTurismo	As of 2017	Pneumatic Systems	NTP 2.5 MY11	Version Information	
GranTurismo	As of 2017	Pneumatic Systems	NTP 2.5 MY11	Read Fault Code;Clear Fault Memory	
GranTurismo	As of 2017	Pneumatic Systems	NTP 2.5 MY11	Read Data Stream	
GranTurismo	As of 2017	Pneumatic Systems	NTP Tyre Pressure Beru	Version Information	
GranTurismo	As of 2017	Pneumatic Systems	NTP Tyre Pressure Beru	Read Fault Code;Clear Fault Memory	
GranTurismo	As of 2017	Pneumatic Systems	NTP Tyre Pressure Beru	Read Data Stream	
GranTurismo	2018	Engine	NCM ME9 Engine	Version Information	
GranTurismo	2018	Engine	NCM ME9 Engine	Read Fault Code;Clear Fault Memory	
GranTurismo	2018	Engine	NCM ME9 Engine	Read Data Stream	
GranTurismo	2018	Brakes	EPB Elec. Parking Brake	Version Information	
GranTurismo	2018	Brakes	EPB Elec. Parking Brake	Read Fault Code;Clear Fault Memory	
GranTurismo	2018	Brakes	EPB Elec. Parking Brake	Read Data Stream	
GranTurismo	2018	Brakes	NFR Braking System Node	Version Information	
GranTurismo	2018	Brakes	NFR Braking System Node	Read Fault Code;Clear Fault Memory	
GranTurismo	2018	Brakes	NFR Braking System Node	Read Data Stream	
GranTurismo	2018	Transmission	NCA Automatic Gearbox Node	Version Information	
GranTurismo	2018	Transmission	NCA Automatic Gearbox Node	Read Fault Code;Clear Fault Memory	
GranTurismo	2018	Transmission	NCA Automatic Gearbox Node	Read Data Stream	
GranTurismo	2018	Suspensions	NCS Skyhook Suspensions	Version Information	

model	year	system	subitem	function	subfunction
GranTurismo	2018	Suspensions	NCS Skyhook Suspensions	Read Fault Code;Clear Fault Memory	
GranTurismo	2018	Suspensions	NCS Skyhook Suspensions	Read Data Stream	
GranTurismo	2018	Dashboard	NQS Dashboard	Version Information	
GranTurismo	2018	Dashboard	NQS Dashboard	Read Fault Code;Clear Fault Memory	
GranTurismo	2018	Dashboard	NQS Dashboard	Read Data Stream	
GranTurismo	2018	Dashboard	NQS Dashboard	Additional Functions	Service Information Reset
GranTurismo	2018	Security	NAB Airbag TRW Node	Version Information	
GranTurismo	2018	Security	NAB Airbag TRW Node	Read Fault Code;Clear Fault Memory	
GranTurismo	2018	Security	NAB Airbag TRW Node	Read Data Stream	
GranTurismo	2018	Climate Control	NCL Air Conditioning System	Version Information	
GranTurismo	2018	Climate Control	NCL Air Conditioning System	Read Fault Code;Clear Fault Memory	
GranTurismo	2018	Climate Control	NCL Air Conditioning System	Read Data Stream	
GranTurismo	2018	Telematic	Amplifier New Premium 9 Chn (AMP_P9)	Version Information	
GranTurismo	2018	Telematic	Amplifier New Premium 9 Chn (AMP_P9)	Read Fault Code;Clear Fault Memory	
GranTurismo	2018	Telematic	Amplifier New Premium 9 Chn (AMP_P9)	Read Data Stream	
GranTurismo	2018	Telematic	Entertainment	Version Information	
GranTurismo	2018	Telematic	Entertainment Module(ETM)	Read Fault Code;Clear Fault Memory	
GranTurismo	2018	Telematic	Entertainment	Read Data Stream	
GranTurismo	2018	Electrical Systems	CSG Sagem Servocontrol	Version Information	
GranTurismo	2018	Electrical Systems	CSG Sagem Servocontrol	Read Fault Code;Clear Fault Memory	
GranTurismo	2018	Electrical Systems	CSG Sagem Servocontrol	Read Data Stream	
GranTurismo	2018	Electrical Systems	NAG Guide Adjust	Version Information	
GranTurismo	2018	Electrical Systems	NAG Guide Adjust	Read Fault Code;Clear Fault Memory	
GranTurismo	2018	Electrical Systems	NAG Guide Adjust	Read Data Stream	
GranTurismo	2018	Electrical Systems	NBC Body Computer	Version Information	
GranTurismo	2018	Electrical Systems	NBC Body Computer	Read Fault Code;Clear Fault Memory	
GranTurismo	2018	Electrical Systems	NBC Body Computer	Read Data Stream	
GranTurismo	2018	Electrical Systems	NCP Roof	Version Information	

model	year	system	subitem	function	subfunction
GranTurismo	2018	Electrical Systems	NCP Roof	Read Fault Code;Clear Fault Memory	
GranTurismo	2018	Electrical Systems	NCP Roof	Read Data Stream	
GranTurismo	2018	Electrical Systems	NFA Headlight Master	Version Information	
GranTurismo	2018	Electrical Systems	NFA Headlight Master	Read Fault Code;Clear Fault Memory	
GranTurismo	2018	Electrical Systems	NFA Headlight Master	Read Data Stream	
GranTurismo	2018	Electrical Systems	NFA Node Adaptative Headlight AI-Box Slave	Version Information	
GranTurismo	2018	Electrical Systems	NFA Node Adaptative Headlight AI-Box Slave	Read Fault Code;Clear Fault Memory	
GranTurismo	2018	Electrical Systems	NFA Node Adaptative Headlight AI-Box Slave	Read Data Stream	
GranTurismo	2018	Electrical Systems	NIM Internal Roof Node	Version Information	
GranTurismo	2018	Electrical Systems	NIM Internal Roof Node	Read Fault Code;Clear Fault Memory	
GranTurismo	2018	Electrical Systems	NIM Internal Roof Node	Read Data Stream	
GranTurismo	2018	Electrical Systems	NPG Driver Door	Version Information	
GranTurismo	2018	Electrical Systems	NPG Driver Door	Read Fault Code;Clear Fault Memory	
GranTurismo	2018	Electrical Systems	NPG Driver Door	Read Data Stream	
GranTurismo	2018	Electrical Systems	NPP Passenger Door	Version Information	
GranTurismo	2018	Electrical Systems	NPP Passenger Door	Read Fault Code;Clear Fault Memory	
GranTurismo	2018	Electrical Systems	NPP Passenger Door	Read Data Stream	
GranTurismo	2018	Electrical Systems	NSP Parking Sensors	Version Information	
GranTurismo	2018	Electrical Systems	NSP Parking Sensors	Read Fault Code;Clear Fault Memory	
GranTurismo	2018	Electrical Systems	NSP Parking Sensors	Read Data Stream	
GranTurismo	2018	Pneumatic Systems	NTP_MY18	Version Information	
GranTurismo	2018	Pneumatic Systems	NTP_MY18	Read Fault Code;Clear Fault Memory	
GranTurismo	2018	Pneumatic Systems	NTP_MY18	Read Data Stream	
Alfa Romeo 8C	All Year	Engine	NCM ME7 Engine	Version Information	
Alfa Romeo 8C	All Year	Engine	NCM ME7 Engine	Read Fault Code;Clear Fault Memory	

model	year	system	subitem	function	subfunction
Alfa Romeo 8C	All Year	Engine	NCM ME7 Engine	Read Data Stream	
Alfa Romeo 8C	All Year	Brakes	EPB Elec. Parking Brake	Version Information	
Alfa Romeo 8C	All Year	Brakes	EPB Elec. Parking Brake	Read Fault Code;Clear Fault Memory	
Alfa Romeo 8C	All Year	Brakes	EPB Elec. Parking Brake	Read Data Stream	
Alfa Romeo 8C	All Year	Brakes	NFR Braking System Node	Version Information	
Alfa Romeo 8C	All Year	Brakes	NFR Braking System Node	Read Fault Code;Clear Fault Memory	
Alfa Romeo 8C	All Year	Brakes	NFR Braking System Node	Read Data Stream	
Alfa Romeo 8C	All Year	Transmission	NCR F1 Gearbox	Version Information	
Alfa Romeo 8C	All Year	Transmission	NCR F1 Gearbox	Read Fault Code;Clear Fault Memory	
Alfa Romeo 8C	All Year	Transmission	NCR F1 Gearbox	Read Data Stream	
Alfa Romeo 8C	All Year	Dashboard	NQS Dashboard	Version Information	
Alfa Romeo 8C	All Year	Dashboard	NQS Dashboard	Read Fault Code;Clear Fault Memory	
Alfa Romeo 8C	All Year	Dashboard	NQS Dashboard	Read Data Stream	
Alfa Romeo 8C	All Year	Dashboard	NQS Dashboard	Additional Functions	Service Information Reset
Alfa Romeo 8C	All Year	Security	AWS Siemens	Version Information	
Alfa Romeo 8C	All Year	Security	AWS Siemens	Read Fault Code;Clear Fault Memory	
Alfa Romeo 8C	All Year	Security	AWS Siemens	Read Data Stream	
Alfa Romeo 8C	All Year	Security	NAB Airbag TRW Node	Version Information	
Alfa Romeo 8C	All Year	Security	NAB Airbag TRW Node	Read Fault Code;Clear Fault Memory	
Alfa Romeo 8C	All Year	Security	NAB Airbag TRW Node	Read Data Stream	
Alfa Romeo 8C	All Year	Climate Control	NCL Air Conditioning System	Version Information	
Alfa Romeo 8C	All Year	Climate Control	NCL Air Conditioning System	Read Fault Code;Clear Fault Memory	
Alfa Romeo 8C	All Year	Climate Control	NCL Air Conditioning System	Read Data Stream	
Alfa Romeo 8C	All Year	Electrical Systems	NBC Body Computer	Version Information	
Alfa Romeo 8C	All Year	Electrical Systems	NBC Body Computer	Read Fault Code;Clear Fault Memory	

model	year	system	subitem	function	subfunction
Alfa Romeo 8C	All Year	Electrical Systems	NBC Body Computer	Read Data Stream	
Alfa Romeo 8C	All Year	Electrical Systems	NCP Roof	Version Information	
Alfa Romeo 8C	All Year	Electrical Systems	NCP Roof	Read Fault Code;Clear Fault Memory	
Alfa Romeo 8C	All Year	Electrical Systems	NCP Roof	Read Data Stream	
Alfa Romeo 8C	All Year	Electrical Systems	NIM Internal Roof Node	Version Information	
Alfa Romeo 8C	All Year	Electrical Systems	NIM Internal Roof Node	Read Fault Code;Clear Fault Memory	
Alfa Romeo 8C	All Year	Electrical Systems	NIM Internal Roof Node	Read Data Stream	
Alfa Romeo 8C	All Year	Electrical Systems	NPG Driver Door	Version Information	
Alfa Romeo 8C	All Year	Electrical Systems	NPG Driver Door	Read Fault Code;Clear Fault Memory	
Alfa Romeo 8C	All Year	Electrical Systems	NPG Driver Door	Read Data Stream	
Alfa Romeo 8C	All Year	Electrical Systems	NPP Passenger Door	Version Information	
Alfa Romeo 8C	All Year	Electrical Systems	NPP Passenger Door	Read Fault Code;Clear Fault Memory	
Alfa Romeo 8C	All Year	Electrical Systems	NPP Passenger Door	Read Data Stream	
Alfa Romeo 8C	All Year	Pneumatic Systems	NTP Tyre Pressure Beru	Version Information	
Alfa Romeo 8C	All Year	Pneumatic Systems	NTP Tyre Pressure Beru	Read Fault Code;Clear Fault Memory	
Alfa Romeo 8C	All Year	Pneumatic Systems	NTP Tyre Pressure Beru	Read Data Stream	
Grancabrio	As of 2017	Engine	NCM ME7 Engine	Version Information	
Grancabrio	As of 2017	Engine	NCM ME7 Engine	Read Fault Code;Clear Fault Memory	
Grancabrio	As of 2017	Engine	NCM ME7 Engine	Read Data Stream	
Grancabrio	As of 2017	Engine	NCM ME9 Engine	Version Information	
Grancabrio	As of 2017	Engine	NCM ME9 Engine	Read Fault Code;Clear Fault Memory	
Grancabrio	As of 2017	Engine	NCM ME9 Engine	Read Data Stream	
Grancabrio	As of 2017	Brakes	EPB Elec. Parking Brake	Version Information	
Grancabrio	As of 2017	Brakes	EPB Elec. Parking Brake	Read Fault Code;Clear Fault Memory	
Grancabrio	As of 2017	Brakes	EPB Elec. Parking Brake	Read Data Stream	
Grancabrio	As of 2017	Brakes	NFR Braking System Node	Version Information	
Grancabrio	As of 2017	Brakes	NFR Braking System Node	Read Fault Code;Clear Fault Memory	
Grancabrio	As of 2017	Brakes	NFR Braking System Node	Read Data Stream	
Grancabrio	As of 2017	Transmission	NCA Automatic Gearbox Node	Version Information	

model	year	system	subitem	function	subfunction
Grancabrio	As of 2017	Transmission	NCA Automatic Gearbox Node	Read Fault Code;Clear Fault Memory	
Grancabrio	As of 2017	Transmission	NCA Automatic Gearbox Node	Read Data Stream	
Grancabrio	As of 2017	Transmission	NCR F1 Gearbox	Version Information	
Grancabrio	As of 2017	Transmission	NCR F1 Gearbox	Read Fault Code;Clear Fault Memory	
Grancabrio	As of 2017	Transmission	NCR F1 Gearbox	Read Data Stream	
Grancabrio	As of 2017	Suspensions	NCS Skyhook Suspensions	Version Information	
Grancabrio	As of 2017	Suspensions	NCS Skyhook Suspensions	Read Fault Code;Clear Fault Memory	
Grancabrio	As of 2017	Suspensions	NCS Skyhook Suspensions	Read Data Stream	
Grancabrio	As of 2017	Dashboard	NQS Dashboard	Version Information	
Grancabrio	As of 2017	Dashboard	NQS Dashboard	Read Fault Code;Clear Fault Memory	
Grancabrio	As of 2017	Dashboard	NQS Dashboard	Read Data Stream	
Grancabrio	As of 2017	Dashboard	NQS Dashboard	Additional Functions	Service Information Reset
Grancabrio	As of 2017	Security	AWS Siemens	Version Information	
Grancabrio	As of 2017	Security	AWS Siemens	Read Fault Code;Clear Fault Memory	
Grancabrio	As of 2017	Security	AWS Siemens	Read Data Stream	
Grancabrio	As of 2017	Security	NAB Airbag TRW Node	Version Information	
Grancabrio	As of 2017	Security	NAB Airbag TRW Node	Read Fault Code;Clear Fault Memory	
Grancabrio	As of 2017	Security	NAB Airbag TRW Node	Read Data Stream	
Grancabrio	As of 2017	Climate Control	NCL Air Conditioning System	Version Information	
Grancabrio	As of 2017	Climate Control	NCL Air Conditioning System	Read Fault Code;Clear Fault Memory	
Grancabrio	As of 2017	Climate Control	NCL Air Conditioning System	Read Data Stream	
Grancabrio	As of 2017	Telematic	NIT Infotelematic Node	Version Information	
Grancabrio	As of 2017	Telematic	NIT Infotelematic Node	Read Fault Code;Clear Fault Memory	
Grancabrio	As of 2017	Telematic	NIT Infotelematic Node	Read Data Stream	
Grancabrio	As of 2017	Electrical Systems	CSG Sagem Servocontrol	Version Information	
Grancabrio	As of 2017	Electrical Systems	CSG Sagem Servocontrol	Read Fault Code;Clear Fault Memory	
Grancabrio	As of 2017	Electrical Systems	CSG Sagem Servocontrol	Read Data Stream	
Grancabrio	As of 2017	Electrical Systems	NAG Guide Adjust	Version Information	
Grancabrio	As of 2017	Electrical Systems	NAG Guide Adjust	Read Fault Code;Clear Fault Memory	
Grancabrio	As of 2017	Electrical Systems	NAG Guide Adjust	Read Data Stream	
Grancabrio	As of 2017	Electrical Systems	NBC Body Computer	Version Information	

model	year	system	subitem	function	subfunction
Grancabrio	As of 2017	Electrical Systems	NBC Body Computer	Read Fault Code;Clear Fault Memory	
Grancabrio	As of 2017	Electrical Systems	NBC Body Computer	Read Data Stream	
Grancabrio	As of 2017	Electrical Systems	NCP Roof	Version Information	
Grancabrio	As of 2017	Electrical Systems	NCP Roof	Read Fault Code;Clear Fault Memory	
Grancabrio	As of 2017	Electrical Systems	NCP Roof	Read Data Stream	
Grancabrio	As of 2017	Electrical Systems	NFA Headlight Master	Version Information	
Grancabrio	As of 2017	Electrical Systems	NFA Headlight Master	Read Fault Code;Clear Fault Memory	
Grancabrio	As of 2017	Electrical Systems	NFA Headlight Master	Read Data Stream	
Grancabrio	As of 2017	Electrical Systems	NFA Node Adaptative Headlight AI-Box Slave	Version Information	
Grancabrio	As of 2017	Electrical Systems	NFA Node Adaptative Headlight AI-Box Slave	Read Fault Code;Clear Fault Memory	
Grancabrio	As of 2017	Electrical Systems	NFA Node Adaptative Headlight AI-Box Slave	Read Data Stream	
Grancabrio	As of 2017	Electrical Systems	NIM Internal Roof Node	Version Information	
Grancabrio	As of 2017	Electrical Systems	NIM Internal Roof Node	Read Fault Code;Clear Fault Memory	
Grancabrio	As of 2017	Electrical Systems	NIM Internal Roof Node	Read Data Stream	
Grancabrio	As of 2017	Electrical Systems	NPG Driver Door	Version Information	
Grancabrio	As of 2017	Electrical Systems	NPG Driver Door	Read Fault Code;Clear Fault Memory	
Grancabrio	As of 2017	Electrical Systems	NPG Driver Door	Read Data Stream	
Grancabrio	As of 2017	Electrical Systems	NPP Passenger Door	Version Information	
Grancabrio	As of 2017	Electrical Systems	NPP Passenger Door	Read Fault Code;Clear Fault Memory	
Grancabrio	As of 2017	Electrical Systems	NPP Passenger Door	Read Data Stream	
Grancabrio	As of 2017	Electrical Systems	NSP Parking Sensors	Version Information	
Grancabrio	As of 2017	Electrical Systems	NSP Parking Sensors	Read Fault Code;Clear Fault Memory	
Grancabrio	As of 2017	Electrical Systems	NSP Parking Sensors	Read Data Stream	
Grancabrio	As of 2017	Pneumatic Systems	NTP 2.5 MY11	Version Information	
Grancabrio	As of 2017	Pneumatic Systems	NTP 2.5 MY11	Read Fault Code;Clear Fault Memory	

model	year	system	subitem	function	subfunction
Grancabrio	As of 2017	Pneumatic Systems	NTP 2.5 MY11	Read Data Stream	
Grancabrio	As of 2017	Pneumatic Systems	NTP Tyre Pressure Beru	Version Information	
Grancabrio	As of 2017	Pneumatic Systems	NTP Tyre Pressure Beru	Read Fault Code;Clear Fault Memory	
Grancabrio	As of 2017	Pneumatic Systems	NTP Tyre Pressure Beru	Read Data Stream	
Grancabrio	2018	Engine	NCM ME9 Engine	Version Information	
Grancabrio	2018	Engine	NCM ME9 Engine	Read Fault Code;Clear Fault Memory	
Grancabrio	2018	Engine	NCM ME9 Engine	Read Data Stream	
Grancabrio	2018	Brakes	EPB Elec. Parking Brake	Version Information	
Grancabrio	2018	Brakes	EPB Elec. Parking Brake	Read Fault Code;Clear Fault Memory	
Grancabrio	2018	Brakes	EPB Elec. Parking Brake	Read Data Stream	
Grancabrio	2018	Brakes	NFR Braking System Node	Version Information	
Grancabrio	2018	Brakes	NFR Braking System Node	Read Fault Code;Clear Fault Memory	
Grancabrio	2018	Brakes	NFR Braking System Node	Read Data Stream	
Grancabrio	2018	Transmission	NCA Automatic Gearbox Node	Version Information	
Grancabrio	2018	Transmission	NCA Automatic Gearbox Node	Read Fault Code;Clear Fault Memory	
Grancabrio	2018	Transmission	NCA Automatic Gearbox Node	Read Data Stream	
Grancabrio	2018	Suspensions	NCS Skyhook Suspensions	Version Information	
Grancabrio	2018	Suspensions	NCS Skyhook Suspensions	Read Fault Code;Clear Fault Memory	
Grancabrio	2018	Suspensions	NCS Skyhook Suspensions	Read Data Stream	
Grancabrio	2018	Dashboard	NQS Dashboard	Version Information	
Grancabrio	2018	Dashboard	NQS Dashboard	Read Fault Code;Clear Fault Memory	
Grancabrio	2018	Dashboard	NQS Dashboard	Read Data Stream	
Grancabrio	2018	Dashboard	NQS Dashboard	Additional Functions	Service Information Reset
Grancabrio	2018	Security	NAB Airbag TRW Node	Version Information	
Grancabrio	2018	Security	NAB Airbag TRW Node	Read Fault Code;Clear Fault Memory	
Grancabrio	2018	Security	NAB Airbag TRW Node	Read Data Stream	
Grancabrio	2018	Climate Control	NCL Air Conditioning System	Version Information	
Grancabrio	2018	Climate Control	NCL Air Conditioning System	Read Fault Code;Clear Fault Memory	
Grancabrio	2018	Climate Control	NCL Air Conditioning System	Read Data Stream	
Grancabrio	2018	Telematic	Amplifier New Premium 9 Chn (AMP_P9)	Version Information	
Grancabrio	2018	Telematic	Amplifier New Premium 9 Chn (AMP_P9)	Read Fault Code;Clear Fault Memory	

model	year	system	subitem	function	subfunction
Grancabrio	2018	Telematic	Amplifier New Premium 9 Chn (AMP_P9)	Read Data Stream	
Grancabrio	2018	Telematic	Entertainment	Version Information	
Grancabrio	2018	Telematic	Entertainment Module(ETM)	Read Fault Code;Clear Fault Memory	
Grancabrio	2018	Telematic	Entertainment	Read Data Stream	
Grancabrio	2018	Electrical Systems	CSG Sagem Servocontrol	Version Information	
Grancabrio	2018	Electrical Systems	CSG Sagem Servocontrol	Read Fault Code;Clear Fault Memory	
Grancabrio	2018	Electrical Systems	CSG Sagem Servocontrol	Read Data Stream	
Grancabrio	2018	Electrical Systems	NAG Guide Adjust	Version Information	
Grancabrio	2018	Electrical Systems	NAG Guide Adjust	Read Fault Code;Clear Fault Memory	
Grancabrio	2018	Electrical Systems	NAG Guide Adjust	Read Data Stream	
Grancabrio	2018	Electrical Systems	NBC Body Computer	Version Information	
Grancabrio	2018	Electrical Systems	NBC Body Computer	Read Fault Code;Clear Fault Memory	
Grancabrio	2018	Electrical Systems	NBC Body Computer	Read Data Stream	
Grancabrio	2018	Electrical Systems	NCP Roof	Version Information	
Grancabrio	2018	Electrical Systems	NCP Roof	Read Fault Code;Clear Fault Memory	
Grancabrio	2018	Electrical Systems	NCP Roof	Read Data Stream	
Grancabrio	2018	Electrical Systems	NFA Headlight Master	Version Information	
Grancabrio	2018	Electrical Systems	NFA Headlight Master	Read Fault Code;Clear Fault Memory	
Grancabrio	2018	Electrical Systems	NFA Headlight Master	Read Data Stream	
Grancabrio	2018	Electrical Systems	NFA Node Adaptative Headlight AI-Box Slave	Version Information	
Grancabrio	2018	Electrical Systems	NFA Node Adaptative Headlight AI-Box Slave	Read Fault Code;Clear Fault Memory	
Grancabrio	2018	Electrical Systems	NFA Node Adaptative Headlight AI-Box Slave	Read Data Stream	
Grancabrio	2018	Electrical Systems	NIM Internal Roof Node	Version Information	
Grancabrio	2018	Electrical Systems	NIM Internal Roof Node	Read Fault Code;Clear Fault Memory	
Grancabrio	2018	Electrical Systems	NIM Internal Roof Node	Read Data Stream	
Grancabrio	2018	Electrical Systems	NPG Driver Door	Version Information	

model	year	system	subitem	function	subfunction
Grancabrio	2018	Electrical Systems	NPG Driver Door	Read Fault Code;Clear Fault Memory	
Grancabrio	2018	Electrical Systems	NPG Driver Door	Read Data Stream	
Grancabrio	2018	Electrical Systems	NPP Passenger Door	Version Information	
Grancabrio	2018	Electrical Systems	NPP Passenger Door	Read Fault Code;Clear Fault Memory	
Grancabrio	2018	Electrical Systems	NPP Passenger Door	Read Data Stream	
Grancabrio	2018	Electrical Systems	NSP Parking Sensors	Version Information	
Grancabrio	2018	Electrical Systems	NSP Parking Sensors	Read Fault Code;Clear Fault Memory	
Grancabrio	2018	Electrical Systems	NSP Parking Sensors	Read Data Stream	
Grancabrio	2018	Pneumatic Systems	NTP_MY18	Version Information	
Grancabrio	2018	Pneumatic Systems	NTP_MY18	Read Fault Code;Clear Fault Memory	
Grancabrio	2018	Pneumatic Systems	NTP_MY18	Read Data Stream	
Levante	2016-2017	Engine	Engine Control Module V6 (ECM_V6)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Engine	Engine Control Module V6 (ECM_V6)	Read Data Stream	
Levante	2016-2017	Engine	Engine Control Module Diesel (ECM_V6D)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Engine	Engine Control Module Diesel (ECM_V6D)	Read Data Stream	
Levante	2016-2017	Braking Systems	Electrical Stability Control (ESC)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Braking Systems	Electrical Stability Control (ESC)	Read Data Stream	
Levante	2016-2017	Transmission	All Wheel Drive (AWD)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Transmission	All Wheel Drive (AWD)	Read Data Stream	
Levante	2016-2017	Transmission	Transmission Control Module (TCM)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Transmission	Transmission Control Module (TCM)	Read Data Stream	
Levante	2016-2017	Gearbox	Electronic Shifter Module (ESM)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Gearbox	Electronic Shifter Module (ESM)	Read Data Stream	
Levante	2016-2017	Suspensions	Active Suspensions Control Module (ASCM)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Suspensions	Active Suspensions Control Module (ASCM)	Read Data Stream	

model	year	system	subitem	function	subfunction
Levante	2016-2017	Heaters	Comfort Seats And Wheel Module (CSWM)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Heaters	Comfort Seats And Wheel Module (CSWM)	Read Data Stream	
Levante	2016-2017	Alarm	Intrusion Transceiver Module (ITM)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Alarm	Intrusion Transceiver Module (ITM)	Read Data Stream	
Levante	2016-2017	Dashboard	Integrated Panel Cluster (IPC)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Dashboard	Integrated Panel Cluster (IPC)	Read Data Stream	
Levante	2016-2017	Security	Driver Assistance System MODULE (DASM)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Security	Driver Assistance System MODULE (DASM)	Read Data Stream	
Levante	2016-2017	Security	Haptic Lane Feedback Module (HALF)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Security	Haptic Lane Feedback Module (HALF)	Read Data Stream	
Levante	2016-2017	Security	Left Blind Spot Sensor (LBSS)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Security	Left Blind Spot Sensor	Read Data Stream	
Levante	2016-2017	Security	Occupant Restraint Controller (ORC)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Security	Occupant Restraint Controller (ORC)	Read Data Stream	
Levante	2016-2017	Security	Right Blind Spot Sensor (RBSS)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Security	Right Blind Spot Sensor (RBSS)	Read Data Stream	
Levante	2016-2017	Climate Control	Heating, Ventilation And Air Conditioning (HVAC)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Climate Control	Heating, Ventilation And Air Conditioning (HVAC)	Read Data Stream	
Levante	2016-2017	Climate Control	Heating, Ventilation And Air Conditioning Rear (HVACR)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Climate Control	Heating, Ventilation And Air Conditioning Rear (HVACR)	Read Data Stream	
Levante	2016-2017	Telematic	Amplifier High Premium 16 Chn(AMP_HP16)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Telematic	Amplifier High Premium 16 Chn(AMP_HP16)	Read Data Stream	
Levante	2016-2017	Telematic	Amplifier New Premium 11 Chn (AMP_P9)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Telematic	Amplifier New Premium 11 Chn (AMP_P11)	Read Data Stream	
Levante	2016-2017	Telematic	Central Vision Processing Module (CVPM)	Read Fault Code;Clear Fault Memory	

model	year	system	subitem	function	subfunction
Levante	2016-2017	Telematic	Central Vision Processing Module (CVPM)	Read Data Stream	
Levante	2016-2017	Telematic	Digital Television(DTV)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Telematic	Digital Television(DTV)	Read Data Stream	
Levante	2016-2017	Telematic	Entertainment Module(ETM)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Telematic	Entertainment	Read Data Stream	
Levante	2016-2017	Telematic	Integrated Center Stack (ICS)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Telematic	Integrated Center Stack (ICS)	Read Data Stream	
Levante	2016-2017	Telematic	Telematic Box Module(TBM)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Telematic	Telematic Box	Read Data Stream	
Levante	2016-2017	Electrical Systems	Active Noise Cancelation (ANC)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Electrical Systems	Active Noise Cancelation (ANC)	Read Data Stream	
Levante	2016-2017	Electrical Systems	Adaptative Front Lighting System (AFLS)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Electrical Systems	Adaptative Front Lighting System (AFLS)	Read Data Stream	
Levante	2016-2017	Electrical Systems	Body Control Module (BCM)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Electrical Systems	Body Control Module (BCM)	Read Data Stream	
Levante	2016-2017	Electrical Systems	Door Module Rear Left(DMRL)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Electrical Systems	Door Module Rear Left(DMRL)	Read Data Stream	
Levante	2016-2017	Electrical Systems	Door Module Rear Right(DMRR)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Electrical Systems	Door Module Rear Right(DMRR)	Read Data Stream	
Levante	2016-2017	Electrical Systems	Driver Door Module (DDM)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Electrical Systems	Driver Door Module (DDM)	Read Data Stream	
Levante	2016-2017	Electrical Systems	Memory Seat Module(MSM)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Electrical Systems	Memory Seat Module(MSM)	Read Data Stream	
Levante	2016-2017	Electrical Systems	Parktronics Module (PTS)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Electrical Systems	Parktronics Module (PTS)	Read Data Stream	
Levante	2016-2017	Electrical Systems	Passenger Door Module (PDM)	Read Fault Code;Clear Fault Memory	

model	year	system	subitem	function	subfunction
Levante	2016-2017	Electrical Systems	Passenger Door Module (PDM)	Read Data Stream	
Levante	2016-2017	Electrical Systems	Power Lift Gate Module (PLGM)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Electrical Systems	Power Lift Gate Module (PLGM)	Read Data Stream	
Levante	2016-2017	Electrical Systems	Radio Frequency Hub(RFH)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Electrical Systems	Radio Frequency Hub(RFH)	Read Data Stream	
Levante	2016-2017	Electrical Systems	Steering Column Control Module (SCCM)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Electrical Systems	Steering Column Control Module (SCCM)	Read Data Stream	
Levante	2016-2017	Electrical Systems	Trailer Tow Module (TTM)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Electrical Systems	Trailer Tow Module (TTM)	Read Data Stream	
Levante	2016-2017	Pneumatic Systems	Tyre Pressure Monitor (TPM)	Read Fault Code;Clear Fault Memory	
Levante	2016-2017	Pneumatic Systems	Tyre Pressure Monitor (TPM)	Read Data Stream	
Levante	2018	Engine	Engine Control Module V6 (ECM_V6_MY18)	Read Fault Code;Clear Fault Memory	
Levante	2018	Engine	Engine Control Module V6 (ECM_V6_MY18)	Read Data Stream	
Levante	2018	Engine	Engine Control Module Diesel (ECM_V6D_MY18)	Read Fault Code;Clear Fault Memory	
Levante	2018	Engine	Engine Control Module Diesel (ECM_V6D_MY18)	Read Data Stream	
Levante	2018	Braking Systems	Electrical Stability Control (ESC_MY18)	Read Fault Code;Clear Fault Memory	
Levante	2018	Braking Systems	Electrical Stability Control (ESC_MY18)	Read Data Stream	
Levante	2018	Transmission	All Wheel Drive (AWD)	Read Fault Code;Clear Fault Memory	
Levante	2018	Transmission	All Wheel Drive (AWD)	Read Data Stream	
Levante	2018	Transmission	Transmission Control Module (TCM)	Read Fault Code;Clear Fault Memory	
Levante	2018	Transmission	Transmission Control Module (TCM)	Read Data Stream	
Levante	2018	Gearbox	Electronic Shifter Module (ESM)	Read Fault Code;Clear Fault Memory	
Levante	2018	Gearbox	Electronic Shifter Module (ESM)	Read Data Stream	
Levante	2018	Suspensions	Active Suspensions Control Module (ASCM)	Read Fault Code;Clear Fault Memory	
Levante	2018	Suspensions	Active Suspensions Control Module (ASCM)	Read Data Stream	

model	year	system	subitem	function	subfunction
Levante	2018	Heaters	Comfort Seats And Wheel Module (CSWM)	Read Fault Code;Clear Fault Memory	
Levante	2018	Heaters	Comfort Seats And Wheel Module (CSWM)	Read Data Stream	
Levante	2018	Alarm	Intrusion Transceiver Module (ITM)	Read Fault Code;Clear Fault Memory	
Levante	2018	Alarm	Intrusion Transceiver Module (ITM)	Read Data Stream	
Levante	2018	Dashboard	Integrated Panel Cluster (IPC)	Read Fault Code;Clear Fault Memory	
Levante	2018	Dashboard	Integrated Panel Cluster (IPC)	Read Data Stream	
Levante	2018	Security	Driver Assistance System MODULE (DASM)	Read Fault Code;Clear Fault Memory	
Levante	2018	Security	Driver Assistance System MODULE (DASM)	Read Data Stream	
Levante	2018	Security	Haptic Lane Feedback Module (HALF)	Read Fault Code;Clear Fault Memory	
Levante	2018	Security	Haptic Lane Feedback Module (HALF)	Read Data Stream	
Levante	2018	Security	Left Blind Spot Sensor (LBSS)	Read Fault Code;Clear Fault Memory	
Levante	2018	Security	Left Blind Spot Sensor	Read Data Stream	
Levante	2018	Security	Occupant Restraint Controller (ORC_MY18)	Read Fault Code;Clear Fault Memory	
Levante	2018	Security	Occupant Restraint Controller (ORC_MY18)	Read Data Stream	
Levante	2018	Security	Right Blind Spot Sensor (RBSS)	Read Fault Code;Clear Fault Memory	
Levante	2018	Security	Right Blind Spot Sensor (RBSS)	Read Data Stream	
Levante	2018	Climate Control	Heating, Ventilation And Air Conditioning (HVAC)	Read Fault Code;Clear Fault Memory	
Levante	2018	Climate Control	Heating, Ventilation And Air Conditioning (HVAC)	Read Data Stream	
Levante	2018	Climate Control	Heating, Ventilation And Air Conditioning Rear (HVACR)	Read Fault Code;Clear Fault Memory	
Levante	2018	Climate Control	Heating, Ventilation And Air Conditioning Rear (HVACR)	Read Data Stream	
Levante	2018	Telematic	Amplifier High Premium 16 Chn(AMP_HP16)	Read Fault Code;Clear Fault Memory	
Levante	2018	Telematic	Amplifier High Premium 16 Chn(AMP_HP16)	Read Data Stream	
Levante	2018	Telematic	Amplifier New Premium 11 Chn (AMP_P9)	Read Fault Code;Clear Fault Memory	
Levante	2018	Telematic	Amplifier New Premium 11 Chn (AMP_P11)	Read Data Stream	
Levante	2018	Telematic	Central Vision Processing Module (CVPM)	Read Fault Code;Clear Fault Memory	

model	year	system	subitem	function	subfunction
Levante	2018	Telematic	Central Vision Processing Module (CVPM)	Read Data Stream	
Levante	2018	Telematic	Digital Television(DTV)	Read Fault Code;Clear Fault Memory	
Levante	2018	Telematic	Digital Television(DTV)	Read Data Stream	
Levante	2018	Telematic	Entertainment Module(ETM)	Read Fault Code;Clear Fault Memory	
Levante	2018	Telematic	Entertainment	Read Data Stream	
Levante	2018	Telematic	Integrated Center Stack (ICS)	Read Fault Code;Clear Fault Memory	
Levante	2018	Telematic	Integrated Center Stack (ICS)	Read Data Stream	
Levante	2018	Telematic	Telematic Box Module(TBM)	Read Fault Code;Clear Fault Memory	
Levante	2018	Telematic	Telematic Box	Read Data Stream	
Levante	2018	Electrical Systems	Active Noise Cancelation (ANC)	Read Fault Code;Clear Fault Memory	
Levante	2018	Electrical Systems	Active Noise Cancelation (ANC)	Read Data Stream	
Levante	2018	Electrical Systems	Adaptative Front Lighting System (AFLS)	Read Fault Code;Clear Fault Memory	
Levante	2018	Electrical Systems	Adaptative Front Lighting System (AFLS)	Read Data Stream	
Levante	2018	Electrical Systems	Body Control Module (BCM_MY18)	Read Fault Code;Clear Fault Memory	
Levante	2018	Electrical Systems	Body Control Module (BCM_MY18)	Read Data Stream	
Levante	2018	Electrical Systems	Door Module Rear Left(DMRL)	Read Fault Code;Clear Fault Memory	
Levante	2018	Electrical Systems	Door Module Rear Left(DMRL)	Read Data Stream	
Levante	2018	Electrical Systems	Door Module Rear Right(DMRR)	Read Fault Code;Clear Fault Memory	
Levante	2018	Electrical Systems	Door Module Rear Right(DMRR)	Read Data Stream	
Levante	2018	Electrical Systems	Driver Door Module (DDM)	Read Fault Code;Clear Fault Memory	
Levante	2018	Electrical Systems	Driver Door Module (DDM)	Read Data Stream	
Levante	2018	Electrical Systems	Memory Seat Module(MSM)	Read Fault Code;Clear Fault Memory	
Levante	2018	Electrical Systems	Memory Seat Module(MSM)	Read Data Stream	
Levante	2018	Electrical Systems	Parktronics Module (PTS)	Read Fault Code;Clear Fault Memory	
Levante	2018	Electrical Systems	Parktronics Module (PTS)	Read Data Stream	
Levante	2018	Electrical Systems	Passenger Door Module (PDM)	Read Fault Code;Clear Fault Memory	

model	year	system	subitem	function	subfunction
Levante	2018	Electrical Systems	Passenger Door Module (PDM)	Read Data Stream	
Levante	2018	Electrical Systems	Power Lift Gate Module (PLGM)	Read Fault Code;Clear Fault Memory	
Levante	2018	Electrical Systems	Power Lift Gate Module (PLGM)	Read Data Stream	
Levante	2018	Electrical Systems	Radio Frequency Hub(RFH)	Read Fault Code;Clear Fault Memory	
Levante	2018	Electrical Systems	Radio Frequency Hub(RFH)	Read Data Stream	
Levante	2018	Electrical Systems	Steering Column Control Module (SCCM)	Read Fault Code;Clear Fault Memory	
Levante	2018	Electrical Systems	Steering Column Control Module (SCCM)	Read Data Stream	
Levante	2018	Electrical Systems	Trailer Tow Module (TTM)	Read Fault Code;Clear Fault Memory	
Levante	2018	Electrical Systems	Trailer Tow Module (TTM)	Read Data Stream	
Levante	2018	Electrical Systems	Electronic Steering Power (EPS)	Read Fault Code;Clear Fault Memory	
Levante	2018	Electrical Systems	Electronic Steering Power (EPS)	Read Data Stream	
Levante	2018	Electrical Systems	Security Gateway (SGW)	Read Fault Code;Clear Fault Memory	
Levante	2018	Electrical Systems	Security Gateway (SGW)	Read Data Stream	
Levante	2018	Pneumatic Systems	Tyre Pressure Monitor (TPM)	Read Fault Code;Clear Fault Memory	
Levante	2018	Pneumatic Systems	Tyre Pressure Monitor (TPM)	Read Data Stream	